



[Manuals.plus](#) /

> [Quoizel](#) /

> Quoizel Westover 22.75" Outdoor Wall Sconce (Model WVR8409EK) Instruction Manual

Quoizel WVR8409EK

Quoizel Westover 22.75" Outdoor Wall Sconce

MODEL: WVR8409EK

Instruction Manual

Introduction

Thank you for choosing the Quoizel Westover Outdoor Wall Sconce. This fixture is designed to provide elegant and durable outdoor lighting. Featuring clear beveled glass panels and a sturdy Earth Black finish, it is built to withstand outdoor elements while enhancing your home's exterior. This manual provides essential information for safe installation, operation, and maintenance of your new lighting fixture.



Image: The Quoizel Westover 22.75 inch Outdoor Wall Sconce, showcasing its Earth Black finish and clear beveled glass panels.

Safety Information

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be fatal or cause property damage. All wiring connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician or trained factory personnel if you are unfamiliar with wiring connections.

- **WARNING:** Risk of electric shock. Disconnect power at the main circuit breaker or fuse box before installation or servicing.
- This fixture is ETL listed for wet locations, ensuring reliable outdoor performance.
- Do not install this fixture on a surface that is not stable or capable of supporting its weight.
- Use only the specified bulb type and wattage to avoid overheating and potential damage.

What's in the Box

Your Quoizel Westover Outdoor Wall Sconce package includes the following components:

- 1 x Westover Wall Sconce (Lantern)
- Mounting Hardware (screws, wire nuts, mounting plate)
- Installation Instructions

Note: Bulbs are not included. This fixture requires two 15-watt LED candelabra base (E12) bulbs.

Setup and Installation

Follow these steps for proper installation of your outdoor wall sconce. It is recommended to have assistance due to the fixture's weight and size.

1. **Prepare for Installation:** Turn off the electrical power at the main fuse box or circuit breaker. Ensure the power is completely off before proceeding.
2. **Mounting Plate Installation:** Secure the universal mounting bracket (included) to your existing junction box. Ensure the bracket is firmly attached and level.
3. **Wiring Connections:** Connect the fixture's wires to your household electrical wires according to standard electrical codes. Typically, black to black (live), white to white (neutral), and green or bare copper to ground. Use the provided wire nuts and ensure all connections are secure.
4. **Attach Fixture to Mounting Plate:** Carefully align the fixture with the mounting plate and secure it using the provided screws. Ensure the fixture is flush against the wall and stable.
5. **Install Bulbs:** Insert two 15-watt LED candelabra base (E12) bulbs into the sockets. Do not exceed the maximum wattage.
6. **Restore Power:** Once installation is complete and all connections are secure, restore power at the main circuit breaker.

WESTOVER COLLECTION

Westover flush mounts feature clean lines and hand-riveted accents for bold industrial appeal, while the elongated rectangular frame offers a clear view of the sleek interior.



Earth Black Finish
4" H x 12" W x 12" D



Earth Black Finish
10" H x 5.75" W x 6.5" D



Earth Black Finish
14.25" H x 5" W x 6.5" D



Earth Black Finish
17" H x 6" W x 7.5" D



Earth Black Finish
20" H x 7" W x 8.5" D



Earth Black Finish
30" H x 9" W x 10.25" D

Earth Black Finish
20.5" H x 7" W x 7" D



Earth Black Finish
20.75" H x 7" W x 7" D

LIGHTING THAT FEELS LIKE HOME - INSIDE AND OUT

Image: Visual representation of the weather-resistant, water-resistant, and heat-resistant features of the Westover Wall Sconce, highlighting its durability for outdoor use.

Operating Instructions

The Quozel Westover Outdoor Wall Sconce operates via your home's standard wall switch. This fixture is designed to be dimmable, allowing you to adjust the light intensity with a compatible dimmer switch (sold separately).

- **Turning On/Off:** Use your existing wall switch to turn the light fixture on or off.
- **Dimming Function:** If a compatible dimmer switch is installed, rotate or slide the dimmer control to adjust the brightness of the bulbs. Ensure you use dimmable E12 LED bulbs for this feature.



Image: A detailed view of the interior of the Quoizel Westover Sconce, highlighting the two E12 candelabra base sockets where bulbs are installed.

Maintenance

Regular maintenance will help preserve the appearance and functionality of your Quoizel Westover Outdoor Wall Sconce.

- **Cleaning:** To clean the fixture, turn off the power and wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or glass.
- **Glass Care:** The clear beveled glass panels can be carefully removed for thorough cleaning if necessary. Handle with care to prevent breakage.
- **Bulb Replacement:** Ensure power is off before replacing bulbs. Allow bulbs to cool completely before touching. Replace with two 15-watt LED candelabra base (E12) bulbs.
- **Inspection:** Periodically inspect the fixture for any signs of wear, loose connections, or damage. Address any issues promptly to ensure safe operation.

Troubleshooting

If you experience issues with your Quoizel Westover Outdoor Wall Sconce, refer to the following common

troubleshooting steps:

Problem	Possible Cause	Solution
Light does not turn on	<ol style="list-style-type: none">1. Power is off2. Loose wiring connection3. Faulty bulb	<ol style="list-style-type: none">1. Check circuit breaker/fuse2. Verify all wiring connections are secure (power off first)3. Replace bulb(s)
Light flickers	<ol style="list-style-type: none">1. Loose bulb2. Incompatible dimmer switch/bulb3. Loose wiring	<ol style="list-style-type: none">1. Tighten bulb(s)2. Ensure dimmer and bulbs are compatible3. Check wiring connections (power off first)
Glass panels are dirty	Environmental exposure	Clean with a soft, damp cloth. For stubborn dirt, carefully remove panels and wash with mild soap and water.

Specifications

Detailed specifications for the Quoizel Westover 22.75" Outdoor Wall Sconce (Model WVR8409EK):

Feature	Detail
Brand	Quoizel
Model Number	WVR8409EK
Color	Earth Black
Material	Alloy Steel, Glass
Light Fixture Form	Wall Sconce
Room Type	Outdoor
Indoor/Outdoor Usage	Outdoor
Power Source	AC/DC
Special Features	Dimmable
Number of Light Sources	2
Voltage	120 Volts
Light Color	Clear (from glass)
Lighting Method	LED (recommended)
Wattage	15 watts (per bulb, max)
Bulb Base	E12 (Candelabra)
Water Resistance Level	Waterproof (Wet Rated)
Mounting Type	Wall Mount, Surface Mount

Feature	Detail
Specification Met	ETL Listed
Item Dimensions (L x W x H)	10.25"L x 9"W x 22.75"H



Image: Detailed product dimensions for the Quoizel Westover 22.75 inch Outdoor Wall Sconce, including height, width, and backplate size.

Warranty and Support

Your Quoizel Westover Outdoor Wall Sconce is backed by a 3-Year Quoizel Limited Warranty. This warranty covers defects in materials and workmanship under normal use.

- **Warranty Details:** For specific terms and conditions of the 3-Year Limited Warranty, please refer to the warranty documentation included with your purchase or visit the official Quoizel website.
- **Customer Support:** If you have any questions regarding installation, operation, or warranty claims, please contact Quoizel customer support. Contact information can typically be found on the product packaging or the official Quoizel website.

Additional protection plans may be available for purchase separately, offering extended coverage beyond

the manufacturer's limited warranty.