

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Kichler](#) /

› [Kichler Daya 54-inch LED Ceiling Fan Instruction Manual](#)

Kichler 310072SBK

Kichler Daya 54-inch LED Ceiling Fan Instruction Manual

Model: 310072SBK

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Kichler Daya 54-inch LED Ceiling Fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

The Daya 54-inch ceiling fan features an LED light diffused through Satin Etched Cased Opal Glass, encased by a decorative cage. Its Satin Black finish offers a modern industrial and coastal aesthetic. The fan includes a variable blade pitch for efficient air movement and an integrated LED module to illuminate your room.



Image: Overall view of the Kichler Daya 54-inch LED Ceiling Fan, showcasing its Satin Black finish and integrated LED light with an etched cased opal glass diffuser.

SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always turn off power at the main circuit breaker or fuse box before beginning installation or performing any maintenance.

- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Ensure the installation site is structurally sound and capable of supporting the fan's weight (approximately 25.2 pounds).
- Do not operate the fan with damaged blades or housing.
- Keep hands, clothing, and other objects clear of the fan blades during operation.
- This fan is designed for indoor use only.

For detailed safety instructions, refer to the complete installation guide provided with your product.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- (5) 54-inch ABS fan blades
- (1) 172mm x 20mm AC motor
- (1) Mounting Kit
- (1) Hanger System
- (1) 4.5 inch Down rod
- (1) LED module with Etched Cased Opal Glass
- (1) 65K Wall Control System-Full Function



Image: Close-up view of the Kichler Daya fan blades, highlighting their satin black finish and durable ABS material.

SPECIFICATIONS

Feature	Detail
Brand	Kichler
Model Name	Daya

Item Model Number	310072SBK
Color	Satin Black
Electric Fan Design	Ceiling Fan
Power Source	AC
Style	Traditional
Product Dimensions	54"D x 54"W x 15.5"H
Room Type	Living Room
Special Feature	Heavy Duty
Recommended Uses	Air Circulation
Wattage	23 watts
Voltage	120 Volts
Item Weight	25.2 Pounds
Indoor/Outdoor Usage	Indoor
Specification Met	UL Listed
Control Method	Remote (via 65K Wall Control System)
Efficiency	High Energy Efficiency
Number of Power Levels	3
Motor Type	AC Induction
Type of Bulb	LED
Luminous Flux	2200 Lumen

SETUP (INSTALLATION)

Installation of a ceiling fan requires electrical knowledge and adherence to safety standards. Kichler recommends professional installation for optimal safety and performance.

General Installation Overview:

- 1. Prepare the Installation Site:** Ensure power is disconnected at the circuit breaker. Confirm the ceiling junction box is securely mounted and capable of supporting the fan's weight.
- 2. Mount the Hanger Bracket:** Attach the hanger bracket to the ceiling junction box using appropriate hardware.
- 3. Assemble the Downrod and Motor:** Secure the downrod to the fan motor assembly.
- 4. Wire the Fan:** Connect the fan's electrical wires to the household wiring according to the provided wiring diagram in the full instruction manual.
- 5. Attach the Fan Blades:** Securely attach the five fan blades to the motor housing.
- 6. Install the Light Kit:** Connect and install the LED module with the Etched Cased Opal Glass.
- 7. Install the Wall Control:** Wire and install the 65K Wall Control System according to its specific instructions.

For detailed, step-by-step installation instructions, including wiring diagrams and specific hardware requirements, please refer to the comprehensive installation manual included with your Kichler Daya Ceiling Fan. Failure to follow these instructions can result in electric shock, fire, or personal injury.



Image: Detailed view of the Kichler Daya fan's central light fixture, showing the etched cased opal glass diffuser and the surrounding decorative cage.

OPERATING INSTRUCTIONS

Your Kichler Daya Ceiling Fan is controlled by the included 65K Wall Control System, which offers full functionality for fan speed and light operation.

Fan Operation:

- The fan features three distinct speed settings: Low, Medium, and High.
- Use the fan speed buttons on the wall control to cycle through the desired speed or turn the fan off.
- The variable blade pitch is designed to optimize air movement across all speeds.

Light Operation:

- The integrated LED light can be turned On or Off using the dedicated light button on the wall control.
- The LED module provides 2200 lumens of ambient light.

Refer to the 65K Wall Control System manual for specific button functions and advanced features.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Kichler Daya Ceiling Fan.

- **Cleaning:** Dust the fan blades and motor housing periodically with a soft, lint-free cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- **Glass Cleaning:** The Etched Cased Opal Glass can be cleaned with a mild glass cleaner and a soft cloth. Ensure the light is off and cool before cleaning.
- **Blade Inspection:** Periodically check the fan blades for any signs of damage or warping. The durable plastic blades are designed to resist warping in moisture.
- **Tightening Fasteners:** Annually, check all screws and fasteners on the fan and mounting hardware to ensure they are secure.

CAUTION: Always disconnect power to the fan at the circuit breaker before cleaning or performing any maintenance.

TROUBLESHOOTING

If you experience issues with your Kichler Daya Ceiling Fan, consult the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wire connections; incorrect wall control settings.	Check circuit breaker/fuses. Ensure all wire connections are secure. Verify wall control is set to ON and desired speed.
Light does not work	Loose wire connections; faulty LED module; incorrect wall control settings.	Check wire connections to the light kit. Ensure wall control light button is pressed. If issues persist, contact Kichler support for LED module replacement.
Fan wobbles	Loose blades or mounting hardware; unbalanced blades.	Ensure all blade screws and mounting hardware are tight. Use a balancing kit (not included) if necessary.
Noisy operation	Loose screws; motor issues; blades hitting an obstruction.	Check all screws for tightness. Ensure no obstructions are in the fan's path. If motor noise persists, contact Kichler support.

If these steps do not resolve the issue, please contact Kichler customer support or a qualified electrician.

WARRANTY AND SUPPORT

Your Kichler Daya 54-inch LED Ceiling Fan is backed by a **Limited Lifetime Warranty**. This warranty covers defects in materials and workmanship under normal use and service.

For warranty claims, technical assistance, or to purchase replacement parts, please contact Kichler Customer Support:

- **Website:** www.kichler.com
- **Phone:** Refer to the Kichler website for regional contact numbers.

- Please have your model number (310072SBK) and date of purchase available when contacting support.

ADDITIONAL INFORMATION

Kichler Gentry Ceiling Fan Collection Overview

Explore the broader Kichler Gentry Collection, which features a range of ceiling fans designed with visually stunning aesthetics and industrial-era finishes, complementing various rustic styles. This video provides an overview of the collection's design philosophy.

Your browser does not support the video tag.

Video: An overview of the Kichler Gentry Ceiling Fan Collection, showcasing various models and design elements, including industrial-era finishes and rustic styles.

About Kichler Lighting

Kichler Lighting is dedicated to creating lighting solutions that are integral to special moments. With over 85 years of experience, Kichler focuses on quality, service, and continuous improvement to illuminate lives. This video shares the brand's story and commitment.

Your browser does not support the video tag.

Video: The Kichler Brand Story, highlighting their commitment to quality lighting and design over 85 years.

© 2024 Kichler Lighting LLC. All Rights Reserved.

For the most up-to-date information, please visit the official Kichler website.