

LEGAMI BASK0001

Legami Mini Basket Arcade Game BASK0001 Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and proper use of your Legami Mini Basket Arcade Game, Model BASK0001. Please read these instructions thoroughly before operating the product and retain them for future reference.



Figure 1: Legami Mini Basket Arcade Game (Model BASK0001)

The Legami Mini Basket Arcade Game is a compact, battery-operated game designed for single-player entertainment. It features a basketball hoop, a spring-loaded shooting mechanism, and a digital score display with integrated lights and sounds. The game offers three adjustable time intervals for play.

SAFETY INFORMATION

- **Adult Supervision:** Recommended for younger users.
- **Battery Safety:** Use only the specified battery type (3x AA). Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity (+/-). Remove exhausted batteries promptly. Do not recharge non-rechargeable batteries.
- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age.
- **Product Care:** Do not expose the game to water or extreme temperatures. Avoid dropping the unit.

PACKAGE CONTENTS

- 1 x Legami Mini Basket Arcade Game (Model BASK0001)

Note: 3x AA batteries are not included and must be purchased separately.

SETUP

1. **Battery Installation:** Locate the battery compartment on the underside or back of the unit. Using a small screwdriver (not included), open the battery compartment cover. Insert 3 new AA batteries, ensuring correct polarity (+ and -). Close the compartment cover and secure it with the screw.




Figure 2: Battery Installation (3x AA batteries not included)

2. **Placement:** Place the Mini Basket Arcade Game on a stable, flat surface.

OPERATING INSTRUCTIONS

1. **Power On:** Locate the ON/OFF switch, usually on the back or side of the unit. Slide the switch to the 'ON' position. The game will power on with lights and sounds.
2. **Start Game:** Press the large red button on the front of the unit to start a game. The digital display will show the countdown for the selected game interval.
3. **How to Play:** During the game, press the large red button to launch the mini basketball towards the hoop. Each successful basket will be registered on the digital score display, accompanied by lights and sounds.



Figure 3: Operating the Game by Pressing the Shooting Button

4. **Game Intervals:** The game offers three time intervals: 45, 90, or 120 seconds. To select an interval, look for a dedicated button or switch, typically labeled 'TIME' or 'MODE'. Press or slide it to cycle through the available options. The selected time will be indicated on the display.
5. **End of Game:** The game ends when the timer runs out. Your final score will be displayed.
6. **Power Off:** When finished playing, slide the ON/OFF switch to the 'OFF' position to conserve battery life.

MAINTENANCE

- **Cleaning:** Wipe the surface of the game with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the game in a cool, dry place away from direct sunlight. If storing for an extended period, remove the batteries to prevent leakage.
- **Battery Replacement:** Replace all 3 AA batteries when the lights dim, sounds become distorted, or

the game functions erratically.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Game does not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity. Replace with new AA batteries.
Lights and sounds are weak or distorted.	Low battery power.	Replace all 3 AA batteries.
Basketball does not launch properly.	Shooting mechanism obstruction or damage.	Ensure no debris is blocking the mechanism. If damaged, discontinue use.
Score display is not working.	Battery issue or internal malfunction.	Check/replace batteries. If problem persists, contact customer support.

SPECIFICATIONS

- **Model:** BASK0001
- **Brand:** LEGAMI
- **Dimensions (L x W x H):** 10 cm x 22 cm x 32.5 cm
- **Power Source:** 3 x AA Batteries (not included)
- **Material:** ABS
- **Display Type:** LED
- **Controller Type:** Button Control
- **Number of Players:** 1
- **Game Intervals:** 45, 90, 120 seconds
- **Assembly Required:** No
- **Educational Goal:** Improve hand-eye coordination and quick decision-making skills

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the point of purchase or visit the official Legami website. Keep your purchase receipt as proof of purchase.