Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ABCTen Horizontal Case

ABCTen Universal Canvas Phone Holster

Model: Horizontal Case

Introduction

This manual provides instructions for the proper use and care of your ABCTen Universal Canvas Phone Holster. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image: The ABCTen Universal Canvas Phone Holster shown attached horizontally to a belt, providing a secure and accessible way to carry a mobile phone.

Setup

The ABCTen Universal Canvas Phone Holster offers two primary methods for attachment to your belt or clothing: a belt clip and two belt loops. Choose the method that best suits your needs for security and convenience.

Attaching with Belt Loops

1. Locate the two fabric loops on the back of the holster.
2. Thread your belt through both loops, ensuring the holster is positioned comfortably on your waist.
3. Adjust the holster's position as needed. This method provides maximum security, preventing accidental detachment.

Attaching with Belt Clip

1. Locate the metal belt clip on the back of the holster.

2. Slide the clip over your belt or the waistband of your pants.
3. Ensure the clip is firmly attached. This method offers quick attachment and removal.



Image: A visual guide demonstrating the two attachment options: threading a belt through the integrated belt loops for enhanced security, and using the metal belt clip for quick and easy attachment to a belt or waistband.

Operating Instructions

This section details how to properly insert and secure your mobile phone within the holster.

Inserting Your Phone

1. Open the top flap of the holster, which is secured by a strong nylon hook-and-loop fastener.
2. Gently slide your mobile phone into the main compartment of the holster. The elastic stretch bands on the sides will adapt to the phone's width, providing a snug fit.

3. Ensure the phone is fully seated within the holster.

Securing Your Phone

1. Once the phone is inside, fold the top flap down over the phone.
2. Press firmly on the flap to engage the nylon hook-and-loop fastener, ensuring it is securely closed. This strong closure prevents accidental opening and keeps your phone safe.



Image: The holster with its top flap open, revealing the strong nylon hook-and-loop fastener designed to secure the phone inside and prevent accidental opening.



Image: A mobile phone being partially inserted into the holster, demonstrating the ease of access and the internal space available for the device.

Maintenance

To ensure the longevity and appearance of your ABCTen Universal Canvas Phone Holster, follow these simple maintenance guidelines:

- **Cleaning:** The holster is constructed from durable nylon material. For general cleaning, wipe the exterior with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners, as these can damage the fabric.
- **Drying:** Allow the holster to air dry completely after cleaning. Do not machine wash or tumble dry.
- **Storage:** Store the holster in a cool, dry place away from direct sunlight when not in use.

Troubleshooting

If you encounter any issues with your holster, consider the following common points:

- **Phone does not fit:** Verify your phone's dimensions against the holster's internal size specifications. The holster is

designed for phones with similar dimensions to those listed in the specifications section.

- **Holster feels loose on belt:** Ensure your belt is threaded through both belt loops for maximum security. If using the belt clip, confirm it is fully engaged over your belt or waistband.
- **Flap not closing securely:** Check for any debris or obstructions on the hook-and-loop fastener. Clean if necessary. Ensure the phone is fully inserted and not overfilling the holster.

Specifications

Detailed specifications for the ABCTen Universal Canvas Phone Holster (Horizontal Case):

- **Internal Dimensions:** Approximately 16.6 cm (6.53 inches) x 8.5 cm (3.34 inches) x 2 cm (0.78 inches)
- **Material:** Durable Nylon
- **Form Factor:** Pouch
- **Fastener Type:** Clip On / Belt Loops (Hook-and-loop flap closure)
- **Compatible Phone Models (examples):** Infinix Hot 8 Lite, Hot 9, Note 7 Lite, S5 Lite, HiSense E30 (5.99"), Xiaomi Redmi Note 9 / K30 Pro, Samsung Galaxy Note 20, OnePlus 8, iPhone Xs Max, 6 plus, 6s plus, 7 plus, 8plus, Samsung Galaxy S8 Plus, Huawei G7, Huawei P9 plus, Huawei Mate 7 (6 inch), Huawei Mate 8 (6 inch), Huawei Google Nexus 6P (5.7inch), LG G3, G4, Samsung Galaxy Note 5, 4, 3, 2. (*Note: Compatible with phones of similar size to the internal dimensions.*)



Image: A detailed diagram illustrating the external and internal dimensions of the holster, including length, width, and thickness, to help users determine phone compatibility.

Warranty and Support

For information regarding product warranty, returns, or customer support, please refer to the purchase documentation or contact the manufacturer, ABCTen, directly through their official channels. This manual does not constitute a warranty statement.

© 2026 ABCTen. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08PNVYQNJ

More documents and user manuals: **https://manuals.plus/**