



Manuals.plus /

› DEERFAMY /

› DEERFAMY Hammock Chair Model 00702BL Instruction Manual

DEERFAMY 00702BL

DEERFAMY Hammock Chair Model 00702BL Instruction Manual

Your Guide to Setup, Operation, and Maintenance

INTRODUCTION

Thank you for choosing the DEERFAMY Hammock Chair, Model 00702BL. This portable and comfortable swinging chair is designed for various outdoor environments, including camping, backyard relaxation, and other leisure activities. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new hammock chair. Please read these instructions thoroughly before use and retain them for future reference.

SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Ensure proper assembly of all components before use.
- Do not exceed the maximum weight capacity of 350 pounds (158 kg).
- Always place the chair on a firm, level surface to ensure stability and prevent tipping.
- Exercise caution when using the footrest, phone pocket, and cup holder to avoid potential hazards such as entanglement or spills.
- Keep children and pets away from the chair during assembly and ensure they are supervised when near the chair during use.
- Inspect the chair for any damage or wear before each use. Do not use if any parts are damaged or missing.

PACKAGE CONTENTS

Verify that all items are present in the package:

- DEERFAMY Hammock Chair Frame
- Hammock Chair Fabric Seat
- Storage Bag

If any components are missing or damaged, please contact DEERFAMY customer support.

SETUP INSTRUCTIONS

The DEERFAMY Hammock Chair is designed for quick and easy setup.


1. **Unfold the Frame:** Remove the chair frame from the storage bag. Gently pull the legs apart until the frame is fully extended.
2. **Secure the Locks:** Locate the yellow security locks on the frame joints. Ensure they are pushed into the 'Locked' position to prevent accidental folding.
3. **Attach the Seat:** Unfold the fabric hammock seat. Locate the metal hooks on the top corners of the seat and attach them securely to the corresponding pins on the top of the chair frame.
4. **Adjust Footrest (Optional):** If desired, adjust the footrest straps to your preferred length for comfort.
5. **Final Check:** Before sitting, gently press down on the seat to ensure all connections are secure and the chair is stable.

Easy setup and folding

Setup or organize in seconds



Figure 1: Easy setup and folding process. The image displays the chair in three stages: organized in its storage bag, folded, and fully unfolded for use.



Unique security lock design

Figure 2: Detail of the unique security lock design. Ensure the lock is in the 'Locked' position for safe use.

OPERATING INSTRUCTIONS

Once assembled, the DEERFAMY Hammock Chair offers a comfortable and relaxing experience.

- **Sitting:** Carefully sit into the chair, distributing your weight evenly. The chair is designed to rock gently.
- **Using the Footrest:** Place your feet into the adjustable footrest straps for added comfort and support. Adjust the strap length as needed.

- **Cup Holder:** Utilize the integrated cup holder on the side for beverages. Ensure cups are securely placed to prevent spills.
- **Phone Pocket:** Store your mobile phone or small items in the mesh pocket located on the side of the seat.
- **Portability:** To move the chair, ensure no one is sitting in it. For transport, fold the chair and place it in its storage bag.



Figure 3: Enhanced features including an extra cup holder, a mobile phone pocket, and an adjustable footrest for user convenience.

Weight capacity up to **350** lbs



Thickened steel
frame



600D polyester
fabric



Figure 4: The chair in use, showcasing its robust design with a 350 lbs weight capacity, constructed from thickened steel and 600D polyester fabric.

MAINTENANCE

Proper care will extend the life of your DEERFAMY Hammock Chair.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use mild soap and water. Rinse thoroughly and allow to air dry completely before folding and storing. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, fold the chair and store it in its included storage bag in a dry, cool place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all frame connections, fabric, and stitching for signs of wear, tear, or damage. Address any issues promptly to ensure continued safe use.



Intensive stitching

Figure 5: Detail of the intensive stitching, indicating durability and quality construction.

TROUBLESHOOTING

If you encounter issues with your hammock chair, refer to the following common problems and solutions:

- **Chair feels unstable:** Ensure the chair is placed on a completely level surface. Verify that all frame joints are fully extended and the security locks are engaged in the 'Locked' position. Check that the fabric seat is correctly attached to the frame hooks.
- **Difficulty folding/unfolding:** Ensure the security locks are disengaged before attempting to fold the chair. If unfolding, ensure the frame is fully extended until it clicks into place.
- **Fabric tearing or fraying:** Discontinue use immediately. Contact customer support for assistance. Regular inspection and proper storage can help prevent this.

SPECIFICATIONS

Feature	Detail
Brand	DEERFAMY
Model Name	00702BL
Product Dimensions	32"D x 38.5"W x 37.8"H
Weight Capacity	Up to 350 lbs (158 kg)
Item Weight	12.92 pounds (5.86 kg)
Material	600D Polyester, Nylon Mesh, Steel Frame
Special Features	Breathable, Foldable, Portable, Cup Holder, Foot Rest
Care Instructions	Wipe Clean
Included Components	Storage Bag



Figure 6: Product dimensions for the DEERFAMY Hammock Chair.



Figure 7: Detailed packaging and unfolded dimensions of the hammock chair.

WARRANTY AND SUPPORT

DEERFAMY stands behind the quality of its products. For specific warranty details or to inquire about support, please refer to the warranty card included with your purchase or visit the official DEERFAMY website. For immediate assistance, you may also contact DEERFAMY customer service through the retailer where the product was purchased.

Online Resources:

- Visit the DEERFAMY Store on Amazon for product information and support.