

[Manuals.plus](#) /

› [YOBYBO](#) /

› YOBYBO NOTE20 Wireless Earbuds Instruction Manual

YOBYBO NOTE20

YOBYBO NOTE20 Wireless Earbuds Instruction Manual

1. INTRODUCTION

The YOBYBO NOTE20 Wireless Earbuds are designed for a comfortable and high-quality audio experience. These earbuds feature Bluetooth 5.0 connectivity, an ergonomic in-ear design, and touch controls. The compact charging case supports both USB Type-C and wireless charging. The NOTE20 has been recognized with the Red Dot Award 2020 for its unique design.



reddot winner 2020

キブンが上がる

デザイナーズイヤホン

NOTE20

- 世界最軽量クラス TWSイヤホン -



カラバリは4色

あなたの好きなカラーが
きっと見つかる

唯一無二のデザイン

天窓設計でイヤホンの
取り出しも楽々

世界最薄・最軽量

収納はもちろん
持ち運びにも便利

耳が痛くならない

特許技術採用の
ショートイヤーパーズ

Figure 1.1: YOBYBO NOTE20 Wireless Earbuds in various colors, showcasing the compact design.

The earbuds are ultra-lightweight, with each earbud weighing approximately 4.5 grams. The charging case is notably thin at 13.5 mm, making the entire unit highly portable.

Unique Design

イヤホンをアクセサリー感覚で

他人とは一味違うオシャレを



reddot winner 2020
best of the best

思わず一目惚れしちゃう♡

唯一無二のイヤホン



＼イヤホンが取り出しやすい／
オープンドデザイン



ケースの裏側も天窓設計。
カンタンにイヤホンを取り出せる。

Figure 1.2: The YOBYBO NOTE20 case, demonstrating its compact size and ease of carrying.

2. WHAT'S IN THE BOX

Please check the package contents upon unboxing:

- YOBYBO NOTE20 Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- Replacement Short Earpieces (2 pairs)
- User Manual

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. The case supports both USB Type-C cable charging and wireless charging.

- **USB Type-C Charging:** Connect the provided USB Type-C cable to the charging port on the case and to a power source.
- **Wireless Charging:** Place the charging case on a compatible wireless charging pad.

The earbuds provide approximately 4 to 5 hours of continuous playback on a single charge. The charging case extends the total playback time to about 25 to 30 hours. A full charge for the case typically takes 1 hour.

クリアな中高音域と パワフルな低音再生

10mm口径のダイナミックドライバーを搭載

高音質・低遅延な
AACコーデック搭載



臨場感あふれる音で
ボーカルや楽器の音も鮮明に

1日中バッテリー切れを気にしない

25時間の長時間再生



Figure 3.1: Battery life and charging overview.

3.2 Pairing with a Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and search for available devices.
4. Select "YOBYBO NOTE20" from the list to connect.

The NOTE20 uses MCSync technology, allowing each earbud to receive signals directly from your device, enhancing connection stability and reducing delays. You can also use a single earbud by simply removing one from the case while leaving the other in.

3.3 Achieving a Comfortable Fit

The NOTE20 earbuds feature an ergonomic, asymmetrical design with patented short earpieces to ensure a comfortable fit without causing ear canal discomfort, even during extended use.

1. Gently insert the earbud into your ear.
2. Rotate the earbud slightly to find the most comfortable and secure angle. The asymmetrical design is intended to conform to the natural shape of your ear.
3. If needed, try the alternative short earpieces provided to optimize the fit.

Comfortable and Super Fit, No Pain

耳が痛くならない、快適なフィット感

もう他のイヤホンには戻れない・・・



「しっかりとフィットするので
着けているのを忘れてしまうくらいです。」

The Ultra Thin and Lightest Earbuds

世界最薄 最軽量クラス

薄くて軽い! 普段使いに最適




Figure 3.2: Proper insertion and fit of the earbud.

業界初!!

耳が痛くならないカナル型イヤホン登場 人間工学に基づく独自設計が極上の装着感を演出

- ✔ 特許技術のショートイヤピースを採用!
- ✔ 耳の中を傷つけない非対称設計が極上の装着感を実現!



当製品

丁度良い

快適なつけ心地

従来品

長過ぎる

短過ぎる

イタくて重たい...

音漏れが凄い...

Figure 3.3: Comparison of YOBAYO NOTE20's ergonomic design with traditional earbuds.

4. OPERATING INSTRUCTIONS

The YOBYBO NOTE20 earbuds feature touch controls for various functions:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold on either earbud during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud (functionality may vary by device).

The earbuds automatically power on when removed from the charging case and power off when placed back into the case.

5. MAINTENANCE

To ensure the longevity and optimal performance of your YOBYBO NOTE20 earbuds:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals.
- **Water Resistance:** The earbuds are waterproof and sweatproof. However, they are not designed for submersion in water. Avoid exposing them to strong jets of water or wearing them while swimming. Dry them thoroughly if they get wet.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) or high humidity.

6. TROUBLESHOOTING

If you encounter issues with your YOBYBO NOTE20 earbuds, try the following steps:

6.1 No Sound or Intermittent Connection

- Ensure both earbuds are charged.
- Make sure Bluetooth is enabled on your device and the earbuds are selected.
- Try placing the earbuds back in the case, closing it, and then reopening it to re-establish the connection.
- If the issue persists, unpair "YOBYBO NOTE20" from your device's Bluetooth settings and then repeat the pairing process (Section 3.2).
- Ensure there are no obstructions between your device and the earbuds.

6.2 Earbuds Not Charging

- Check that the charging cable is securely connected to both the case and the power source.
- If using wireless charging, ensure the case is correctly positioned on the charging pad.
- Verify that the charging contacts on the earbuds and inside the case are clean and free of debris.
- Ensure the charging case itself has sufficient power.

6.3 Poor Sound Quality

- Ensure the earbuds are properly seated in your ears for a good seal.
- Clean any earwax or debris from the earbud nozzles.
- Try adjusting the volume on both your device and the earbuds.
- Move closer to your connected device to avoid interference.

7. SPECIFICATIONS

Feature	Specification
Model Name	YOBYBO NOTE20
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.0
Form Factor	In-Ear
Control Method	Touch
Water Resistance Level	Waterproof
Special Features	Ergonomic, Fast Charging, Sweatproof
Earbud Weight	4.5 g (approx.)
Total Weight (with case)	35.6 g
Charging Case Dimensions (LxWxH)	6.08 x 5.57 x 1.35 cm
Battery Type	Lithium Ion (3 batteries included)
Earbud Playback Time	4-5 hours
Total Playback Time (with case)	25-30 hours
Charging Port	USB Type-C
Manufacturer	MiraArc

8. WARRANTY AND SUPPORT

YOBYBO products are designed for durability and performance. In case of any manufacturing defects or issues, please refer to your purchase documentation for warranty details.

For support regarding replacement issues or any other inquiries, please contact the retailer or YOBYBO customer service through their official website or the contact information provided at the point of purchase. Please have your product model number (NOTE20) and proof of purchase ready when contacting support.