

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Troy-Bilt](#) /

› [Troy-Bilt TB4218 Gas Chainsaw User Manual](#)

## Troy-Bilt TB4218

# Troy-Bilt TB4218 Gas Chainsaw User Manual

Model: TB4218 (41AY4218766)

## 1. IMPORTANT SAFETY INFORMATION

---

Operating a chainsaw can be dangerous. Read and understand all safety warnings and instructions before using this product. Failure to follow these instructions may result in serious injury or death.

### Personal Protective Equipment (PPE)

- **Head Protection:** Wear a safety helmet.
- **Eye Protection:** Always wear safety glasses or goggles.
- **Ear Protection:** Use earplugs or earmuffs to prevent hearing damage.
- **Hand Protection:** Wear heavy-duty work gloves.
- **Leg Protection:** Wear chainsaw protective chaps or trousers.
- **Foot Protection:** Wear steel-toed safety boots with non-slip soles.

### General Safety Precautions

- Never operate the chainsaw when fatigued, ill, or under the influence of alcohol or drugs.
- Keep children, bystanders, and animals at least 50 feet (15 meters) away from the work area.
- Inspect the chainsaw before each use for loose parts, damage, or fuel leaks.
- Ensure the chain brake is functional.
- Always hold the chainsaw firmly with both hands.
- Be aware of kickback and how to avoid it.
- Do not operate the chainsaw in a tree unless specifically trained to do so.
- Fuel the chainsaw in a well-ventilated area, away from ignition sources.

## 2. PRODUCT OVERVIEW

---

The Troy-Bilt TB4218 is a gas-powered chainsaw designed for cutting wood. It features a 42cc, full crank, 2-cycle engine and an 18-inch low-kickback bar and chain.



*Figure 2.1: Front-side view of the Troy-Bilt TB4218 Gas Chainsaw. This image shows the overall design, including the engine housing, handle, and the 18-inch bar and chain.*

### **Key Features:**

- **Engine:** 42cc, full crank 2-cycle engine.
- **Starting System:** SpringAssist® technology for easier pull starts.
- **Bar and Chain:** 18-inch low-kickback bar and chain.
- **Lubrication:** Adjustable, automatic bar and chain oiler for proper lubrication.
- **Safety Brake:** Automatic, inertia-activated chain brake.
- **Comfort:** 3-point anti-vibration handles and lightweight design.



Figure 2.2: Side view of the Troy-Bilt TB4218 Gas Chainsaw, highlighting the model number TB4218 and engine displacement 42cc on the engine cover.

## 3. SETUP

---

### 3.1 Fueling the Chainsaw

The TB4218 uses a 2-cycle engine and requires a specific fuel mixture. Use fresh unleaded gasoline mixed with the provided 2-cycle engine oil at the ratio specified in the engine manual (typically 50:1 or 40:1). Always mix fuel in a separate, approved fuel container.

1. Ensure the engine is off and cool.
2. Clean the area around the fuel cap to prevent dirt from entering the fuel tank.
3. Carefully remove the fuel cap.
4. Pour the pre-mixed fuel into the fuel tank, filling it to approximately 80% capacity. Do not overfill.
5. Securely replace the fuel cap.

### 3.2 Filling the Chain Oil Reservoir

The chainsaw features an adjustable, automatic bar and chain oiler. It is crucial to keep the oil reservoir filled with appropriate bar and chain oil to ensure proper lubrication and extend the life of the bar and chain.

1. Ensure the engine is off and cool.
2. Clean the area around the oil cap.
3. Carefully remove the oil cap.
4. Fill the oil reservoir with quality bar and chain oil.
5. Securely replace the oil cap.

### 3.3 Adjusting Chain Tension

Correct chain tension is vital for safe and efficient operation. A new chain will stretch during the first few minutes of use and will require re-tensioning.



Figure 3.1: Close-up of the chainsaw bar, showing a label indicating to "Adjust new chain after 15 minutes of use."

1. Ensure the engine is off and the chain brake is engaged.
2. Loosen the bar nuts slightly.
3. Adjust the tensioning screw until the chain fits snugly against the guide bar, but can still be pulled around by hand without binding.
4. Tighten the bar nuts securely.
5. *Important:* Recheck chain tension after the first 15 minutes of operation with a new chain, and periodically thereafter.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Starting the Chainsaw

The TB4218 features SpringAssist® technology for easier pull starts.

1. Place the chainsaw on a firm, flat surface.
2. Engage the chain brake.
3. Set the choke to the FULL CHOKE position.
4. Press the primer bulb several times until fuel is visible.
5. Pull the starter rope firmly and smoothly until the engine attempts to start (usually a few pulls).
6. Once the engine "pops" or attempts to start, move the choke to the HALF CHOKE position.
7. Pull the starter rope again until the engine starts.
8. Once the engine runs, disengage the chain brake and allow it to warm up for a few seconds before use.

### 4.2 Cutting Techniques

Always maintain a stable stance and firm grip with both hands. Plan your cuts to avoid kickback and ensure the tree or limb falls safely.

- **Felling:** For felling trees, always make a notch cut first, followed by a felling cut from the opposite side.
- **Limbing:** Remove smaller branches first, working from the bottom up. Be aware of spring-loaded branches.
- **Bucking:** Cut logs into shorter sections. Support the log to prevent pinching the bar.



Figure 4.1: An individual demonstrating proper two-hand grip and stance while operating the Troy-Bilt TB4218 chainsaw to cut logs. Note the use of safety glasses and protective clothing.

### 4.3 Stopping the Chainsaw

To stop the engine, simply move the ON/OFF switch to the OFF position. Engage the chain brake immediately after stopping the engine.

## 5. MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the life of your chainsaw. Always disconnect the spark plug wire before performing any maintenance.

### 5.1 Chain Sharpening

A sharp chain is essential for safe and efficient cutting. Sharpen the chain regularly or replace it when dull or damaged. Refer to the chain manufacturer's specifications for correct file size and sharpening angles.

### 5.2 Air Filter Cleaning

Clean the air filter frequently, especially when working in dusty conditions. A clogged air filter can reduce engine performance and increase fuel consumption.

1. Remove the air filter cover.
2. Remove the air filter and clean it with warm, soapy water.
3. Rinse thoroughly and allow to air dry completely before reinstallation.

### 5.3 Spark Plug Inspection

Inspect the spark plug periodically. Clean or replace it if it is fouled, worn, or damaged. Ensure the correct spark plug gap is maintained.

### 5.4 Bar and Sprocket Maintenance

Keep the guide bar groove clean and free of debris. Flip the guide bar periodically to ensure even wear. Inspect the drive sprocket for wear and replace if necessary.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Engine does not start	No fuel, incorrect choke setting, fouled spark plug, clogged fuel filter.	Check fuel level, adjust choke, clean/replace spark plug, clean/replace fuel filter.
Engine runs poorly	Dirty air filter, incorrect fuel mixture, dull chain.	Clean air filter, use correct fuel mixture, sharpen/replace chain.
Chain does not move	Chain brake engaged, chain too tight, clutch issue.	Disengage chain brake, adjust chain tension, consult service center.
Excessive vibration	Loose components, damaged chain, worn anti-vibration mounts.	Check for loose parts, replace damaged chain, consult service center.

## 7. SPECIFICATIONS

---

Feature	Detail
---------	--------

Feature	Detail
Model Number	TB4218 (41AY4218766)
Engine Displacement	42cc
Engine Type	2-cycle, Full Crank
Bar Length	18 inches
Starting System	SpringAssist®
Chain Brake	Automatic, Inertia-Activated
Oiling System	Adjustable, Automatic Bar and Chain Oiler
Anti-Vibration System	3-point anti-vibration handles
Item Weight	15.46 pounds (6.99 kg)
Product Dimensions	11.4"L x 10.5"W x 32.4"H (28.96cm L x 26.67cm W x 82.30cm H)

## 8. WARRANTY AND SUPPORT

---

### 8.1 Limited Warranty

This Troy-Bilt TB4218 Gas Chainsaw comes with a **2-year limited warranty**. Please refer to the warranty card included with your product for full terms and conditions. The warranty covers defects in materials and workmanship under normal use.

### 8.2 Customer Support

For technical assistance, replacement parts, or warranty claims, please contact Troy-Bilt customer support. Visit the official Troy-Bilt website for contact information and service center locations.

*Note:* Always have your model number (TB4218 or 41AY4218766) and serial number ready when contacting support.