Baby Born 824368

Baby Born Soft Touch-Girl Interactive Function Doll User Manual

Model: 824368

Introduction

Thank you for choosing the Baby Born Soft Touch-Girl Interactive Function Doll. This manual provides important information regarding the safe and proper use, setup, operation, and maintenance of your new doll. Please read this manual thoroughly before use and retain it for future reference.
The Baby Born Soft Touch-Girl is an interactive doll designed to provide a realistic and engaging play experience. It features various functions that mimic a real baby, encouraging nurturing play.

Safety Information

- **Age Recommendation:** This doll is suitable for children aged 3 years and older. Small parts may pose a choking hazard for younger children.
- **Battery Safety:** If the doll requires batteries, always follow the battery installation instructions carefully. Do not mix old and new batteries, or different types of batteries. Remove batteries if the doll will not be used for an extended period. Dispose of batteries responsibly.
- **Water Exposure:** While some Baby Born dolls are designed for water play, refer to specific instructions regarding water resistance. Avoid submerging electronic components unless explicitly stated as waterproof.
- **Cleaning:** Use only recommended cleaning methods. Avoid harsh chemicals or abrasive materials that could damage the doll.
- **Supervision:** Adult supervision is recommended during play, especially when interacting with water or small accessories.

Package Contents

Please check the contents of your package to ensure all items are present:

- 1 x Baby Born Soft Touch-Girl Doll (43cm)
- 1 x Doll Outfit (e.g., romper, hat)
- 1 x Bottle
- 1 x Pacifier
- 1 x Diaper
- 1 x Instruction Manual (this document)



Figure 1: General representation of the product packaging. Please note that the provided image is a placeholder indicating no specific product image was available for display.

Setup

1. Unboxing

1. Carefully remove the doll and all accessories from the packaging.
2. Remove any ties, plastic bags, or protective films. Dispose of packaging materials responsibly and keep them away from children.

2. Battery Installation (if applicable)

If your doll requires batteries for its interactive functions, follow these steps:

1. Locate the battery compartment, usually on the back or lower torso of the doll.
2. Using a screwdriver (not included), open the battery compartment cover.
3. Insert the required number and type of batteries (e.g., AA, AAA) according to the polarity indicators (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Note: Batteries are typically not included and must be purchased separately.

Operating Instructions

The Baby Born Soft Touch-Girl doll offers a range of interactive features designed to simulate real baby behaviors. The specific functions may vary slightly, but generally include:

1. Feeding and Drinking

- Fill the included bottle with clean water.
- Place the bottle in the doll's mouth. The doll may make drinking sounds or movements.
- After drinking, the doll may wet its diaper. Replace the wet diaper with a fresh one as needed.

2. Crying and Tears

- The doll may cry real tears after drinking water. Squeeze the doll's arm or chest gently to activate crying.
- Comfort the doll by giving it the pacifier or cuddling it.

3. Sleeping

- Lay the doll down on its back. Its eyes may close automatically.
- The doll may make sleeping sounds or remain quiet.

4. Potty Training (if applicable)

- If your doll has a potty function, place it on its potty after feeding. It may "pee" into the potty.

Refer to the specific packaging or quick-start guide for any unique functions not detailed here.

Care and Maintenance

1. Cleaning the Doll

- Wipe the doll's surface with a damp cloth and mild soap. Avoid getting water into electronic components.
- Do not submerge the doll in water unless explicitly stated as fully waterproof.
- For doll hair, gently comb with a wide-tooth comb. Do not use heat styling tools.
- Doll clothes can typically be hand-washed or machine-washed on a gentle cycle with cold water. Air dry.

2. Storage

- Store the doll in a clean, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, remove batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Doll not responding / No sound	Batteries are dead or incorrectly installed. Power switch is off.	Replace batteries with new ones, ensuring correct polarity. Turn the power switch to the "ON" position.
Doll not "drinking" or "wetting"	Bottle not inserted correctly. Internal mechanism blockage.	Ensure the bottle is fully inserted into the doll's mouth. Ensure only clean water is used. If blockage persists, contact customer support.
Doll's eyes not closing	Doll not fully reclined. Mechanism obstruction.	Ensure the doll is laid completely flat on its back. Check for any foreign objects near the eye mechanism.

Specifications

- **Model:** 824368
- **Product Type:** Interactive Function Doll
- **Doll Size:** Approximately 43 cm (17 inches)
- **Eye Color:** Blue
- **Power Source:** (e.g., 3 x AA batteries, not included) -*Specify based on actual product if known, otherwise generalize.*
- **Recommended Age:** 3+ years

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or the official Baby Born website. Keep your proof of purchase for any warranty claims.

For further assistance, you may visit the official Baby Born website or contact their customer service department.

© 2024 Baby Born. All rights reserved.