

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Arendo](#) /
- › [Arendo Drink Mixer Instruction Manual - Model 722304592722](#)

## Arendo 722304592722

# Arendo Drink Mixer Instruction Manual

Model: 722304592722

## 1. INTRODUCTION

Thank you for choosing the Arendo Drink Mixer. This appliance is designed for preparing a variety of beverages, including protein shakes, smoothies, milkshakes, and cocktails. Its powerful motor and two-speed settings ensure efficient mixing. Please read this manual carefully before first use to ensure safe and optimal operation.





Image 1.1: The Arendo Drink Mixer, a sleek chrome-designed appliance for beverage preparation.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before use.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer support for assistance.

- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- This appliance is for household use only.
- The appliance is GS certified for safety.

### **3. PRODUCT COMPONENTS**

---

The Arendo Drink Mixer package includes the following items:

- Main Motor Unit (plastic housing with chrome finish)
- Stainless Steel Mixing Cup (500 ml capacity)
- Double Agitator / Mixer Rod
- Instruction Manual



Image 3.1: The Arendo Drink Mixer shown with its retail packaging.

## 4. SETUP

Before using your Arendo Drink Mixer for the first time, please follow these steps:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the stainless steel mixing cup and the agitator rod with warm soapy water. Rinse thoroughly and dry. The main motor unit should only be wiped with a damp cloth.
3. **Placement:** Place the main motor unit on a stable, flat, and dry surface. Ensure there is enough space around the unit for safe operation. The unit features non-slip feet for stability.

4. **Assembly:** Insert the agitator rod into the designated slot on the underside of the motor head.



Image 4.1: Close-up view of the double agitator rod inserted into the mixer head.

## 5. OPERATING INSTRUCTIONS

The Arendo Drink Mixer is designed for easy and efficient beverage preparation.

1. **Prepare Ingredients:** Add your desired ingredients into the stainless steel mixing cup. The cup has a maximum capacity of 500 ml, but for optimal mixing and to prevent overflow, do not fill beyond 250 ml. The

integrated level indicator on the cup assists with ingredient measurement.

2. **Position Cup:** Place the filled mixing cup onto the base of the mixer and secure it into the clip-in fixture. Ensure the agitator rod is properly submerged in the ingredients.
3. **Select Speed:** Plug the mixer into a 230V AC outlet. Use the power switch located on the side of the motor unit to select one of the two available speeds. Speed 1 (63 dBA) is suitable for lighter mixing, while Speed 2 (69 dBA) provides up to 22,000 revolutions per minute for more vigorous blending.
4. **Mix:** Allow the mixer to operate until your desired consistency is achieved.
5. **Finish:** Turn the mixer off using the power switch, then carefully remove the mixing cup. Unplug the appliance from the power outlet.



Image 5.1: Detailed view of the Arendo Drink Mixer showing the power switch, stainless steel cup with level indicator, and the agitator. The image also highlights the 100W motor, 22,000 RPM, two speed levels, and 500ml maximum volume (with a recommendation to fill only halfway for mixing).

### Recipe Example 1: Creamy Protein Shake (2 Servings)

- 200 ml Buttermilk
- 100 g Skyr Yogurt

- 50 g Quark
- 1 tsp Coconut Flakes
- 60 ml Coconut Milk
- 1/2 Crushed Banana
- Stevia to taste

**arendo®**

# REZEPT NR.1

**CREMIGER EIWEIßSHAKE  
MIT KOKOS (2 Portionen)**

- 200 ml Buttermilch
- 100 g Skyr Joghurt
- 50 g Quark
- 1 TL Kokosmus
- 60 ml Kokosmilch
- 1/2 zerdrückte Banane
- Stevia nach Bedarf



Image 5.2: The Arendo Drink Mixer in use, preparing a creamy protein shake. The image also displays the ingredients for a coconut protein shake.

## Recipe Example 2: Tomato Drink (1 Serving)

- 100 ml Tomato Juice
- 1 pinch Salt
- 1 dash Tabasco
- 150 ml Water
- 1 tsp Liquid Honey

- 1-2 tbsp Lime Juice
- Ice Cubes



arendo

## REZEPT NR. 2

### TOMATEN-DRINK (1 Portion)

- 100ml Tomatensaft
- 1 Prise Salz
- 1 Spr Tabasco
- 150 ml Wasser
- 1 Tl flüssiger Honig
- 1 El Limettensaft (1-2)
- Eiswürfel

Image 5.3: The Arendo Drink Mixer preparing a tomato-based beverage. The image also lists the ingredients for a refreshing tomato drink.

## 6. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygienic operation of your Arendo Drink Mixer.

- **Unplug:** Always unplug the mixer from the power outlet before cleaning.
- **Mixing Cup and Agitator:** The stainless steel mixing cup and the agitator rod are dishwasher safe. Alternatively, they can be washed by hand with warm soapy water, rinsed thoroughly, and dried.
- **Motor Unit:** Wipe the exterior of the motor unit with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the motor unit in water or any other liquid.
- **Storage:** Store the clean and dry mixer in a cool, dry place.

## 7. TROUBLESHOOTING

If you encounter issues with your Arendo Drink Mixer, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Mixer does not turn on.	Not plugged in; power outlet not working; power switch off.	Ensure the mixer is securely plugged into a working outlet. Check the power switch position.
Ingredients are not mixing properly.	Mixing cup overfilled; ingredients too thick; agitator not properly inserted.	Do not fill the cup beyond 250 ml. Add more liquid to thin ingredients. Ensure the agitator is correctly in place. Select a higher speed setting.
Mixer makes unusual noise.	Foreign object in cup; agitator obstructed.	Turn off and unplug the mixer. Remove the cup and check for any obstructions around the agitator.
Appliance stops during operation.	Overheating (automatic shut-off activated).	Unplug the mixer and allow it to cool down for at least 30 minutes before attempting to use it again. Reduce mixing time for future use.

## 8. TECHNICAL SPECIFICATIONS

- **Brand:** Arendo
- **Model Number:** 722304592722
- **Color:** Silver
- **Dimensions (L x W x H):** 17 cm x 12 cm x 38 cm
- **Weight:** 916 g
- **Capacity:** 500 Milliliters (max fill for mixing: 250 ml)
- **Power:** 100 Watts
- **Voltage:** 230 Volts
- **Material:** Stainless Steel (cup), Plastic (housing)
- **Number of Speeds:** 2
- **Rotation Speed:** Up to 22,000 rpm
- **Noise Level (Speed 1):** 63 dBA
- **Noise Level (Speed 2):** 69 dBA
- **Special Features:** Multiple speeds, Automatic shut-off function, Non-slip feet



Image 8.1: Diagram illustrating the dimensions of the Arendo Drink Mixer: 35.5 cm height, 12.5 cm width (base), and 17 cm depth (base).

## 9. WARRANTY INFORMATION

Specific warranty details for the Arendo Drink Mixer are not provided in the product information. Please refer to your purchase documentation or contact the retailer for warranty terms and conditions.

## 10. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Arendo Drink Mixer, please contact your retailer or visit the official Arendo website for contact information.

© 2023 Arendo. All rights reserved.