

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OGORI](#) /

› [OGORI Cordless Electric Mop Instruction Manual](#)

## OGORI B07

# OGORI Cordless Electric Mop Instruction Manual

Model: B07

## 1. PRODUCT OVERVIEW

The OGORI Cordless Electric Mop is designed to make floor cleaning effortless and efficient. Featuring a powerful dual motor, built-in water tank with auto-spray, and LED headlights, it's suitable for various hard floor surfaces including hardwood, tile, vinyl, and laminate.



Figure 1: OGORI Cordless Electric Mop with included cleaning and waxing pads.

## 2. PACKAGE CONTENTS

Please ensure all items are present in the package:

- Electric Mop Main Unit
- Adjustable Handle
- Detachable Lithium-Ion Battery
- Power Adapter
- 2 x Cleaning Pads (Pink)
- 2 x Waxing Pads (Blue)
- Measuring Cup/Funnel
- User Manual



Figure 2: Contents included in the OGORI Electric Mop package.

### 3. SETUP GUIDE

#### 3.1. Assembly

1. **Insert Battery:** Insert the detachable lithium-ion battery into the designated slot on the main unit.

Ensure it clicks into place securely.

2. **Connect Handle:** Align the handle with the main unit's connection point and push firmly until it locks.
3. **Attach Mop Pads:** Secure the desired cleaning or waxing pads to the bottom of the mop head using the hook-and-loop fasteners.

### 3.2. Charging the Battery

Before first use, fully charge the battery. Connect the power adapter to the battery and plug it into a power outlet. The indicator lights on the mop will show charging status. A full charge typically takes 2.5-3 hours.




Figure 3: Detachable battery and charging details. The battery provides 50-60 minutes for dry mopping and 30-40 minutes for wet mopping.

### 3.3. Filling the Water Tank

Open the water tank cap located on the mop head. Use the provided measuring cup/funnel to fill the 300ml water tank with clean water or a suitable floor cleaning solution. Close the cap securely.

# ON-DEMAND SPRAY

Spray trigger allows you to control how much formula you want during cleaning.



300ml Water Tank



Easy to Fill

Figure 4: On-demand spray feature and water tank filling.

## 4. OPERATING INSTRUCTIONS

### 4.1. Power On/Off

Press the power button located on the handle to turn the mop ON. Press it again to turn OFF.

### 4.2. Water Spray Function

Press the spray trigger located on the underside of the handle to dispense water or cleaning solution onto the floor. Release the trigger to stop spraying.

### 4.3. Adjustable Handle & Swivel Steering

The handle length can be adjusted for comfortable use. The mop features 180-degree swivel steering and 90-degree vertical rotation, allowing it to easily reach under furniture and into tight corners.

## LED HEAD LIGHTS, CORDLESS FOR EVERY CORNERS

Cordless design with LED head light let you clean every corners around funitres easily. Stain can't hide any more.



No Time-consuming & Laborious



No Knee Pain & Backache



No Space Restricted



No Harmful to Floor

Figure 5: Swivel steering for easy maneuverability.



## SWIVEL STEERING SELF-PROPELLED

180°rotation from side to side helps you clean the dirt easier in the corner or under furniture.



Figure 6: LED headlights illuminate dark corners for thorough cleaning.

### 4.4. Dual Motor & Cleaning Performance

The mop is equipped with a dual motor system, providing a powerful 300 rotations per minute for effective cleaning and polishing. It operates at less than 50dB noise level for a quiet cleaning experience.

# DUAL MOTOR & LESS THAN 50dB NOICE

Powerful clean, optimized noise reducing technology brings you a low noise working experience.



Figure 7: Dual motor for powerful and quiet cleaning.

## 4.5. Applicable Floor Types

The OGORI Electric Mop is suitable for various sealed hard floor surfaces, including:

- Hardwood Floors
- Tile Floors
- Vinyl Floors
- Laminate Floors
- Marble Floors



Figure 8: The mop effectively cleans various stains on multiple floor types.

## 5. MAINTENANCE

### 5.1. Cleaning Mop Pads

The mop pads are reusable and can be cleaned by hand or machine washed. For best results, clean pads immediately after use.

### 5.2. Battery Care

The detachable battery has a service life of 2-3 years under normal use. If a replacement is needed, a new battery can be purchased.

## 6. TROUBLESHOOTING

## 6.1. Machine Does Not Start

- Ensure the battery is fully charged and correctly inserted.
- Verify the power button on the handle is pressed firmly.
- If the issue persists, please contact customer service.

## 6.2. Water Spray Not Working

- Ensure the water tank is filled.
- Use only clean water or recommended cleaning solutions to prevent nozzle clogging.
- If the nozzle is blocked, try flushing it with clean water.

## 6.3. Mop Stops Suddenly

The mop is designed with a protection mechanism that may suspend operation on uneven ground to prevent excessive friction. If this occurs, shut down the mop for about 10 minutes and then restart it.

## 6.4. Important Note: Not a Vacuum Cleaner

This product is an electric mop for wet and dry cleaning/polishing. It **cannot** be used as a vacuum cleaner to pick up solid debris.

## 7. SPECIFICATIONS

Feature	Specification
Model Number	B07
Product Dimensions	10.2" L x 7.4" W x 50" H
Item Weight	8.84 pounds
Water Tank Volume	300 Milliliters
Battery Type	Lithium Ion (included)
Handle Material	Metal
Head Material	Cotton
Surface Recommendation	Floor, Tile

## 8. OFFICIAL PRODUCT VIDEOS

### 8.1. B07 Electric Spin Mop with LED Headlight and Water Spray

Your browser does not support the video tag.

This video demonstrates the general operation of the OGORI B07 Electric Spin Mop, including its LED headlight and

water spray function. It showcases the mop's ease of use and effectiveness on various floor types.

## 8.2. Details for Using the OGORI Mop, Charging, Water Spray, Etc

Your browser does not support the video tag.



This video provides detailed instructions on using the OGORI Mop, including how to charge the battery, operate the water spray, and troubleshoot common issues. It offers practical tips for optimal performance.

## 9. WARRANTY & SUPPORT

The detachable battery is covered by a 1-year replacement warranty. For any problems, questions, or support needs, please contact us via email:

**Email: [ogori\\_service@hotmail.com](mailto:ogori_service@hotmail.com)**

## Related Documents - B07

 <b>OGORI</b> MULTI-FUNCTION CORDLESS ELECTRIC SPIN MOP <b>B07</b>	<p><a href="#"><u>OGORI B07 Multi-Function Cordless Electric Spin Mop - User Manual and Guide</u></a></p> <p>Comprehensive guide for the OGORI B07 Multi-Function Cordless Electric Spin Mop, covering product description, installation, operation, troubleshooting, specifications, warnings, and warranty details.</p>
	<p><a href="#"><u>B07 Smart Watch User Manual and Features</u></a></p> <p>Comprehensive guide to the B07 Smart Watch, covering setup, features like health monitoring (heart rate, blood oxygen, sleep, etc.), sports tracking, notifications, and troubleshooting.</p>
	<p><a href="#"><u>B07 Smart Lock Installation Guide and User Manual</u></a></p> <p>Detailed installation guide and user manual for the B07 smart lock by Shenzhen Rongfu Tiancheng Industrial Co., Ltd., covering physical setup, app integration, features, and troubleshooting.</p>
	<p><a href="#"><u>Manuel de l'utilisateur du chargeur EV VEVOR Modèles EV-B07-EU011B/EV-B07-EU022B</u></a></p> <p>Découvrez le manuel de l'utilisateur pour le chargeur EV VEVOR, modèles EV-B07-EU011B et EV-B07-EU022B. Ce guide couvre l'installation, l'utilisation, les spécifications et le dépannage de votre chargeur portable.</p>