

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Legami](#) /

› [Legami Be Free Wireless Earbuds Kitty Model EAR0002 Instruction Manual](#)

Legami EAR0002

Legami Be Free Wireless Earbuds

Model: EAR0002 - Kitty Edition

INTRODUCTION

Thank you for choosing the Legami Be Free Wireless Earbuds. These Kitty-themed earbuds provide a seamless audio experience with wireless convenience, perfect for music and calls. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

PACKAGE CONTENTS

Ensure all items are present in the box:

- Legami Be Free Wireless Earbuds (Left and Right)
- Kitty-themed Charging Case
- USB Type-C Charging Cable
- Instruction Manual (this document)



Image: The Legami Be Free Wireless Earbuds, their Kitty-themed charging case, and the included USB Type-C charging cable.

PRODUCT OVERVIEW

The Legami Be Free Wireless Earbuds are designed for ease of use and portability. Key features include:

- **Touch Sensor:** For intuitive control of music and calls.
- **Up to 5 Hours Playback:** Enjoy extended listening on a single charge.
- **Integrated Dual Microphone:** Ensures clear voice quality during calls.
- **Automatic Connection:** Quick and effortless pairing with your devices.
- **High-Quality Audio and Voice:** For an immersive sound experience.
- **Lightweight and Practical Design:** Comfortable for prolonged use and easy to carry.
- **Waterproof Rating:** Provides protection against splashes and sweat.



Image: A top-down view of the Legami Be Free Wireless Earbuds securely placed within their Kitty-themed charging case.

SETUP

1. Charging the Earbuds and Case

1. Connect the provided USB Type-C charging cable to the charging port on the Kitty-themed case.
2. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, wall adapter).
3. The indicator light on the case will show the charging status. Ensure the earbuds are placed inside the case to charge them simultaneously.
4. Allow approximately 1-2 hours for a full charge of both the case and earbuds.




Image: The Legami Be Free Wireless Earbuds removed from their charging case, with the open case and USB Type-C cable ready for connection.

2. Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your smartphone, tablet, or computer, go to the Bluetooth settings.
4. Search for available devices and select "Legami Be Free" (or similar name) from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
6. The earbuds support automatic connection, meaning they will reconnect to the last paired device when removed from the case.

OPERATING INSTRUCTIONS

Touch Controls

The Legami Be Free Earbuds feature intuitive touch controls on each earbud:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud (e.g., Siri, Google Assistant).

Wearing the Earbuds

Gently insert each earbud into your ear canal. Adjust for a comfortable and secure fit to ensure optimal sound quality and prevent them from falling out during activity.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Do not use abrasive cleaners or immerse in water.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not used for extended periods.
- **Water Resistance:** While water-resistant, avoid prolonged exposure to water or submersion. Dry thoroughly if exposed to moisture before placing back in the charging case.

TROUBLESHOOTING

Problem	Solution
Earbuds not pairing.	<ul style="list-style-type: none"> ◦ Ensure earbuds are charged. ◦ Turn off Bluetooth on your device and turn it back on. ◦ Forget the device in your Bluetooth settings and try pairing again. ◦ Place earbuds back in the case, close it, wait a few seconds, then open it again to reset pairing mode.
Only one earbud is working.	<ul style="list-style-type: none"> ◦ Ensure both earbuds are charged. ◦ Place both earbuds back into the charging case, close the lid, and then open it again. ◦ Try resetting the earbuds by forgetting them in your device's Bluetooth settings and re-pairing.
Earbuds not charging.	<ul style="list-style-type: none"> ◦ Check if the charging cable is securely connected to both the case and the power source. ◦ Ensure the charging contacts on the earbuds and inside the case are clean and free of debris. ◦ Try a different USB port or power adapter.
Poor sound quality.	<ul style="list-style-type: none"> ◦ Ensure the earbuds are properly seated in your ears. ◦ Clean any earwax or debris from the earbud nozzles. ◦ Move closer to your connected device to avoid interference.

SPECIFICATIONS

- **Model Number:** EAR0002
- **Brand:** Legami
- **Color:** Kitty
- **Connectivity:** Wireless Bluetooth
- **Playback Time:** Up to 5 hours
- **Control Type:** Touch Control

- **Microphone:** Integrated Dual Microphone
- **Compatible Devices:** Bluetooth-enabled devices (desktops, phones, laptops, tablets)
- **Material:** Acrylonitrile Butadiene Styrene (ABS), Silicone
- **Item Weight:** 130 Grams
- **Water Resistance:** Waterproof
- **Ear Placement:** In-ear
- **Charging Port:** USB Type-C

WARRANTY AND SUPPORT

Specific warranty information for the Legami Be Free Wireless Earbuds (Model EAR0002) is not provided in the product details. For warranty claims or technical support, please refer to the retailer where the product was purchased or visit the official Legami website for customer service contact information.

Information regarding spare parts availability and guaranteed software updates is not available.