

CHICLEW B08PV92K96

CHICLEW Portable Electric Scooter Bag (2L) User Manual

Model: B08PV92K96

1. INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your CHICLEW Portable Electric Scooter Bag (2L). Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.

2. PRODUCT FEATURES

- **Quick Release Design:** Allows for convenient attachment and removal from scooter handlebars.
- **Wide Compatibility:** Designed with adjustable ties and non-slip silicone pads for stability on various electric folding bikes and vehicles.
- **2L Large Capacity:** Provides ample space for essentials such as phones, wallets, keys, earphones, and small tools.
- **Waterproof PU Material:** Constructed from waterproof PU material with sealed double zipper closure to protect contents from rain.
- **EVA Hard Shell:** Features a rigid EVA hard-shell construction for shape retention, internal structure integrity, and shock absorption to protect items.




Image: The bag's durable hard shell, secure bi-directional zippers, and reflective stripe for enhanced visibility.



Image: Waterproof capabilities of the bag, showing water beading off its PU material and sealed zippers.



Image: The bag's universal design allows it to be mounted on different types of electric scooters and bicycles.

3. PACKAGE CONTENTS

The package includes:

- 1 x CHICLEW Electric Scooter Bag
- 1 x Mounting Bracket
- 1 x Screwdriver
- 2 x Fastener Rings (for securing the bracket)
- Spare Screws
- Buffer Gaskets (for handlebar protection)



Image: All parts required for installation, including the bag, mounting bracket, screwdriver, and fasteners.

4. SETUP AND INSTALLATION

1. **Prepare the Bracket:** Place the buffer gaskets between the mounting bracket and your scooter's handlebar stem to protect the surface.
2. **Attach Fastener Rings:** Secure the mounting bracket to the handlebar stem using the two fastener rings. Ensure they are positioned correctly for stability.
3. **Tighten Screws:** Use the provided screwdriver to tighten the screws on the fastener rings. Ensure the bracket is firmly attached and does not move. Do not overtighten to avoid damage.
4. **Mount the Bag:** Align the back of the scooter bag with the installed bracket. Slide the bag downwards onto the bracket until you hear a distinct "CLICK," indicating it is securely locked in place.
5. **Remove the Bag (Quick Release):** To remove the bag, press the quick-release button on the bracket and slide the bag upwards.



Image: Visual guide demonstrating the quick and easy 1-step installation and removal process.

Your browser does not support the video tag.

Video: This video demonstrates the installation process of the CHICLEW Electric Scooter Bag on a scooter, showing how to attach the mounting bracket and secure the bag.

5. OPERATING INSTRUCTIONS

To open the bag, use the dual zippers. The bag features internal mesh pockets for organizing smaller items like keys, earphones, or a power bank. The main compartment is suitable for larger items such as a phone, wallet, or small water bottle. Close the zippers completely to ensure the waterproof seal is maintained.



2L Large Capacity

Image: The 2L capacity of the bag, demonstrating how various personal items can be stored inside.



CLASSIFIED STORAGE

Image: The internal layout of the bag, featuring mesh pockets for organized storage of small items.

6. MAINTENANCE

To clean the bag, wipe the exterior with a damp cloth. Avoid using harsh chemicals or abrasive cleaners. Ensure the zippers are free of debris to maintain smooth operation and waterproof integrity. Store the bag in a cool, dry place when not in use.

7. TROUBLESHOOTING

- **Bag feels loose or falls off:** Ensure the fastener rings are tightened securely to the handlebar stem. Verify that the bag is fully clicked into the mounting bracket. The buffer gaskets should be correctly positioned to provide a snug fit and prevent slippage.

8. SPECIFICATIONS

Model:	B08PV92K96
Capacity:	2 Liters
Material:	Waterproof PU, EVA Hard Shell
Color:	Black
Compatibility:	Electric scooters, folding bicycles, and similar vehicles with suitable handlebar stems.
Mounting:	Quick Release Bracket with Adjustable Fastener Rings

9. WARRANTY AND SUPPORT

CHICLEW is committed to product quality. For any issues or support, please contact the seller or refer to the CHICLEW brand store for assistance. The product is typically backed by a 1-year quality guarantee and lifetime product & technical support.

For more information, visit the [CHICLEW Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question