

Vigdur 4205021

Vigdur Rattan Ball String Lights Instruction Manual

Brand: Vigdur | Model: 4205021

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Indoor and Outdoor Use:** This product is suitable for both indoor and outdoor applications. Ensure all connections are secure and protected from direct water exposure when used outdoors.
- **Electrical Safety:** Always plug the string lights into a grounded outlet. Do not overload electrical outlets.
- **Connection Limit:** Do not connect more than 10 strings end-to-end. Exceeding this limit may cause overheating and fire hazard.
- **Handling:** Do not hang objects from the string lights. Do not secure the wiring with staples or nails.
- **Bulb and Fuse Replacement:** Always unplug the lights before attempting to replace bulbs or fuses. Use only the specified replacement parts.
- **Damage Inspection:** Regularly inspect the string lights for any damage to the cord, bulbs, or rattan balls. Discontinue use if any damage is found.

2. PACKAGE CONTENTS

Verify that all components are present in your package:

- 1 x Vigdur Rattan Ball String Light (9.84 feet long)
- 10 x LED Bulbs (pre-installed within rattan balls)
- 10 x Rattan Ball Lampshades (pre-installed)
- 6 x Cable Ties (for installation)
- Spare Fuses and Bulbs (for replacement)

3. SETUP INSTRUCTIONS

3.1 Unpacking and Inspection

Carefully remove the string lights from the packaging. Untangle the string and inspect all components for any signs of damage. Ensure all rattan balls are securely attached to the light string.



Image 1: Overview of Vigdur Rattan Ball String Lights, showing the 9.84 ft length and individual ball dimensions of 2.75 inches.

3.2 Placement

Choose a suitable location for your string lights. These lights are designed for both indoor and outdoor use, such as bedrooms, patios, gardens, or for event decoration. Plan the layout to ensure the power cord reaches an outlet without tension.

3.3 Connecting Multiple Strings (Optional)

If you wish to extend the length, these lights feature an end-to-end connectable design. Locate the male plug at one end and the female receptacle at the other. Connect up to a maximum of 10 strings. Ensure connections are tight to prevent moisture ingress, especially for outdoor use.



End to end connectable



2replaceable LED bulbs



Spare fuse in male plug

HIGH QUALITY MATERIAL HOLLOW-CARVED DESIGN

Image 2: Detailed view of the string lights, highlighting the end-to-end connectable feature, replaceable LED bulbs, and the spare fuse located in the male plug.

3.4 Securing the Lights

Use the provided cable ties or other appropriate fasteners to secure the string lights in your desired position. Avoid pulling or twisting the wires excessively.




Image 3: Close-up of the rattan balls and wiring, illustrating the 9.84-inch spacing between each light and the 2.75-inch diameter of the rattan balls.

4. OPERATING INSTRUCTIONS

To operate the Vigdur Rattan Ball String Lights:

1. Ensure the lights are properly installed and secured.
2. Plug the power cord into a standard electrical outlet. The lights will illuminate.
3. To turn off the lights, simply unplug the power cord from the outlet.

Your browser does not support the video tag.

Video 1: Official product video from Vigdur demonstrating the aesthetic appeal and warm light of the rattan ball string lights in various settings.

5. MAINTENANCE

5.1 Cleaning

To clean the string lights, first unplug them from the power source. Gently wipe the rattan balls and wires with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

5.2 Bulb Replacement

Although the LED bulbs are long-lasting, if a bulb needs replacement, ensure the lights are unplugged. Carefully remove the rattan ball cover, then gently pull out the faulty LED bulb and insert a new one. Replace the rattan ball cover securely. Use only Vigdur-approved replacement bulbs.

5.3 Fuse Replacement

If the entire string light set fails to illuminate, check the fuse located in the male plug. Unplug the lights, slide open the fuse compartment, and replace the blown fuse with a new one of the same rating (spare fuses are included). Close the compartment securely.

6. TROUBLESHOOTING

- **Lights not turning on:**
 - Ensure the power plug is fully inserted into a working electrical outlet.
 - Check the fuse in the male plug and replace if blown (refer to Section 5.3).
 - Verify that all individual bulbs are securely seated and not damaged.
- **Some bulbs are out:**
 - Identify and replace any faulty bulbs (refer to Section 5.2).
- **Lights are dim:**
 - Ensure the power source is stable and providing adequate voltage.
 - If multiple strings are connected, ensure the total length does not exceed the maximum recommended limit of 10 strings.

7. SPECIFICATIONS

Feature	Specification
Brand	Vigdur
Model Number	4205021
Color	White (Rattan Balls) / Warm White (Light)
Indoor/Outdoor Usage	Indoor, Outdoor
Special Features	Linkable, Shatterproof
Light Source Type	LED
Power Source	Corded Electric
Color Temperature	2700 Kelvin
Number of Light Sources	10
Wattage	3.6 watts
Item Length	9.84 Feet
Material	Plastic (Rattan Balls are made of high-quality iron wire and plastic)
Item Weight	15.8 ounces

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Vigdur

customer service directly. Keep your purchase receipt for warranty claims.