

YCCTEAM YCC-XB9001

YCCTEAM Wired Controller Instruction Manual

Model: YCC-XB9001

1. PRODUCT OVERVIEW

The YCCTEAM Wired Controller is designed for an enhanced gaming experience on Xbox One, Xbox One S/X, and PC Windows 10/11. It features precise controls, dual vibration feedback, and an ergonomic design for comfortable extended play sessions. This controller is a third-party product, not manufactured or endorsed by Microsoft.



Image 1.1: Front view of the YCCTEAM Wired Controller, showcasing its white and black design with colored A, B, X, Y buttons and dual joysticks.

2. SETUP AND CONNECTION

Connecting your YCCTEAM Wired Controller is a simple plug-and-play process. No additional drivers are typically required for most compatible systems.

2.1. Connecting to Your Device

1. Locate an available USB port on your Xbox One console (including S/X models) or your Windows PC (Windows 10/11).
2. Insert the USB connector of the controller's cable firmly into the USB port.
3. The LED indicator lights on the controller will illuminate, indicating a successful connection. Once the lights are solid, the controller is ready for use.



Image 2.1: The YCCTEAM Wired Controller connected via USB to a gaming console setup, illustrating its plug-and-play compatibility.

3. OPERATING THE CONTROLLER

Familiarize yourself with the controller's layout and features for optimal performance.

3.1. Button Layout and Functions



Image 3.1: Diagram illustrating the various buttons and their labels on the YCCTEAM Wired Controller, including joysticks, D-pad, Menu, Home, View, LT/LB, RT/RB, and the Audio-Jack.

- **Dual Analog Joysticks:** Provide 360-degree precision control for movement and camera.
- **D-pad:** Directional pad for precise directional input.
- **A/B/X/Y Buttons:** Standard action buttons, color-coded for easy identification.
- **LT/LB (Left Trigger/Bumper):** Shoulder buttons and triggers for various in-game actions.
- **RT/RB (Right Trigger/Bumper):** Shoulder buttons and triggers for various in-game actions.
- **Menu Button:** Access in-game menus or system options.
- **View Button:** Provides additional in-game options or system functions.
- **Home Button:** Returns to the console dashboard or main menu.

3.2. Dual Vibration Function

The controller features asymmetric dual vibration motors, providing tactile feedback that enhances immersion during gameplay. The intensity of the vibration varies based on in-game events.



Image 3.2: An illustration of the controller highlighting its dual vibration motors and the 3.5mm audio jack, indicating interactive game experience enhancement.

3.3. 3.5mm Audio Jack

A 3.5mm audio jack is integrated into the controller, allowing you to connect compatible headsets for in-game audio. Please note that this controller does not include a microphone function.

3.4. Ergonomics and Design

The controller is designed with an ergonomic shape and anti-sweat, anti-slip grips to provide maximum comfort and reduce fatigue during long gaming sessions. The buttons are crafted using a high-end crystal process for durability and a clear appearance.

ERGONOMICS DESIGN



Image 3.3: An illustration demonstrating the ergonomic design of the controller, showing how it fits comfortably in the hand, along with a 'Press Test' graphic indicating high sensibility and accuracy of buttons.

4. MAINTENANCE AND CARE

Proper care will extend the lifespan of your controller.

- Keep the controller in a dry environment and avoid exposure to extreme temperatures.
- Clean the controller regularly with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Avoid dropping the controller or subjecting it to strong impacts.
- Do not attempt to disassemble the controller, as this will void any potential warranty.

5. TROUBLESHOOTING

If you encounter issues with your YCCTEAM Wired Controller, please refer to the following common solutions:

- **Controller Not Connecting/LEDs Not On:**
 - Ensure the USB cable is fully inserted into both the controller and the device's USB port.
 - Try a different USB port on your console or PC.

- Test the controller on another compatible device to rule out a device-specific issue.
- **Vibration Not Working:**
 - Verify that the game you are playing supports vibration feedback.
 - Check in-game settings to ensure vibration is enabled.
 - Ensure the controller is securely connected.
- **Buttons or Joysticks Unresponsive/Drifting:**
 - Disconnect and reconnect the controller.
 - Ensure no debris is lodged around the buttons or joysticks.
 - For PC, ensure your operating system and game drivers are up to date.
- **Compatibility Issues with Xbox One:**
 - Some users have reported issues with Xbox consoles blocking third-party controllers. While this controller is designed to be compatible, Microsoft's system updates may occasionally affect third-party accessory functionality.
 - If your Xbox One console displays an 'unauthorized product' message, try restarting the console with the controller connected. If the issue persists, the controller may not be fully supported by the current Xbox system software.

6. SPECIFICATIONS

Feature	Detail
Model Number	YCC-XB9001
Compatibility	Xbox One, Xbox One S/X, PC Windows 10/11
Connectivity	Wired USB
Vibration	Asymmetric Dual Vibration
Audio Port	3.5mm Headset Jack (no mic function)
Dimensions	16.9 x 13.5 x 7.6 cm
Weight	330 g

7. WARRANTY AND SUPPORT

Specific warranty details are not provided within this manual. For information regarding warranty coverage, returns, or technical support, please refer to the product packaging or contact YCCTEAM customer service directly through their official channels or the retailer from whom the product was purchased.

You can often find support information on the YCCTEAM brand store page on Amazon or their official website.

