Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Yaheetech /
- > Yaheetech Metal Weave Arm Chair (Model YT-00100626-036) Instruction Manual

Yaheetech YT-00100626-036

Yaheetech Metal Weave Arm Chair (Model YT-00100626-036) Instruction Manual

Your guide to assembly, usage, and maintenance.

1. Introduction

Thank you for choosing the Yaheetech Metal Weave Arm Chair. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new dining chairs. Please read these instructions thoroughly before beginning assembly and retain them for future reference.



Figure 1: Yaheetech Metal Weave Arm Chairs (Set of 2)

These mid-century style dining chairs feature a durable metal frame with a wood-color finish, a distinctive Y-shaped backrest, and a hand-knitted natural paper twine seat. Designed for comfort and stability, they are suitable for various indoor settings.

2. SAFETY INFORMATION

- This product is intended for indoor use only.
- Avoid exposing the chairs directly to moisture or prolonged sunlight.
- Ensure all screws and connections are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacity of 330 pounds (150 kg) per chair.
- Keep small parts away from children during assembly to prevent choking hazards.
- Allow for a measurement error of ±1cm/0.5inch due to manual measurement.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Chair Frame (with integrated armrest and backrest) x 2
- Seat (natural paper twine) x 2
- Assembly Hardware (screws, washers, Allen wrench) x 1 set
- User Manual x 1




Figure 2: Key Components and Features

4. ASSEMBLY INSTRUCTIONS

Assembly is straightforward and typically requires one person. An Allen wrench is included for your convenience.

- 1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
- 2. **Attach the Seat:** Align the pre-drilled holes on the natural paper twine seat with the corresponding holes on the chair frame.
- 3. **Secure the Seat:** Insert the provided screws through the seat and into the chair frame. Hand-tighten all screws initially.
- 4. **Final Tightening:** Once all screws are in place, use the Allen wrench to fully tighten them. Ensure all connections are firm and secure. Do not overtighten.
- 5. **Adjust Foot Pads:** The chairs are equipped with adjustable foot pads. Turn the foot pads clockwise or counter-clockwise to level the chair and prevent wobbling on uneven surfaces.



Figure 3: Adjusting the Foot Pads for Stability

5. Usage Guidelines

- Weight Capacity: Each chair has a maximum weight capacity of 330 pounds (150 kg). Do not exceed this limit.
- **Placement:** These chairs are designed for indoor use. While the product description mentions indoor/outdoor usage, the important information section advises against outdoor use, moisture, or direct sunlight. For optimal longevity, use indoors.
- **Stability:** Always ensure the chair is placed on a flat, stable surface. Adjust the foot pads as needed to prevent wobbling.
- Stackability: The chairs are designed to be stackable, allowing for convenient storage and space-saving when not in use.



STACKABLE FOR SAVING SPACE

Figure 4: Stackable Design for Space Saving

6. MAINTENANCE

- **Cleaning:** Wipe clean with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish and the natural paper twine seat.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability and safety.
- Avoid Moisture: Protect the chairs from excessive moisture and humidity to prevent damage to the metal frame and the natural paper twine seat.

7. TROUBLESHOOTING

- **Wobbling Chair:** If the chair wobbles, ensure it is on a flat surface. Adjust the protective foot pads on each leg until the chair is stable.
- Loose Connections: If the chair feels unstable, check all assembly screws and tighten them firmly with the provided Allen wrench.
- **Difficulty Assembling:** Review the assembly instructions carefully. Ensure all parts are oriented correctly. If issues persist, contact customer support.

8. SPECIFICATIONS

Feature	Detail		
Brand	Yaheetech		
Model Name	Dining chair		
Model Number	YT-00100626-036		
Color	Wood Color		
Product Dimensions (D x W x H)	22.5"D x 21.5"W x 29"H		
Seat Height	17 Inches		
Seat Depth	16 inches		
Item Weight	25.8 pounds (per chair)		
Maximum Weight Recommendation	330 Pounds (150 kg)		
Material	Metal frame, Natural Paper Twine seat		
Style	Mid-Century Modern		
Indoor/Outdoor Usage	Indoor (Recommended)		
Included Components	User Manual		



Figure 5: Product Dimensions and Weight Capacity

9. WARRANTY AND SUPPORT

Yaheetech stands behind the quality of its products. For any questions, concerns, or assistance with your product, please refer to the following information:

- **Return Policy:** This product is eligible for a 30-day refund or replacement policy from the date of purchase. Please refer to the retailer's specific return guidelines for detailed information.
- **Manufacturer Support:** For direct support, you may contact Yaheetech customer service. Contact details are typically available on the Yaheetech official website or through your purchase platform.
- Online Resources: Visit the official Yaheetech store for additional product information and support:
 Yaheetech Store

© 2025 Yaheetech. All rights reserved.

