Monkey Loop 10176051

Monkey Loop Prime 04 Floor Guitar Stand User Manual

Model: 10176051

Introduction

Thank you for choosing the Monkey Loop Prime 04 Floor Guitar Stand. This stand is designed to provide a stable and secure resting place for your guitar or bass, protecting it from accidental falls and scratches. Constructed from ultra-resistant yet lightweight steel, it offers durability and portability. The contact surfaces are equipped with protective rubber to ensure your instrument's finish remains pristine. Its foldable design allows for convenient storage and transport.

Safety Information

- Ensure the stand is placed on a flat, stable, and non-slip surface to prevent tipping.
- Always verify that your instrument is securely seated in the stand before leaving it unattended.
- Utilize the safety closure mechanism on the neck support to prevent the instrument from falling forward.
- Keep the stand away from high-traffic areas where it might be accidentally bumped.
- Do not exceed the recommended weight capacity.

Package Contents

Please check the package to ensure all components are present:

- 1 x Monkey Loop Prime 04 Floor Guitar Stand (main frame, neck support, base arms)
- Instruction Manual (this document)

Note: The stand is designed for minimal assembly.

Setup

1. **Unfolding the Stand**

   Carefully remove the stand from its packaging. The stand is designed to fold for compact storage. Gently unfold the base legs until they are fully extended and locked into position, forming a stable tripod base.



Image: The Monkey Loop Prime 04 guitar stand shown in its folded, compact state, ready for transport or storage.

2. **Adjusting Height**

   Locate the height adjustment knob on the main vertical shaft. Loosen the knob, extend the upper part of the stand to your desired height (between 63 cm and 75 cm), and then securely tighten the knob to lock it in place. Ensure the stand is stable after adjustment.





Image: The Monkey Loop Prime 04 guitar stand fully assembled and extended, showcasing its stable design.

3. **Inspecting Protective Rubber**

   Before first use, inspect all rubberized contact points (on the base arms and neck support) to ensure they are intact and free from damage. These rubber pads protect your instrument's finish.



Image: A close-up view of the neck support of the Monkey Loop Prime 04 stand, highlighting the protective rubber and the brand logo.

Operating Instructions

1. **Placing Your Instrument**

   Gently place the body of your guitar or bass onto the lower support arms of the stand. Ensure the instrument rests evenly on both arms.





Image: An angled view of a guitar securely resting on the Monkey Loop Prime 04 stand, demonstrating proper placement.

2. **Securing the Neck**

   Guide the neck of your instrument into the upper neck support. The stand features a non-slip rubber safety closure. Once the neck is in place, swing the safety strap over the neck to secure it, preventing accidental falls.



Image: A detailed view showing a guitar neck properly seated and secured within the stand's upper neck support.



Image: A close-up of the neck support with its safety strap in the open position, illustrating the mechanism for securing the instrument's neck.

3. **Removing Your Instrument**

   To remove your instrument, first unlatch the safety closure on the neck support, then gently lift the instrument straight up and away from the stand.





Image: A front view of a guitar resting on the Monkey Loop Prime 04 stand, demonstrating the stand's stability when in use.

Maintenance

- **Cleaning:** Wipe the stand with a soft, dry cloth to remove dust and dirt. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Rubber Pads:** Periodically check the condition of the protective rubber pads on the base and neck support. Ensure they are not worn, cracked, or missing, as this could compromise instrument protection.
- **Joints and Fasteners:** Occasionally inspect all joints and fasteners (like the height adjustment knob) to ensure they are tight and secure. Tighten if necessary.
- **Storage:** When not in use for extended periods, fold the stand for compact storage in a dry, cool place to prolong its lifespan.

Troubleshooting

Problem	Possible Cause	Solution
Stand feels unstable or wobbly.	Not fully unfolded; placed on uneven surface; height adjustment knob loose.	Ensure base legs are fully extended and locked. Move to a flat, stable surface. Tighten height adjustment knob securely.
Instrument slips or scratches.	Damaged or missing rubber pads; instrument not properly seated.	Inspect and replace any damaged rubber pads. Ensure instrument body rests fully on both lower arms and neck is secured by the safety closure.
Stand difficult to fold/unfold.	Minor friction in joints; dirt accumulation.	Apply a small amount of silicone lubricant to moving joints if necessary. Clean any visible dirt from the folding mechanisms.

Specifications

Model	Prime 04
Item Model Number	10176051
Brand	Monkey Loop
Material	Alloy Steel
Color	Black
Adjustable Height	63 - 75 cm (24.8 - 29.5 inches)
Product Dimensions (L x W x H)	7.87 x 5.12 x 20.87 inches (folded)
Item Weight	1.3 kg (2.86 pounds)
Compatibility	All types of guitars and bass guitars

Warranty and Support

For warranty information or technical support regarding your Monkey Loop Prime 04 Floor Guitar Stand, please refer to the warranty card included with your purchase or visit the official Monkey Loop website. You may also contact customer

service through the retailer where the product was purchased.
For further assistance, please contact:

Brand: Monkey Loop

Website: www.monkeyloop.com (*Note: This is a placeholder URL as no official website was provided in the input.*)

© 2025 Monkey Loop. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question