

PUR PDI4000Z

PUR XL 44-Cup Water Filter Dispenser

Model: PDI4000Z

Brand: PUR

[Introduction](#)[Safety](#)[Contents](#)[Setup](#)[Operation](#)[Maintenance](#)[Troubleshooting](#)[Specifications](#)[Warranty](#)

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your PUR XL 44-Cup Water Filter Dispenser. Please read this manual thoroughly before initial use and retain it for future reference. The PUR XL 44-Cup Water Filter Dispenser is designed to provide cleaner, better-tasting drinking water by reducing various chemical and physical substances.



Image 1.1: The PUR XL 44-Cup Water Filter Dispenser, showcasing its design and included filters.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.
- This product is intended for household use only.
- Keep out of reach of children.
- Ensure all components are properly assembled before filling with water.
- Do not expose the dispenser to extreme temperatures.
- Handle the dispenser with care to prevent damage to the spout or other components.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x PUR XL 44-Cup Water Filter Dispenser
- 2 x Genuine PUR Dispenser Filters
- 1 x Removable Stand for Filter Storage (optional use)

Transform Your Tap Water



Image 3.1: The dispenser highlighting its 44-cup capacity, filter change light indicator, dishwasher-safe design, and inclusion of two filters.

4. SETUP INSTRUCTIONS

Follow these steps for initial setup:

1. **Unpack Components:** Carefully remove all parts from the packaging. Wash the dispenser and lid with mild soap and water. Rinse thoroughly. The dispenser is dishwasher safe.
2. **Prepare Filters:** Rinse each PUR filter under cold tap water for 15 seconds. This helps to remove any loose carbon dust.
3. **Insert Filters:** Insert the prepared filters into the designated slots in the upper reservoir. Twist each filter to lock it securely in place using the LockFit™ design.
4. **Assemble Dispenser:** Place the upper reservoir onto the lower base. Ensure it sits firmly. If desired, attach the removable stand to the bottom of the dispenser for additional height or filter storage.
5. **Initial Fill:** Fill the upper reservoir with cold tap water. Allow the water to filter through to the lower chamber. Discard the first two full reservoirs of filtered water to prime the filters.

2-in-1 Faster Filtration*



Image 4.1: A detailed view of a PUR filter, emphasizing its ability to reduce chlorine and mercury for improved water quality.

5. OPERATING INSTRUCTIONS

Using your PUR XL 44-Cup Water Filter Dispenser is straightforward:

1. **Filling the Dispenser:** Remove the lid and fill the upper reservoir with cold tap water. The water will slowly filter through the PUR filters into the lower chamber.
2. **Dispensing Water:** Position a glass or container under the pull-down spout. Gently pull down the spout lever to dispense filtered water. Release the lever to stop the flow.
3. **Filter Indicator Light:** The dispenser features a filter indicator light on the spout. This light will signal when it's time to change your filter. Green indicates the filter is working, yellow means to change the filter soon, and red indicates it's time to replace the filter.

CONVENIENCE THAT FITS YOUR LIFESTYLE



Image 5.1: The PUR dispenser integrated into a family's daily routine, showing its convenience for various uses.

NEVER MISS A FILTER CHANGE

With PUR's **filter change light indicator**




Image 5.2: Visual guide to the filter change light indicator: Green (OK), Yellow (Change Soon), Red (End of Life).

Official Product Video: PUR Filter - Water Pitcher

Video 5.3: This video demonstrates the importance of using genuine PUR filters for reducing contaminants in drinking water and maintaining water quality by replacing filters every 2-3 months.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your dispenser.

6.1 Cleaning the Dispenser

- The PUR XL 44-Cup Water Filter Dispenser is dishwasher safe. Separate the lid, upper reservoir, and lower base before placing them in the dishwasher.
- Alternatively, hand wash all components with mild dish soap and warm water. Rinse thoroughly to remove any soap residue.
- Do not use abrasive cleaners or scouring pads, as these can scratch the plastic.

DISHWASHER SAFE



Image 6.1: The dispenser's components, including the lid and reservoirs, being placed in a dishwasher for easy cleaning.

6.2 Filter Replacement

Each Genuine PUR dispenser filter is certified for up to 40 gallons or 2 months of use. Replace filters as indicated by the filter gauge light or after the recommended period.

1. **Remove Old Filter:** Empty any remaining water from the upper reservoir. Twist the old filter counter-clockwise to unlock and remove it.
2. **Prepare New Filter:** Rinse the new PUR filter under cold tap water for 15 seconds.
3. **Insert New Filter:** Insert the new filter into the slot and twist clockwise to lock it into place.
4. **Reset Filter Indicator:** Press and hold the button on the filter gauge for 5 seconds to reset the indicator.
5. **Prime New Filter:** Fill the upper reservoir and discard the first two full reservoirs of filtered water to prime the new filter.

Be cautious of look-alikes



Image 6.2: The PUR Genuine Filter logo, emphasizing the importance of using authentic PUR filters for certified performance.

7. TROUBLESHOOTING

If you encounter issues with your PUR XL 44-Cup Water Filter Dispenser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Slow filtration rate	Filter is clogged or nearing end of life.	Replace the filter. Ensure the new filter is rinsed for 15 seconds before installation.
Water has an unusual taste or odor	Filter needs replacement or was not properly primed.	Replace the filter and ensure the first two reservoirs of water are discarded after installation.
Spout leaks	Spout not properly seated or damaged.	Check if the spout is securely attached. If damage is visible, contact customer support.
Filter indicator light is red but filter is new	Indicator was not reset.	Press and hold the reset button on the filter gauge for 5 seconds.

8. SPECIFICATIONS

- **Brand:** PUR
- **Model Name:** 44-Cup Extra Large Capacity Dispenser
- **Model Number:** PDI4000ZAM
- **Capacity:** 44 Cups (2.75 Gallons)
- **Product Dimensions:** 12.5"L x 7.7"W x 17"H
- **Item Weight:** 8.75 Pounds
- **Material:** Plastic

- **Special Feature:** Removable stand, Filter replacement light
- **Installation Type:** Countertop
- **Power Source:** Corded Electric (for filter indicator light)
- **Supported Water TDS Level Maximum (PPM):** 500
- **Care Instructions:** Dishwasher Safe
- **Assembly Required:** No
- **Number of Pieces:** 1 (main unit)
- **Purification Method:** Ion Exchange

9. WARRANTY INFORMATION

This product comes with a standard manufacturer's warranty. The warranty covers defects in materials and workmanship for a period of one year from the date of purchase. During this period, the product will be repaired or replaced at no cost to the customer. This warranty does not cover damages caused by accidents, misuse, or normal wear and tear.

10. CUSTOMER SUPPORT

For further assistance, questions, or to purchase replacement filters, please visit the official PUR website or contact their customer service department. Ensure you have your product model number (PDI4000Z) available when seeking support.