

[Manuals.plus](#) /

› [Pro Breeze](#) /

› Pro Breeze Evaporative Air Cooler Instruction Manual

Pro Breeze B08Q6KBYB9

Pro Breeze Evaporative Air Cooler Instruction Manual

Model: B08Q6KBYB9

Brand: Pro Breeze

INTRODUCTION

Thank you for purchasing the Pro Breeze Evaporative Air Cooler. This 3-in-1 appliance functions as an air cooler, a cooling fan, and a humidifier, providing versatile climate control for your home. Please read this manual thoroughly before use to ensure proper operation, maintenance, and safety.



The Pro Breeze Evaporative Air Cooler, a 3-in-1 device, shown with its remote control and two ice packs.




IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Ensure the power supply matches the voltage shown on the rating label.
- Do not operate the appliance with a damaged cord or plug.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Supervise children when the appliance is in use.
- Unplug from the outlet when not in use or before cleaning.
- Do not block air inlets or outlets.
- Use only on a flat, stable surface.
- This appliance is for residential use only.
- Do not use outdoors.
- Do not use in bathrooms or wet environments.
- Do not use near heat sources or open flames.
- Only use attachments recommended by the manufacturer.
- Do not attempt to repair or disassemble the unit yourself. Contact qualified service personnel.

PACKAGE CONTENTS

- Pro Breeze Evaporative Air Cooler
- Remote Control
- Ice Packs (x2)
- User Manual




The Pro Breeze Evaporative Air Cooler package includes the main unit, a remote control, and two ice packs.

PRODUCT DIAGRAM & COMPONENTS

Familiarize yourself with the different parts of your evaporative air cooler.

Advanced Technology

The evaporative filter uses honeycomb waterfall cooling technology to pass cold water in front of an internal fan, which blows cold air and water vapor into your room.




An internal view of the Pro Breeze Evaporative Air Cooler, highlighting the honeycomb filter and internal fan system responsible for cooling. The water tank is visible at the bottom.

- Air Outlet Louvers
- Control Panel
- Water Tank (6 Quarts capacity)
- Caster Wheels (x4)
- Honeycomb Filter
- Dust Filter
- Remote Control Receiver
- Power Cord

Portable

Weighing 13lbs and with four wheels, the Pro Breeze Air Cooler is easy to move and manoeuvre. Bring refreshing air cooling to any room in your home.



The removable water tank of the Pro Breeze Evaporative Air Cooler, designed for easy filling and cleaning.

6 Quarts Air Cooler

Evaporative Air Coolers work best in environments with a relative humidity of less than 60%.



6 Quarts Tank



7 Hour
Timer



2 Ice Packs



3 Fan Speeds



Energy
Efficient



Auto-Oscillation



Two reusable ice packs included with the Pro Breeze Evaporative Air Cooler, used to enhance cooling performance.

SETUP

1. **Unpacking:** Carefully remove the air cooler from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the air cooler on a flat, stable surface. Ensure there is adequate space around the unit for proper airflow (at least 20cm from walls or furniture).
3. **Filling the Water Tank:**
 - Pull out the water tank from the rear of the unit.
 - Fill the tank with clean, cool water. Do not exceed the "MAX" fill line.
 - For enhanced cooling, place the two included ice packs (after freezing them) into the water tank.
 - Slide the water tank back into the unit until it clicks securely into place.
4. **Power Connection:** Plug the power cord into a standard electrical outlet.



Fan Mode



Natural Mode



Night Mode




3 Operating Modes

Switch between Fan Mode, Nature Mode and Night Mode and find the perfect mode for the situation.

The Pro Breeze Evaporative Air Cooler positioned in a living room, demonstrating its compact and portable design.

OPERATING INSTRUCTIONS

The air cooler can be operated using the control panel on top of the unit or the included remote control.



Powerful Cooling

With 3 speed settings and vertical louvres that can oscillate at 70 degrees, the Pro Breeze Air Cooler can rapidly cool a large room.

Close-up view of the control panel on the top of the Pro Breeze Evaporative Air Cooler, showing buttons for power, oscillation, modes, speed, and timer.

Control Panel & Remote Control Functions:


Button/Function	Description
Power (On/Off)	Turns the unit on or off.
Speed (1, 2, 3)	Adjusts fan speed: Low, Medium, High.
Mode (Normal, Natural, Sleep)	Cycles through operating modes: Normal (constant speed), Natural (simulates natural breeze), Sleep (gradually reduces speed for quiet operation).
Cooling/Humidifier	Activates or deactivates the evaporative cooling/humidifying function.
Oscillation	Activates or deactivates the 70° automatic oscillation of the vertical louvers.

Timer (1-7 hours)

Sets the automatic shut-off timer for up to 7 hours.

Ideal Conditions for the Air Cooler

Pro Breeze Evaporative Air Coolers work best in environments with maximum relative humidity of 60% or less, when air is warm and dry. There will be a greater decrease in temperature because more evaporation occurs when humidity is low.



Humidity <20 ~ 25%

Humidity 26 ~ 45%

Humidity 46 ~ 65%

Humidity 66 ~ >80%

Visual representation of the three operating modes: Fan Mode, Natural Mode, and Night Mode, illustrating the versatility of the air cooler in different room settings.

MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your air cooler.

Cleaning the Exterior:

Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Cleaning the Water Tank:

1. Unplug the unit from the power outlet.

2. Pull out the water tank.
3. Empty any remaining water.
4. Clean the tank with mild soap and water. Rinse thoroughly.
5. Dry the tank completely before reinserting.
6. Clean the water tank regularly, especially if using the humidifying function frequently, to prevent mold or mildew buildup.


Cleaning the Filters (Honeycomb & Dust Filter):

The unit is equipped with a honeycomb evaporative filter and a dust filter. These should be cleaned periodically.

1. Unplug the unit.
2. Remove the rear filter frame.
3. Carefully remove the honeycomb filter and dust filter.
4. Rinse both filters under running water to remove dust and debris. For stubborn dirt, use a soft brush.
5. Allow filters to air dry completely before reinserting them into the unit.
6. Reassemble the filters and filter frame.

Advanced Technology

The evaporative filter uses honeycomb waterfall cooling technology to pass cold water in front of an internal fan, which blows cold air and water vapor into your room.



The internal honeycomb filter of the Pro Breeze Evaporative Air Cooler, which should be regularly cleaned for optimal performance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply; Power cord not plugged in; Power button not pressed.	Check power outlet; Ensure power cord is securely plugged in; Press the Power button.
No cool air/Weak cooling.	Water tank empty; Cooling function not activated; Filters are dirty; High humidity in the room.	Fill water tank; Activate cooling mode; Clean honeycomb and dust filters; Evaporative coolers are less effective in high humidity (above 60%).
Unusual noise.	Unit not on a flat surface; Water pump issue (low water level); Obstruction in fan.	Place on a flat surface; Check water level; Unplug and check for obstructions.

Remote control not working.	Batteries dead/incorrectly inserted; Obstruction between remote and unit.	Replace batteries (AAA); Ensure clear line of sight to the unit's receiver.
-----------------------------	--	---

SPECIFICATIONS

Feature	Detail
Model	B08Q6KBYB9
Brand	Pro Breeze
Type	3-in-1 Evaporative Air Cooler, Fan, Humidifier
Power Consumption	65 Watts
Water Tank Capacity	6 Quarts
Coverage Area	Up to 200 sq ft
Fan Speeds	3 (Low, Medium, High)
Oscillation	70° Automatic Oscillation
Timer	Up to 7 hours
Noise Level	As low as 45dB
Dimensions (D x W x H)	11.4"D x 11.9"W x 26"H
Item Weight	13 pounds
Included Accessories	Remote Control, 2 Ice Packs

Quiet Cooling

Operates at noise levels as low as 45dB. Ideal for background use as you work, relax or sleep.



<45dB

The Pro Breeze Evaporative Air Cooler with its dimensions clearly marked: 11.4 inches deep, 11.9 inches wide, and 26 inches high, highlighting its compact design.

WARRANTY & SUPPORT

Pro Breeze products are manufactured to the highest standards. For any questions, technical support, or warranty claims, please contact Pro Breeze customer service.

Please refer to the official Pro Breeze website or your purchase documentation for specific warranty terms and contact information.

Note: Keep your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question