

[Manuals.plus](#) /

> [Audizio](#) /

> Audizio Prato DAB Digital Radio with CD Player, Bluetooth Wireless Streaming, DAB+, USB MP3 Playback, Stereo Speakers, X-Bass Sound, Remote Control, Home Audio System - White & Light Brown User Manual

Audizio 102.217

Audizio Prato DAB Digital Radio with CD Player User Manual

MODEL: 102.217

Introduction

Welcome to the user manual for your Audizio Prato DAB Digital Radio. This all-in-one music system combines modern digital radio technology with classic audio playback options, offering a versatile listening experience. Please read this manual carefully to ensure proper use and to maximize the performance of your device.

Key features of your Audizio Prato include:

- DAB+ Digital and FM Radio reception for clear audio.
- Built-in slot-loading CD player supporting various CD formats.
- Bluetooth 5.3 technology for wireless audio streaming.
- USB MP3 input for direct music playback and device charging.
- Rich stereo speakers with X-Bass enhanced audio and selectable sound modes.
- Remote control for convenient operation.



Figure 1: The Audizio Prato DAB Digital Radio with its included remote control, showcasing its white and light brown wooden design.

Setup

1. Unpacking

Carefully remove the Audizio Prato unit and all accessories from the packaging. Retain the packaging for future transport or storage.

2. Power Connection

Connect the supplied power adapter to the DC IN socket on the rear of the unit, then plug the adapter into a suitable wall outlet. The unit will enter standby mode.

3. Antenna Setup

Extend the telescopic antenna fully for optimal DAB+ and FM radio reception. Adjust its position for the best signal quality.

4. Initial Power On and Auto Scan

Press the **POWER** button on the unit or remote control to turn on the device. Upon first use, the unit may automatically initiate a DAB+ station scan. Allow the scan to complete to populate the station list.

CD PLAYER



INTEGRATED SLOT-LOAD CD PLAYER

 audizio

Figure 2: The Audizio Prato radio positioned on a wooden cabinet, demonstrating its aesthetic integration into a home environment and highlighting its digital radio capabilities.

Operating Instructions

1. General Controls

Control	Function
POWER button	Turns the unit on or off (standby).
VOLUME knob	Adjusts the audio output level.
MENU button	Accesses the system menu for current mode.
FUNCTION button	Switches between different operating modes (DAB, FM, CD, Bluetooth, USB, AUX).

Control	Function
PRESET buttons (1-4)	Quick access to stored radio stations or tracks.



Figure 3: A detailed view of the Audizio Prato's front panel controls, including the volume knob, function buttons, and the accompanying remote control for comprehensive operation.

2. DAB+ Radio Operation

1. Press **FUNCTION** to select DAB mode.
2. The unit will display the current station or initiate a scan if no stations are found.
3. Use the **SELECT** knob or **PRESET +/-** buttons to navigate through the available station list.
4. Press **SELECT** to confirm your station choice.
5. To save a preset: Press and hold a **PRESET** button (1-4) until "Preset Stored" appears.

3. FM Radio Operation

1. Press **FUNCTION** to select FM mode.
2. Press and hold the **PLAY/PAUSE** button to auto-scan for the next available station.

3. Alternatively, use the **PRESET +/-** buttons for manual tuning.
4. To save a preset: Press and hold a **PRESET** button (1-4) until "Preset Stored" appears.

4. CD Player Operation

The Audizio Prato features a convenient slot-loading CD player.

1. Press **FUNCTION** to select CD mode.
2. Gently insert a CD into the slot. The unit will automatically load the disc and begin playback.
3. Use the **PLAY/PAUSE**, **STOP**, **SKIP FORWARD**, and **SKIP BACKWARD** buttons to control playback.



Figure 4: A close-up view of the integrated slot-load CD player on the Audizio Prato, showing a CD being inserted into the unit.

5. Bluetooth Streaming

Stream audio wirelessly from your smartphone, tablet, or other Bluetooth-enabled devices.

1. Press **FUNCTION** to select Bluetooth mode. The display will show "Bluetooth Pairing" or "Bluetooth Connected".
2. On your device, enable Bluetooth and search for "Audizio Prato".

3. Select "Audizio Prato" from the list to pair. Once connected, you can play audio from your device through the radio.

SUPERIOR AUDIO QUALITY



FRONT FACING FULL-RANGE SPEAKERS



Figure 5: A user wirelessly streaming music from a smartphone to the Audizio Prato via Bluetooth, demonstrating the convenience of cable-free audio playback.

6. USB Playback and Charging

The USB port allows for MP3 playback from a USB stick and charging of external devices.

1. Insert a USB stick containing MP3 files into the USB port.
2. Press **FUNCTION** to select USB mode. Playback will begin automatically.
3. Use the **SKIP FORWARD/BACKWARD** buttons to navigate tracks.
4. To charge a device, connect it to the USB charging port using a compatible cable.

7. Auxiliary Input (AUX IN)

Connect external audio devices using a 3.5mm audio cable to the AUX IN port.

1. Connect your external device to the **AUDIO IN** jack on the front panel.

2. Press **FUNCTION** to select AUX mode.
3. Control playback from your connected external device.

COMPACT DESIGN



REMOTE INCLUDED

audizio

Figure 6: A diagram illustrating the various connection points on the Audizio Prato, including Audio In, USB Port, USB Charging, and Headphones Output.

8. Sound Modes and X-Bass

Enhance your listening experience with selectable sound modes:

- Press the **EQ** button on the remote control to cycle through sound modes: Flat, Classic, Rock, Pop, Jazz.
- The X-Bass feature provides enhanced bass response. Activate or deactivate it via the remote control.

WAKE UP WITH AUDIZIO



ALARM & SNOOZE FUNCTION

LCD DISPLAY WITH DIMMER

audizio

Figure 7: The Audizio Prato unit with visual representations of sound waves, emphasizing its front-facing full-range stereo speakers and superior audio quality.

9. Alarm and Sleep Timer

Set alarms to wake up to your favorite radio station or a buzzer, and use the sleep timer to automatically turn off the unit.

- **Alarm Setup:** Press the **ALARM** button on the remote. Use the **SELECT** knob to set time, source (DAB/FM/Buzzer), and volume. Press **SELECT** to confirm each setting.
- **Sleep Timer:** Press the **SLEEP** button on the remote repeatedly to cycle through sleep timer options (e.g., 15, 30, 45, 60, 90, 120 minutes, OFF).

CONNECTIONS



AUDIO IN

USB PORT

USB CHARGING

HEADPHONES OUTPUT

audizio

Figure 8: The Audizio Prato unit on a bookshelf, displaying the time on its LCD screen, illustrating its alarm and snooze functions for waking up.

Maintenance

1. Cleaning

To clean the unit, use a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as these may damage the surface. For the display, use a soft, lint-free cloth. Avoid spraying cleaning solutions directly onto the unit.

2. CD Care

Handle CDs by their edges. Keep them clean and free from scratches. If a CD is dirty, wipe it gently from the center outwards with a soft, lint-free cloth. Do not use harsh chemicals or abrasive materials.

3. General Handling

Avoid placing the unit in direct sunlight, near heat sources, or in areas with high humidity or dust. Ensure adequate ventilation around the unit to prevent overheating. Do not block the ventilation openings.

Troubleshooting

Problem	Possible Cause / Solution
No power	Ensure the power adapter is securely connected to the unit and the wall outlet. Check if the wall outlet is functioning.
No sound	Adjust the volume. Ensure the correct input mode is selected. Check headphone connection if applicable.
Poor radio reception	Fully extend and adjust the telescopic antenna. Try repositioning the unit. Perform a new auto-scan for DAB+ stations.
Bluetooth pairing issues	Ensure the unit is in Bluetooth mode. Make sure Bluetooth is enabled on your device and it is within range. Forget "Audizio Prato" on your device and try pairing again.
CD not playing / "Unknown Disk"	Ensure the CD is clean and free from scratches. Try a different CD. Ensure the CD is inserted correctly.
Remote control not working	Check and replace the batteries in the remote control. Ensure there are no obstructions between the remote and the unit's sensor.

Specifications

Feature	Detail
Model Number	102.217
Product Dimensions (L x W x H)	44.3 x 26 x 19 cm
Item Weight	3.6 kg
Connectivity Technology	Bluetooth 5.3, USB, AUX-in
Speaker Type	Stereo
Radio Tuner	DAB+, FM
CD Player	Slot-loading, supports CD, CD-R, CD-RW, MP3 CD
USB Playback	MP3 files from USB stick
USB Charging	Yes
Colour	White & Light Brown

Feature	Detail
Manufacturer	Tronios B.V.



Figure 9: A diagram illustrating the compact dimensions of the Audizio Prato unit, including its length, width, and height, alongside the remote control.

Warranty and Support

Your Audizio Prato DAB Digital Radio is designed and manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or contact your retailer.

For technical support, troubleshooting assistance beyond this manual, or spare parts, please contact the seller or manufacturer directly. Their contact information can typically be found on your purchase receipt or the product packaging.

Please retain your proof of purchase for any warranty claims.

