

## VINABTY EN2A27ST

# VINABTY EN2A27ST Replacement Remote Control Instruction Manual

**Model:** EN2A27ST | **Brand:** VINABTY

## INTRODUCTION

This manual provides instructions for the VINABTY EN2A27ST replacement remote control. This remote is designed to function as a direct replacement for your original Sharp Smart TV remote, requiring no programming or setup for compatible models. Please read this manual carefully to ensure proper use and maintenance of your new remote control.

## PRODUCT OVERVIEW

The VINABTY EN2A27ST remote control offers a comfortable, ergonomic design for ease of use. It is pre-programmed to work with a range of Sharp Smart TV models.

### Compatible Sharp Smart TV Models:

- LC-50P5000U
- LC-60P6070U
- LC-40P5000U
- LC-43P5000U
- LC-55P5000U
- LC-55P6000U
- LC-60P6000U
- LC-32Q5230U
- LC-43Q5000U
- LC-32Q5280U
- LC-32Q5200U
- LC-55P6050U
- And other similar Sharp Smart TV models.

### Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or outwards to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.

**Note:** The remote control does not require any programming. Once batteries are installed, it is ready for immediate use with compatible Sharp Smart TVs.





Image: A hand holding the VINABTY EN2A27ST remote control, demonstrating its use in front of a television and soundbar. This illustrates the remote's ergonomic design and readiness for operation.

## OPERATING INSTRUCTIONS

To operate your Sharp Smart TV with the VINABTY EN2A27ST remote control, simply point the remote directly at the TV's infrared sensor and press the desired button.

### Basic Functions:

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **Volume Up/Down:** Adjusts the TV's volume.

- **Channel Up/Down:** Changes the TV channel sequentially.
- **Mute Button:** Mutes or unmutes the TV audio.
- **Input/Source Button:** Cycles through available input sources (HDMI, AV, etc.).
- **Menu Button:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate through menus and confirm selections.
- **Smart TV/Home Button:** Accesses the Smart TV interface or home screen.

## MAINTENANCE

### Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

### Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's surface or internal components.

### Storage

Store the remote control in a dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.

## TROUBLESHOOTING

- **Remote not responding:**
  - Ensure fresh AAA batteries are correctly installed.
  - Check for any obstructions between the remote and the TV's infrared sensor.
  - Ensure you are pointing the remote directly at the TV.
- **Some buttons not working:**
  - This remote is a replacement and may not have all the advanced functions of some original remotes. Verify if the button is standard for basic TV operation.
  - Clean the remote surface, especially around the non-working buttons, to remove any debris.

## SPECIFICATIONS

Model	EN2A27ST
Brand	VINABTY
Dimensions	7.9 x 2 x 0.7 inches (approx.)
Item Weight	1.9 ounces (approx.)
Color	Black
Power Source	2 x AAA Batteries (not included)

Special Feature

Ergonomic Design

## WARRANTY AND SUPPORT

For any issues or questions regarding your VINABTY EN2A27ST remote control, please refer to the retailer or manufacturer's support channels. Specific warranty details may vary by purchase location and are typically provided at the time of sale.