

Soul Electronics SS60BK

SOUL S-Nano True Wireless Earbuds Instruction Manual

Model: SS60BK

INTRODUCTION

Thank you for choosing the SOUL S-Nano True Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.

WHAT'S INCLUDED

The SOUL S-Nano package includes the following items:

- SOUL S-Nano Earphones (Left and Right)
- Charging Case
- USB-C Charging Cable
- Multiple Sizes of Ear Tips (S, M, L)
- Carabiner

Figure 1: Package Contents

PRODUCT FEATURES

- **Ultra Portable Design:** Compact and lightweight for easy carrying.
- **Bluetooth Connectivity:** Seamless wireless audio experience.
- **IPX5 Water Resistance:** Protected against sweat and light splashes.
- **Transparency Mode:** Allows you to hear your surroundings while listening to audio.
- **Extended Battery Life:** Up to 24 hours of total playtime with the charging case.



Figure 2: Ultra Portable Design




Figure 3: 24 Hours Battery Life

WHAT'S INCLUDED




Figure 4: Audio Transparency

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the SOUL S-Nano earbuds and charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB-C charging cable to the charging port on the case and to a power source.
3. The LED indicator on the case will show charging status. A full charge typically takes approximately 1.5 hours for the earbuds and 2 hours for the case.

2. Pairing with Your Device

Follow these steps to pair your SOUL S-Nano earbuds with a Bluetooth-enabled device:

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by flashing LED lights on the earbuds.
2. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Select "SOUL S-Nano" from the list of available devices.
4. Once connected, the LED indicators on the earbuds will stop flashing.
5. If pairing fails, place the earbuds back into the case, close the lid, and repeat the steps.

OPERATING INSTRUCTIONS

Wearing the Earbuds

For optimal sound quality and comfort, ensure the earbuds are properly seated in your ears. Experiment with the different

ear tip sizes (S, M, L) to find the best fit.



Figure 5: Correct Earbud Placement

Touch Controls

The SOUL S-Nano earbuds feature intuitive touch controls:

Function	Action
Play/Pause	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Press and hold either earbud for 2 seconds

Function	Action
Activate Voice Assistant	Triple tap on either earbud
Toggle Transparency Mode	Press and hold the right earbud for 2 seconds

MAINTENANCE

Cleaning

Regular cleaning helps maintain sound quality and hygiene:

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water. Ensure they are completely dry before reattaching.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Avoid extreme temperatures.

Water Resistance (IPX5)

The SOUL S-Nano earbuds are rated IPX5, meaning they are resistant to water splashes from any direction. They are suitable for workouts and light rain but should not be submerged in water or exposed to pressurized water streams.

TROUBLESHOOTING

If you encounter issues with your SOUL S-Nano earbuds, refer to the following common solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then reopen to re-enter pairing mode. Check your device's Bluetooth settings.
No sound from one earbud	Check battery level of both earbuds. Try resetting the earbuds (refer to manufacturer's website for specific reset instructions if needed). Re-pair with your device.
Charging case not charging	Ensure the USB-C cable is securely connected to both the case and the power source. Try a different cable or power adapter.
Poor sound quality	Ensure earbuds are clean and ear tips provide a good seal. Move closer to your device to avoid interference.

SPECIFICATIONS

Feature	Detail
Model Number	SS60BK
Connectivity Technology	Wireless (Bluetooth)

Feature	Detail
Wireless Communication Technology	Bluetooth
Ear Placement	In Ear
Water Resistance Level	IPX5 (Waterproof)
Batteries	1 Lithium Ion battery required (included)
Item Weight	5.9 ounces
Product Dimensions	0.39 x 0.39 x 2.05 inches
Control Type	Media Control

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

This video provides a visual overview of the SOUL S-Nano True Wireless Earbuds, showcasing their design, features, and use in various scenarios. It highlights the compact size, multiple color options, and active lifestyles they support.

WARRANTY AND SUPPORT

For warranty information, technical support, or further assistance, please visit the official Soul Electronics website or contact their customer service. Keep your proof of purchase for warranty claims.

Website: [Soul Electronics Store on Amazon](#)

© 2023 Soul Electronics. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question