Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JYX JYX-V15

JYX Wireless Microphone User Manual

Model: JYX-V15 | Brand: JYX

1. Introduction

The JYX Wireless Microphone is a dynamic microphone system designed for various audio applications, including karaoke, meetings, performances, and parties. It offers a stable wireless signal with an operating range of up to 80 feet, providing freedom of movement during use. The system features a rechargeable microphone and receiver, ensuring long hours of operation.

Key Features:

- **Wireless Freedom:** Enjoy up to 80ft transmission distance for energetic performances.
- **Rechargeable Battery:** The receiver provides 8-10 hours of use on a 3-5 hour charge.
- **Extensive Compatibility:** Suitable for home karaoke, church, weddings, conferences, and small stage performances.
- **Quick Setup:** Automatic frequency syncing between receiver and microphone.
- **Durable Design:** Rugged construction for dependable performance and long life.

2. What's in the Box

Carefully unpack your JYX Wireless Microphone system and ensure all components are present:

- 1 x JYX Wireless Microphone
- 1 x Receiver with 6.35mm Plug
- 1 x Anti-Slip Ring
- 2 x Type-C Charging Cables
- 1 x User Manual
- 2 x AA Batteries (for microphone)



Image: Detailed view of the JYX wireless microphone and receiver, highlighting the LED screen, charging port, ON/OFF switch, and indicator lights.

3. Setup Guide

3.1 Initial Charging

Before first use, fully charge the receiver using one of the provided Type-C charging cables. The receiver typically takes 3-5 hours to fully charge and provides 8-10 hours of operation. The microphone uses 2 AA batteries (included).



Image: JYX Wireless Microphone illustrating its 2200mAh battery capacity and up to 10 hours of playing time.

3.2 Connecting the System

1. Insert the 2 AA batteries into the microphone, ensuring correct polarity.
2. Turn on the JYX wireless microphone by pressing and holding the power button. The LED screen will illuminate.
3. Plug the receiver into the 6.35mm microphone jack of your audio device (e.g., karaoke machine, PA system, amplifier, outdoor speaker).
4. Turn on the receiver. The receiver will automatically sync its frequency with the microphone. A stable indicator light on the receiver confirms a successful connection.
5. Adjust the volume on your audio device as needed.



Image: JYX wireless microphone and receiver demonstrating stable wireless signal and 80ft operating distance.



Image: Visual representation of the JYX wireless microphone's wide compatibility with various audio devices.

4. Operating Instructions

4.1 Powering On/Off

- **To Power On:** Press and hold the power button on the microphone until the LED screen lights up. For the receiver, slide the ON/OFF switch to the 'ON' position.
- **To Power Off:** Press and hold the power button on the microphone until the LED screen turns off. For the receiver, slide the ON/OFF switch to the 'OFF' position.

4.2 Usage Tips

- **Optimal Placement:** For best performance, avoid using the microphone in a small, enclosed space. Maintain a certain distance from the audio output device to prevent interference noise.
- **Anti-Slip Ring:** Place the included anti-slip ring on the microphone to prevent it from rolling on flat surfaces and to provide additional grip.
- **Sound Pickup:** The microphone is designed for high-quality sound pickup, focusing on your voice while filtering out

ambient noise and echo.



Image: Illustration of the microphone's 180-degree sound pickup pattern, designed to enhance sound quality and reduce noise.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the microphone and receiver. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the microphone system in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** For optimal battery life, avoid fully discharging the receiver's battery frequently. Recharge it regularly. Remove AA batteries from the microphone if storing for extended periods to prevent leakage.
- **Handle with Care:** Avoid dropping the microphone or subjecting it to strong impacts, as this can damage internal components.

6. Troubleshooting

If you encounter issues with your JYX Wireless Microphone, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
No sound from microphone	Microphone or receiver not powered on; Low battery; Incorrect connection; Frequency not synced.	Ensure both microphone and receiver are turned on. Check battery levels and recharge/replace if necessary. Verify receiver is securely plugged into the 6.35mm jack. Power cycle both devices to re-sync frequency.
Sound cutting in/out or static	Interference; Out of range; Obstructions; Low battery.	Move closer to the receiver. Ensure no large metal objects or other wireless devices are causing interference. Check battery levels. Avoid using in small, enclosed spaces.
Microphone not charging	Faulty cable; Incorrect power source; Receiver charging port issue.	Ensure the Type-C charging cable is properly connected to the receiver and a working USB power source. Try a different charging cable or power adapter.
Poor sound quality (distortion, weak)	Microphone too far/close; Audio device settings; Environmental noise.	Adjust microphone distance from mouth. Check volume and EQ settings on your audio device. Ensure microphone is not picking up excessive background noise.

7. Specifications

Feature	Specification
Model Number	JYX-V15
Microphone Form Factor	Handheld
Connectivity Technology	UHF Wireless
Operating Range	Up to 80 feet (line of sight)
Power Source	Battery Powered (Rechargeable Receiver, AA for Mic)
Receiver Battery Life	8-10 hours (after 3-5 hours charge)
Connector Type	6.35 mm Jack
Material	Metal, Plastic
Polar Pattern	Unidirectional
Signal-to-Noise Ratio	60 dB
Item Weight	14.1 ounces (400 Grams)
Product Dimensions	8.07 x 11.02 x 4.92 inches

8. Warranty & Support

JYX products are manufactured with high-quality standards. For any warranty claims, technical support, or inquiries regarding your JYX Wireless Microphone, please contact JYX customer service directly. Refer to the product packaging or the official JYX website for the most current contact information.

© 2024 JYX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08QFJDPQZ

More documents and user manuals: **https://manuals.plus/**