

Manuals.plus /

› Smoby /

› Smoby Garden House Playhouse Instruction Manual Model 7600810405

Smoby 7600810405

**Spielend wachsen und
die Welt entdecken!**

Smoby Garden House Playhouse

INSTRUCTION MANUAL - MODEL 7600810405

Introduction

Welcome to the instruction manual for your Smoby Garden House Playhouse. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new playhouse. Designed for children aged 24 months to 7 years, this playhouse offers a rich gardening theme experience with various interactive features and accessories.



Image: The Smoby Garden House Playhouse, showcasing its main features including the planter, trellis, and water collector.

Safety Information

- **WARNING:** Intended for indoor or outdoor use.
- **WARNING:** For family use only.
- Minimum age for use: 24 months.
- Adult supervision is recommended during play.
- Ensure all parts are securely assembled before allowing children to play.

Setup and Assembly

Assembly of the Smoby Garden House Playhouse is required. Please follow the detailed instructions provided in the packaging. While assembly is generally straightforward, some parts may be intricate, and a drill might be necessary for certain steps. It is recommended to allocate sufficient time for assembly, approximately 2-3 hours.

Components Included:

- 1 Playhouse structure

- 1 Potting table
- 1 Water collector with watering can
- 1 Large planter
- 1 Trellis
- 20 accessories (including 3 tools: shovel, rake, planter; 6 pots; 1 slate for notes; garden markers; and a small gardener's booklet with clips)



Image: Diagram showing the dimensions of the assembled Smoby Garden House Playhouse: 135 cm height, 128 cm width, 132 cm depth.

Before starting assembly, ensure all components listed above are present. In rare cases, some small parts like screws might be missing or in excess; please verify the contents against the parts list in your physical manual.

Operating Instructions

The Smoby Garden House is designed to encourage imaginative play, particularly around gardening activities.

Key Features and How to Use Them:

- **Planter:** Use the large planter to simulate planting flowers or herbs.
- **Trellis with Pots and Bird Feeder:** The trellis allows for hanging small pots and includes a bird feeder for interactive play.
- **Water Collector and Watering Can:** The water collector system allows for imaginative water collection and use with the included watering can.
- **Mobile Work Surface:** A portable work surface provides a dedicated area for potting and other gardening tasks, keeping tools and accessories organized.
- **Accessories:** Utilize the included shovel, rake, planter, pots, slate, and garden markers to enhance the gardening play experience. The slate allows children to write notes or plant names with chalk.
- **Doors and Windows:** The playhouse features a door, two windows with shutters, and two portholes for realistic

house play.

ACCESORIOS CASAS DE SMOBY							Check de compatibilidad <input checked="" type="checkbox"/> SI <input type="checkbox"/> No <input type="checkbox"/> Includido						
MODELOS							MODELOS						
COMPATIBILIDADES							COMPATIBILIDADES						
810912	810907	810914	810915	850208	810901	810904	810909	810903	810905	810910	810902	810911	810913
C. NATURE II C. LOVELY C. PRETTY C. JULIE	1 Set	✓	✓	✓	✓	✓							
NATUREZ CON COCINA PRETTY CON COCINA	2 Sets	✓	✓	✓	✓	•							
SWEETY CORNER	1 Set	✓	✓	✓	✓	✓							
CASITA CON ARENERO	1 Set	✓	✓	✓	•	✓							
CASITA DE LA PLAYA CON TOBOGÁN	2 Sets	✓	✓	✓	✓								
JURA LODGE II	2 Sets	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
CASITA MY NEW HOUSE	2 Sets	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
CHEF HOUSE	2 Sets	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
CASITA GARDEN HOUSE	2 Sets	✓	✓	✓	✓	✓	•	✓	✓	✓	✓	✓	✓
NEO FRIENDS HOUSE	3 Sets	•	✓	✓	✓	✓	✓	•	✓	✓	•	✓	✓
NEO FRIENDS HOUSE CON COCINA	3 Sets	•	✓	✓	✓	✓	✓	•	✓	✓	•	✓	✓
FRIENDS HOUSE EVO	2 Sets	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

Adaptable a todas las mesas de picnic

Image: A child engaging with the gardening accessories and work surface inside the Smoby Garden House.



Image: A collection of the 20 included accessories for the Smoby Garden House, featuring a watering can, various pots, gardening tools, and plant markers.

Maintenance

To ensure the longevity and appearance of your Smoby Garden House, follow these maintenance guidelines:

- **Cleaning:** Wipe down the playhouse surfaces regularly with a damp cloth and mild soap. Avoid abrasive cleaners.
- **UV Treatment:** The playhouse is UV-treated to ensure its stability and resistance, as well as to maintain color vibrancy over time.
- **Inspection:** Periodically check all screws, fasteners, and connections to ensure they are tight and secure. Replace any damaged parts immediately.
- **Storage:** While designed for outdoor use, consider covering the playhouse during extreme weather conditions to further extend its lifespan.

Troubleshooting

- **Stability Issues (Wind):** The playhouse does not include ground fixation. In areas prone to strong winds, it is recommended to place the playhouse in a sheltered location or secure it to the ground using appropriate anchors (not included).
- **Missing Parts:** If you find any parts missing during assembly, particularly small components like screws, please contact Smoby customer support or your retailer for assistance.
- **Difficulty Assembling:** Refer to the detailed assembly instructions provided with the product. Ensure all steps are followed carefully. If issues persist, seek assistance from another adult.

Specifications

Model Number	7600810405
ASIN	B08QJFVCSL
Brand	Smoby
Material	Plastic
Product Dimensions (L x W x H)	132 cm x 128 cm x 135 cm (52 in x 50.4 in x 53.1 in)
Item Weight	26 Kilograms (57.3 lbs)
Recommended Age	24 months - 7 years
Assembly Required	Yes
Number of Windows	2
Components Included	Playhouse, potting table, water collector with watering can, large planter, trellis, 20 accessories

Warranty and Support

For specific warranty details, please refer to the documentation included with your purchase or contact your retailer.

Smoby is committed to producing high-quality, durable toys.

For customer support, product inquiries, or to report missing/damaged parts, please visit the official Smoby website or contact their customer service department.

Smoby's Commitment to Sustainability:

Smoby is dedicated to environmentally friendly production, reducing waste, and using recycled materials. Packaging is made from 80% recycled cardboard and is fully recyclable.

