

[Manuals.plus](#) /

> [Nostalgia](#) /

> Nostalgia Retro Stainless Steel Electric Tea And Water Kettle, 1.7 Liters, Auto-Shut Off & Boil-Dry Protection, Water Level Indicator Window, Aqua User Manual

Nostalgia WK17AQ

Nostalgia Retro Stainless Steel Electric Tea And Water Kettle

USER MANUAL

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury, including the following:

- Read all instructions before operating this appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or any part of the base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

The Nostalgia Retro Stainless Steel Electric Tea And Water Kettle is designed for rapid boiling and

convenient use. It features a classic retro design combined with modern functionality, making it a stylish and efficient addition to any kitchen.



Image: The Nostalgia Retro Electric Kettle in Aqua, showcasing its sleek design and integrated temperature gauge.

PERFECT FOR ANY COUNTERTOP



Image: The kettle positioned on a kitchen countertop, demonstrating its compact size and aesthetic appeal alongside a mug of tea and a glass of coffee.

Parts Identification

- Kettle Body: Stainless steel construction with retro styling.
- Lid: Removable lid for easy filling.
- Handle: Ergonomically designed handle for comfortable pouring.
- Power Base: 360-degree rotational base for cord-free serving.
- Water Level Indicator Window: Clear window with capacity markings (up to 1.7 liters).
- Temperature Gauge: Easy-to-read analog gauge displaying water temperature.
- On/Off Indicator Switch: Lighted switch for simple operation.
- Spout: Designed for smooth pouring.



Image: Diagram showing the dimensions of the Nostalgia Electric Kettle, with height of 10.14 inches and width of 6.2 inches.

Setup

1. Before first use, wipe down the exterior of the kettle with a damp cloth.
2. Fill the kettle with water up to the MAX fill line (1.7 liters).
3. Boil the water and then discard it. Repeat this process 2-3 times to ensure the kettle is clean and free of any manufacturing residues.
4. Place the kettle securely on its power base.
5. Ensure the power base is placed on a stable, flat, heat-resistant surface.

Operating Instructions

The Nostalgia Electric Kettle is designed for quick and efficient water heating.

1. Fill the kettle with the desired amount of water. Do not fill below the MIN line or above the MAX line (1.7 liters).
2. Place the kettle firmly on its 360-degree rotational power base.
3. Plug the power base into a standard electrical outlet.
4. Flip the lighted On/Off indicator switch to the 'ON' position. The light will illuminate, indicating the kettle is heating.
5. The kettle will rapidly boil the water. The temperature gauge will show the rising temperature.
6. Once the water reaches boiling temperature, the kettle will automatically shut off due to the boil-dry protection system, and the indicator light will turn off.
7. Carefully remove the kettle from the base and pour the hot water.

This kettle is perfect for making tea, coffee, hot chocolate, instant soups, oatmeal, and more.

IT'S AS EASY AS...

1
Fill the kettle and flip the switch

2
Wait for water to boil

3
Pour and enjoy!



quickly boil water for hot drinks, instant soup, pasta, and more!

Image: A visual guide demonstrating the simple three-step process: 1. Fill the kettle and flip the switch, 2. Wait for water to boil, 3. Pour and enjoy.



Image: A collage of four circular images showing different applications for the hot water: Tea, Oatmeal, Instant Soup, and Hot Chocolate.



Image: Close-up of the kettle's 360-degree rotational base with arrows indicating rotation, and an icon illustrating the boil-dry protection feature.

Cleaning & Maintenance

Proper cleaning and maintenance will ensure the longevity of your Nostalgia Electric Kettle.

- Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
- The kettle body should be hand washed only. Do not immerse the kettle body or power base in water or any other liquid.
- Wipe the exterior of the kettle with a damp cloth and dry thoroughly.
- For interior cleaning, fill the kettle with a mixture of water and white vinegar (1:1 ratio) and boil. Let it sit for 30 minutes, then discard the mixture and rinse thoroughly. Repeat if necessary to remove mineral deposits.
- Do not use abrasive cleaners or scouring pads, as they may scratch the finish.

Troubleshooting

If your Nostalgia Electric Kettle is not functioning correctly, please check the following common issues:

- **Kettle does not turn on:** Ensure the power base is securely plugged into a working outlet. Check that the kettle is properly seated on the base and the On/Off switch is flipped to 'ON'.
- **Water is not boiling:** Verify that the kettle has enough water (above MIN line). Ensure the lid is securely closed.
- **Kettle shuts off prematurely:** This may indicate the boil-dry protection system has activated due to insufficient water. Refill the kettle and try again. If the issue persists, ensure the heating element is clean of mineral buildup.
- **Water tastes metallic or unusual:** Ensure you have performed the initial cleaning steps (boiling and discarding water several times). Regular descaling may be necessary if mineral deposits are present.

For issues not listed here, please contact customer support.

Specifications

Brand	Nostalgia
Model Name	WK17AQ
Color	Aqua
Capacity	1.7 Liters
Special Feature	Manual, Auto-Shut Off, Boil-Dry Protection, Water Level Indicator Window, Temperature Gauge, 360-Degree Rotational Base, Cord Storage
Material	Stainless Steel with Chrome Handle Cover
Product Dimensions	8.92"L x 6.2"W x 10.14"H
Item Weight	3.37 pounds
UPC	082677004499

Warranty & Support

This Nostalgia product is covered by a manufacturer's warranty. Please refer to the included warranty card or visit the official Nostalgia website for detailed information regarding warranty coverage, terms, and conditions.

For customer support, product registration, or to purchase replacement parts, please visit the [Nostalgia Store on Amazon](#) or contact Nostalgia customer service directly.