

[Manuals.plus](#) /

> [RALAN](#) /

> RALAN Xbox One Controller Skin Instruction Manual

RALAN Xone

RALAN Xbox One Controller Skin Instruction Manual

Model: Xone

INTRODUCTION

Thank you for choosing the RALAN Anti-Slip Silicone Controller Cover for your Xbox One controller. This manual provides detailed instructions to help you properly install, use, and maintain your new controller skin and thumb grips, ensuring an enhanced gaming experience.

PACKAGE CONTENTS

- 1 x RALAN Silicone Controller Cover for Xbox One
- 12 x Thumb Grip Caps (4 different types, 8 pieces total)

SETUP AND INSTALLATION

Follow these steps to install the silicone cover and thumb grips on your Xbox One controller.

1. **Prepare Your Controller:** Ensure your Xbox One controller is clean and dry before installation.
2. **Install the Silicone Cover:**
 - Gently stretch the silicone cover over the top of your Xbox One controller, aligning the openings with the joysticks and buttons.
 - Work the cover down over the handles of the controller, ensuring a snug fit.
 - Adjust the cover to ensure all buttons, triggers, ports (such as the headset jack and charging port), and the battery compartment are accessible and not obstructed.
3. **Install the Thumb Grips:**
 - Select your preferred type of thumb grip from the 4 available styles.
 - Carefully place each thumb grip over the top of the controller's analog sticks.
 - Press down firmly and rotate slightly to ensure the grip is securely seated and does not slip during use.



Image: Front view of the RALAN silicone controller cover installed on an Xbox One controller.



Image: Side view showing port access with the silicone cover installed.



Image: Back view illustrating access to the battery compartment.

OPERATING INSTRUCTIONS

The RALAN silicone controller cover is designed to enhance your gaming experience by providing improved grip and protection.

- **Enhanced Grip:** The anti-slip silicone material provides a comfortable and secure grip, reducing the chance of the controller slipping from your hands, especially during intense gaming sessions or with sweaty hands.
- **Controller Protection:** The cover acts as a protective layer against scratches, minor impacts, and everyday wear and tear, helping to preserve the original condition of your Xbox One controller.
- **Ergonomic Comfort:** The soft-touch silicone material offers an ergonomic feel, making long gaming sessions more comfortable.

MAINTENANCE AND CARE

To ensure the longevity and cleanliness of your RALAN controller skin, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the silicone cover with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth and air drying.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the silicone material and its finish.
- **Storage:** When not in use, store the controller with the skin in a clean, dry place away from direct sunlight or extreme temperatures.

TROUBLESHOOTING

If you encounter any issues with your RALAN controller skin, please refer to the following common solutions:

- **Cover Obstruction:** If buttons, ports, or the battery compartment are obstructed, gently adjust the silicone cover to ensure all openings are properly aligned. The cover is designed to fit precisely, but minor adjustments may be needed after initial installation.
- **Loose Thumb Grips:** If thumb grips feel loose or fall off during gameplay, ensure they are fully seated onto the analog sticks. Press down firmly and rotate to secure them. If they continue to be loose, they may not be compatible with your specific analog stick design or may have stretched over time.
- **Charging Issues with Dock:** If you use a charging dock, you may need to remove the silicone cover before placing the controller on the dock. Some docks require direct contact with the controller's charging points, which the cover might obstruct.
- **Skin Slippage:** If the skin feels like it's slipping on the controller, ensure it is clean and dry. Over time, silicone can stretch slightly. Re-adjust the cover for a tighter fit.

SPECIFICATIONS

Brand	RALAN
Model Number	Xone
Compatible Devices	Xbox One Wireless/Wired Gamepad
Material	100% Silicone
Product Dimensions	1.18 x 5.59 x 7.48 inches
Item Weight	2.12 ounces
Form Factor	Cover
Shell Type	Soft

WARRANTY AND SUPPORT

RALAN stands behind the quality of its products. If you are not satisfied with your silicone controller skin for any reason, you may be eligible for a refund or replacement within 30 days of purchase, in accordance with the return policy. For further assistance or inquiries, please contact RALAN customer support through your original point of purchase.

PRODUCT VIDEOS

There are currently no official seller-provided product videos available for this item.

