

[Manuals.plus](#) /

> [Atyhao](#) /

> Atyhao V6 Series Vacuum Cleaner Main Brush (185mm) Instruction Manual

Atyhao V6 Series



Atyhao V6 Series Vacuum Cleaner Main Brush (185mm)

INSTRUCTION MANUAL

1. Introduction

This manual provides essential information for the installation, operation, and maintenance of your Atyhao 185mm Main Brush for V6 Series Vacuum Cleaners. Please read these instructions carefully to ensure proper use and longevity of the product.

2. Product Overview

The Atyhao Main Brush is a replacement roller designed for specific V6 Series vacuum cleaner models. It features an anti-winding design to efficiently sweep dust into the vacuum's dust box. Constructed from high-quality, wear-resistant materials, it is designed to be gentle on floors while providing effective cleaning.






Image 1: The Atyhao 185mm Main Brush for V6 Series Vacuum Cleaners, featuring a red plastic core with black and purple bristles.

3. Compatibility and Verification

This main brush is specifically designed for V6 Series Vacuum Cleaners and has a length of **185mm (approximately 7.3 inches)**. It is crucial to verify the length of your existing brush before purchase and installation, as V6 Series vacuum cleaners may use different brush lengths (short and long versions exist). Incorrect length will prevent proper fit and function.




Image 2: The main brush shown with a measurement indicating its approximate length of 185mm (7.3 inches).

New and old models are shipped randomly




Image 3: Comparison illustrating potential variations between "New Type" and "Old Type" main brushes. Ensure your vacuum's brush head is compatible with the 185mm version.

4. Installation Instructions

1. **Preparation:** Ensure your vacuum cleaner is turned off and unplugged from the power source before beginning installation.
2. **Remove Old Brush:** Locate the brush head on your V6 Series vacuum. Follow your vacuum's specific instructions to open the brush head compartment and remove the existing main brush.
3. **Transfer Metal Cylinder: Important:** The Atyhao replacement brush does not include the internal metal cylinder. Carefully remove the metal cylinder from the end of your old brush and insert it into the corresponding slot on the new Atyhao main brush. This component is essential for the brush to spin correctly.
4. **Insert New Brush:** Align the new Atyhao main brush, with the metal cylinder installed, into the brush head compartment. Ensure it seats properly.
5. **Secure Brush Head:** Close and secure the brush head compartment according to your vacuum cleaner's design.
6. **Test:** Plug in and turn on your vacuum cleaner to confirm the new brush spins freely and operates correctly.



Image 4: Close-up view of one end of the main brush, showing the recess where the metal cylinder (pin) from your original brush should be inserted.



Image 5: Another close-up view of the brush end, highlighting the design for receiving the metal cylinder.



Easy to install and easy to replace

Anti-winding roller, rotating the brush to sweep the dust into the dust box.

Image 6: The main brush correctly installed within a V6 Series vacuum cleaner head, ready for use.

5. Operation

Once installed, the main brush operates automatically when the vacuum cleaner is powered on. Its rotating action helps dislodge dirt and debris from various floor surfaces, directing it into the vacuum's suction path. The anti-winding design minimizes hair and fiber entanglement, maintaining efficient cleaning performance.



Image 7: A V6 Series vacuum cleaner actively cleaning a floor, demonstrating the main brush's function in collecting debris.

6. Maintenance

- **Regular Inspection:** Periodically inspect the main brush for any accumulated hair, threads, or debris. Remove any obstructions to maintain optimal cleaning performance and prevent damage to the brush or vacuum.
- **Cleaning:** If necessary, gently clean the bristles with a soft brush or cloth. Avoid using harsh chemicals or excessive water. Ensure the brush is completely dry before re-installing.
- **Replacement:** The main brush is a wear-and-tear component. Regular replacement, as recommended by your vacuum cleaner's manufacturer or when signs of significant wear appear, can improve the overall service life and efficiency of your vacuum.

7. Troubleshooting

- **Brush Does Not Fit:**

Ensure you have the correct 185mm version. V6 Series vacuums can have different brush lengths. Double-check the length of your original brush against the 185mm specification.

- **Brush Does Not Spin:**
Verify that the metal cylinder (pin) from your original brush has been correctly transferred and inserted into the new Atyhao main brush. Without this component, the brush will not engage properly. Also, check for any obstructions (e.g., tangled hair) preventing rotation.
- **Reduced Cleaning Performance:**
Inspect the brush for excessive wear or damage to the bristles. Clean any accumulated debris. If the bristles are severely worn, consider replacing the brush.

8. Specifications

Product Name	Main Brush Roller
Brand	Atyhao
Model Compatibility	V6 Series Vacuum Cleaners
Length	Approx. 185mm (7.3 inches)
Material	High-quality, wear-resistant
ASIN	B08QR22HRM
Manufacturer	Atyhao

9. Warranty and Support

For any questions regarding this product, please refer to the seller's return policy or contact the seller directly through the platform where the purchase was made. Specific warranty information is not provided in this manual. For more products from Atyhao, please visit the [Atyhao Store](#).

© 2024 Atyhao. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question