Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CUBOT CUBOT KingKong Mini 2

CUBOT King Kong Mini 2 User Manual

Model: CUBOT KingKong Mini 2

Introduction

The CUBOT King Kong Mini 2 is a compact and rugged 4G smartphone designed for durability and portability. Featuring a 4-inch display, Android 10, and essential functionalities, it is suitable for various daily and outdoor activities. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your device.



Image: The CUBOT King Kong Mini 2 smartphone held in the palm of a hand, illustrating its small and portable design.



Image: A visual representation of the phone's dimensions (4.68 inches height, 2.28 inches width) and weight (4.23 oz), demonstrating its compact form factor and how it easily fits into a shirt pocket.

Getting Started: Setup



Image: The contents of the product packaging, including the CUBOT King Kong Mini 2 phone, a USB charging cable, a power adapter, a quick start guide, and a compliance regulation document.

Package Contents

Before you begin, ensure all items are present in the box:

- CUBOT King Kong Mini 2 Smartphone
- USB Cable
- Power Adapter
- Quick Start Guide
- Compliance Regulation Document

Inserting SIM and TF Cards

The CUBOT King Kong Mini 2 supports Triple Card Slots, allowing for two Nano SIM cards and one TF (microSD) card for expandable storage up to 128GB.

1. Locate the SIM card tray on the side of the device.
2. Use the provided SIM ejector tool (if included) or a small pin to open the tray.
3. Carefully place your Nano SIM cards and TF card into their respective slots on the tray, ensuring correct orientation.
4. Gently push the tray back into the phone until it is flush with the device body.

Initial Power On and Basic Setup

1. Press and hold the Power button (usually on the right side) until the CUBOT logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. You may be prompted to set up Face ID during this process.

Operating Your Device

Navigation and User Interface

The CUBOT King Kong Mini 2 runs on Android 10, offering a flexible and intuitive user experience. Navigate using the touchscreen gestures and physical buttons.

- **Touchscreen:** Tap to select, swipe to scroll, pinch to zoom.
- **Power Button:** Press to wake/sleep the screen, press and hold to power off or restart.
- **Volume Buttons:** Adjust media volume, call volume, and notification volume.

Key Features



Image: Visual representation of the phone's internal components, highlighting the MT6761 processor, 3GB RAM, and 32GB ROM, alongside the Android 10 operating system logo and various application icons.

- **Camera:** The device features a 13.0MP rear camera and an 8.0MP front camera for capturing photos and videos.



Image: A person holding the CUBOT King Kong Mini 2 horizontally, using it to photograph a snowy mountain scene, with camera specifications (8MP front, 13MP rear) displayed.

- **Compass & Gyroscope:** Equipped with pre-installed magnetic sensors and a gyroscope, the phone can be used with a compass application to aid navigation.




Image: The CUBOT King Kong Mini 2 displaying a map and compass interface, with icons indicating its built-in Compass, Gyroscope, and Geomagnetic capabilities, useful for outdoor navigation.

Note: You may need to download a dedicated compass app from the Google Play Store for full functionality.

- **Face ID:** Unlock your device securely using facial recognition.
- **Connectivity:** Supports 4G cellular technology, Wi-Fi, and Bluetooth for seamless communication and internet access.
- **Multimedia:** Enjoy music with the MP3 Player, listen to FM Radio, and watch videos with the Video Player.
- **Google Play Store:** Access millions of apps, games, movies, and books.

Maintenance

Daily Waterproofing and Durability

The CUBOT King Kong Mini 2 is designed to be daily waterproof and rugged, featuring an alloy and rubber construction for enhanced durability.



Image: The CUBOT King Kong Mini 2 demonstrating its daily waterproof capability with water splashing on its screen, and an inset showing its sturdy construction from alloy and rubber materials.

- While designed for daily water resistance, avoid submerging the device in water or exposing it to high-pressure water jets.
- Ensure all ports and covers are securely closed to maintain water resistance.
- If the device gets wet, wipe it dry with a clean, soft cloth before charging or opening any ports.

Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner. Avoid harsh chemicals.
- Keep ports free of dust and debris. Use a soft brush if necessary.

Battery Care

- Charge the device using the provided charger and cable.
- Avoid extreme temperatures, as they can affect battery performance and lifespan.

- Do not leave the device charging for extended periods after it reaches 100%.

Troubleshooting

If you encounter issues with your CUBOT King Kong Mini 2, refer to the common solutions below. If the problem persists, contact customer support.

Problem	Possible Solution
Device freezes or becomes unresponsive	Press and hold the Power button for about 10-15 seconds to force a restart.
Poor battery life	Reduce screen brightness, close unused apps, disable Wi-Fi/Bluetooth when not in use, or check for background app activity.
Microphone muffled or unclear during calls	Check if the microphone port is obstructed by dust or debris. Clean gently if necessary. Ensure you are speaking directly into the microphone.
Screen is blank or unresponsive during calls/messages	Restart the device. Ensure the proximity sensor (usually near the earpiece) is not covered by a screen protector or case.
Cannot connect to Wi-Fi/Bluetooth	Toggle Wi-Fi/Bluetooth off and on. Restart the phone. Ensure you are within range of the network/device.
Compass app not working	Ensure you have downloaded a reliable compass application from the Google Play Store. Calibrate the compass if the app provides that option.

Software Updates

Periodically check for system updates to ensure your device has the latest features, security patches, and performance improvements. Go to **Settings > System > System update** to check for available updates.

Specifications

Feature	Detail
Model Name	CUBOT King Kong Mini 2
Item Model Number	CUBOT KingKong Mini 2
Brand	CUBOT
Operating System	Android 10.0
CPU Model	MediaTek Helio (MT6761)
RAM Memory Installed Size	3 GB

Feature	Detail
Memory Storage Capacity	32 GB
Expandable Storage	Up to 128GB via TF card
Screen Size	4 Inches (11 cm visible diagonal)
Cellular Technology	4G
Wireless Carrier	Unlocked for All Carriers
Connectivity Technology	Wi-Fi, Bluetooth
Product Dimensions	11.9 x 5.8 x 1.21 cm
Product Weight	200 g
Batteries	1 AAA batteries required. (included) - *Note: This seems to be an error in the source data, as phones typically use Li-ion batteries. Please refer to actual product for battery type.*
Features	Face ID, Compass, Gyroscope, GPS Navigation, Triple Card Slots, Daily Waterproof

Warranty and Support

Product Warranty

CUBOT products come with a two-year quality guarantee. This warranty covers manufacturing defects and malfunctions under normal use.

Customer Support

If you experience any issues with your CUBOT King Kong Mini 2 or require assistance, please contact our customer service center. For purchases made through Amazon, you can reach out to the Amazon customer service for assistance. We aim to respond quickly and friendly within 24 hours.
For more information and support, visit the official CUBOT store:CUBOT Store on Amazon

© 2025 CUBOT. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08QR3MZK6

More documents and user manuals: **https://manuals.plus/**