Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Forte /
- > Forte TEZAUR Computer Desk Model TZRB214B3-Z113 Instruction Manual

Forte TZRB214B3-Z113

Forte TEZAUR Computer Desk Model TZRB214B3-Z113 Instruction Manual

Comprehensive guide for assembly, operation, maintenance, and troubleshooting.

1. PRODUCT OVERVIEW

The Forte TEZAUR Computer Desk is designed to provide a functional workspace with integrated features. It includes an elevated monitor shelf, a metal headphone holder, a cup holder, and cable management openings. The desk features integrated LED lighting with adjustable colors, powered via USB. An additional storage unit with open compartments can be positioned on either the left or right side of the main desk.



Image 1.1: Overview of the Forte TEZAUR Computer Desk with its integrated features.

2. SAFETY WARNINGS

Attention: This desk requires assembly. Please follow all instructions carefully and use appropriate tools. Ensure the desk is fully assembled and stable before placing any items on it or using it. Failure to do so may result in injury or damage to the product.

- Always assemble the desk on a soft, clean surface to prevent scratches.
- It is recommended that two adults assemble this product.
- Do not overtighten screws, as this may damage the material.
- Keep small parts and packaging materials away from children.
- · Verify all components are present before beginning assembly.

3. SETUP AND ASSEMBLY INSTRUCTIONS

Please review all steps before beginning assembly. Ensure you have sufficient space and the necessary tools (e.g., screwdriver, hammer).

3.1 Component Identification

Unpack all components and identify them against the parts list provided in your packaging. Familiarize yourself with the different panels and hardware.

3.2 Main Desk Assembly

- 1. Begin by assembling the main desk frame according to the provided diagrams. Attach the side panels to the main desktop using the designated hardware.
- 2. Secure the back panel to enhance stability.
- 3. Install the elevated monitor shelf onto the main desktop. Ensure it is securely fastened.

3.3 Storage Unit Assembly and Placement

The additional storage unit can be mounted on either the left or right side of the main desk, offering flexibility to suit your space and preference.




Image 3.1: The storage unit can be configured on either the left or right side of the desk.

- 4. Assemble the storage unit's frame and internal shelves.
- 5. Attach the assembled storage unit to the main desk structure on your preferred side (left or right) using

the provided connectors.

3.4 Attaching Accessories

6. Attach the metal headphone holder and cup holder to the underside of the desk. These are typically clamp-on designs.



Image 3.2: Detail of the headphone holder attachment.



Image 3.3: Headphone and cup holder in position.

3.5 LED Lighting Installation

- 7. Carefully place the LED strip into the designated channel on the elevated monitor shelf.
- 8. Connect the LED strip's USB cable to a compatible USB power source (e.g., computer, USB wall adapter).

3.6 Cable Management

Utilize the cable grommets and openings on the desk surface and back panel to route and organize your cables, maintaining a tidy workspace.




Image 3.4: Cable grommet for organized cable routing.

4. OPERATING INSTRUCTIONS

4.1 LED Lighting

The integrated LED lighting is powered via a USB connection. Once connected, use the provided remote control to turn the lights on/off and change colors. Refer to the remote control's specific instructions for detailed functionality.

4.2 Headphone and Cup Holder

The detachable headphone and cup holders can be positioned as desired along the desk edge. Ensure they are securely clamped before use to prevent items from falling.

5. MAINTENANCE

5.1 Cleaning

To clean the desk surfaces, use a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish. Wipe spills immediately.

5.2 Stability Check

Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain the desk's stability.

6. TROUBLESHOOTING

6.1 LED Lights Not Working

- Ensure the USB cable is securely connected to a functioning USB power source.
- Check the remote control battery and replace if necessary.
- Verify the LED strip is correctly seated in its channel.

6.2 Desk Instability

- Check all assembly screws and tighten any that are loose.
- Ensure the desk is placed on a level surface.
- Verify that all components are correctly assembled according to the instructions.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Forte
Model Number	TZRB214B3-Z113
Color	Black Matt
Dimensions (L x W x H)	200 cm x 125.4 cm x 91.1 cm (78.7 in x 49.4 in x 35.9 in)
Material	Engineered Wood, Metal, Melamine
Item Weight	86.2 kg (190 lbs)
Special Features	Elevated Monitor Shelf, Ergonomic Design, Cup Holder, Headphone Holder, LED Lighting (USB, color changeable)
Max Load - Tabletop	40 kg (88 lbs)
Max Load - Monitor Shelf	10 kg (22 lbs)
Max Load - Storage Compartment	5 kg (11 lbs)




Image 7.1: Detailed dimensions and maximum load capacities of the desk.

8. WARRANTY AND SUPPORT

This product is covered by a manufacturer's warranty. Please refer to your purchase documentation for specific warranty terms and conditions. Spare parts availability is typically 2 years from the date of purchase. For technical assistance, missing parts, or warranty claims, please contact your retailer or the Forte customer support directly. Keep your proof of purchase handy when contacting support.

© 2023 Forte. All rights reserved.

Related Documents - TZRB214B3-Z113



Assembly Instructions for TZRB219B3 Gaming Desk

Detailed assembly guide for the TZRB219B3 gaming desk by FORTE, including parts list, step-by-step instructions, and care guidelines.

