

[Manuals.plus](#) /

› [Shark](#) /

› Shark VM252P10 VACMOP Pro Cordless Hard Floor Vacuum Mop with LED Headlights Instruction Manual

Shark VM252P10

Shark VACMOP Pro Cordless Hard Floor Vacuum Mop

MODEL: VM252P10

Brand: Shark

Introduction

The Shark VACMOP Pro cordless hard floor system is designed for efficient cleaning, combining powerful vacuum suction with spray mopping in one convenient unit. It utilizes innovative all-in-one disposable pads to vacuum and lock away debris, preventing messes from being pushed around. This manual provides essential information for setting up, operating, and maintaining your VACMOP Pro to ensure optimal performance.

Key Features

- **Complete Clean:** Powerful suction combined with spray mopping for a thorough clean in one pad.
- **Disposable Pads:** VACMOP Pads vacuum up debris and absorb messes, designed for single use.
- **Powerful Suction:** Effectively pulls in dirt and debris, locking it directly into the disposable VACMOP Pad.
- **Cleaning Solution:** Spray mop with VACMOP spring clean floor cleaner to tackle stuck-on grime, leaving floors shiny.
- **No-Touch Disposal:** Remove dirty pads with a simple button press, eliminating direct contact with messes.
- **Easy Maintenance:** No filter or complex maintenance required; simply replace the disposable pad.
- **Cordless Operation:** Powered by a rechargeable lithium-ion battery for convenient, on-the-go cleaning.
- **Lightweight Design:** Weighs under 5 lbs, making it easily portable.
- **LED Headlights:** Powerful LED headlights reveal hidden debris in dark areas.
- **Included Accessories:** Vacmop unit, charger, 12 disposable pads, and one 12 oz. cleaning solution bottle.

Setup

1. Assembly



The Shark VACMOP Pro typically arrives in a few main components: the main body, the handle, and the cleaning head. Align the handle with the main body and push until it clicks securely into place. Attach the cleaning head to the bottom of the main body, ensuring a firm connection.

2. Charging



Before first use, fully charge the VACMOP Pro. Locate the charging port on the back of the main unit. Insert the charger plug and connect to a power outlet. The LED indicator light will show charging status (e.g., blinking while charging, solid when fully charged). A full charge typically takes a few hours.

3. Filling Cleaning Solution

PROFESSIONAL

Shark
VACMOP™

- ✓ **LIGHTWEIGHT**
- ✓ **NO-TOUCH
DISPOSAL**



To fill the solution tank, locate the fill cap on the top of the main unit. Open the cap and pour Shark VACMOP cleaning solution into the tank, up to the 'MAX FILL' line. Close the cap securely.

4. Attaching Disposable Pad



Place a new disposable VACMOP pad flat on the floor. Align the VACMOP head over the pad and press down firmly until the pad clicks into place. Ensure the pad is securely attached to cover the vacuum slot and spray nozzles.

Operating Instructions

1. Powering On/Off

Press the power button located on the handle to turn the VACMOP Pro on or off. The LED headlights will illuminate when the unit is powered on.

2. Vacuuming Dry Debris

POWERED BY

VACMOP™ PAD



**VACUUMS UP WHAT OTHER
PADS PUSH AROUND**

For dry debris, simply push the VACMOP Pro forward over the area. The powerful suction will draw dirt and debris into the integrated dirt chamber within the disposable pad. The LED headlights will help illuminate hidden debris.

3. Spray Mopping Wet Messes

INCLUDES

12 VACMOP™ Pads
and
12oz. VACMOP™
Multi-Surface
Cleaner



To spray mop, press and hold the spray button on the handle. Move the VACMOP Pro over the floor to clean wet messes and stuck-on grime. The cleaning solution will be dispensed, and the disposable pad will absorb the liquid.


4. Using LED Headlights



The integrated LED headlights automatically illuminate when the unit is powered on, providing visibility for cleaning in dimly lit areas or under furniture.

Maintenance

1. Disposing of Pads



To dispose of a dirty pad, position the VACMOP Pro over a trash can. Press the pad release button (usually a green lever on the side of the cleaning head) to detach the pad without touching it. Discard the used pad.

2. Cleaning the Unit

After each use, empty any remaining cleaning solution from the tank. Wipe down the exterior of the unit with a damp cloth. Periodically check the cleaning head for any debris accumulation and remove as necessary. The brush roll is designed to be self-cleaning, but inspect it for any wrapped hair or debris.

Troubleshooting

- **No Power:** Ensure the unit is fully charged. Check the charger connection and power outlet.
- **No Spray:** Verify the solution tank is filled with Shark VACMOP cleaning solution. Check if the spray nozzle is clogged.
- **Poor Suction:** Ensure the disposable pad is correctly attached and not overly saturated. Replace the disposable pad if it is full of debris.
- **Unit Not Charging:** Confirm the charger is properly connected to both the unit and a working power outlet. Check for any damage to the charger cable or port.

Specifications

- **Model Number:** VM252P10
- **Brand:** Shark
- **Color:** Charcoal Grey
- **Head Material:** Microfiber
- **Item Weight:** 3.3 pounds
- **Product Dimensions:** 5.4 x 9.5 x 47.9 inches
- **Batteries:** 1 Lithium Ion batteries required (included)
- **Handle Material:** Plastic
- **Surface Recommendation:** Hard Floor

Official Product Video

Your browser does not support the video tag.

This video provides an overview of the Shark VACMOP Pro Cordless Hard Floor Vacuum Mop, demonstrating its features and ease of use for cleaning various hard floor messes.

Warranty and Support

For detailed warranty information, product registration, or further customer support, please refer to the official Shark website or contact their customer service department. It is recommended to keep your purchase receipt as proof of purchase for any warranty claims.