

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Adesso](#) /

› [Adesso Barton Floor Lamp \(Model SL1166-21\) - Instruction Manual](#)

Adesso SL1166-21

Adesso Barton Floor Lamp (Model SL1166-21) - Instruction Manual

Model: SL1166-21 | Brand: Adesso

1. PRODUCT OVERVIEW

The Adesso Barton Floor Lamp, Model SL1166-21, is designed to provide adjustable lighting with a modern farmhouse aesthetic. Featuring an antique brass finish and an oatmeal linen fabric shade, this lamp offers both functionality and style. Its height can be adjusted from 57 to 65.5 inches to suit various spaces.



Image 1: The Adesso Barton Floor Lamp, showcasing its antique brass finish and oatmeal linen shade.

2. SAFETY INFORMATION

- Ensure the lamp is unplugged before assembly, cleaning, or bulb replacement.
- This product is UL or ETL listed, indicating compliance with government-regulated safety standards for the USA.
- Do not exceed the maximum wattage specified for the bulb.
- Keep the lamp away from water and moisture. This product is not waterproof.
- Place the lamp on a stable, level surface to prevent tipping.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Lamp Base
- Lower Pole Section
- Adjustable Pole Section with Decorative Joint
- Upper Pole Section with Socket
- Oatmeal Linen Fabric Shade
- Shade Ring (pre-attached to socket)
- Finial

4. SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Adesso Barton Floor Lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Lower Pole to Base:** Screw the lower pole section clockwise into the lamp base until secure. Ensure the power cord is not twisted.



Image 2: Detail of the sturdy antique brass base, showing the connection point for the lamp pole.

3. **Connect Adjustable Pole:** Screw the adjustable pole section onto the lower pole section.
4. **Connect Upper Pole:** Screw the upper pole section (with the socket) onto the adjustable pole section. Gently pull any excess cord through the base as you assemble to ensure a snug fit and prevent tangling.
5. **Attach Shade:** Unscrew the shade ring from the lamp socket. Place the oatmeal linen fabric shade onto the socket, ensuring it rests evenly. Screw the shade ring back onto the socket to secure the shade.



Image 3: The oatmeal linen fabric shade attached to the lamp socket, secured by the shade ring.

6. **Install Bulb:** Insert one E26 Medium base bulb (not included) into the lamp socket. Do not exceed 100 watts. LED bulbs are recommended.
7. **Adjust Height:** Loosen the decorative joint on the pole to adjust the lamp's height between 57 and 65.5

inches. Tighten the joint firmly once the desired height is achieved.



Image 4: The decorative joint on the lamp pole, used for height adjustment.

8. **Plug In:** Plug the lamp into a standard electrical outlet.

5. OPERATING INSTRUCTIONS

The Adesso Barton Floor Lamp is operated using a rotary switch located on the socket.

- **To Turn On:** Rotate the switch clockwise until you hear a click and the light illuminates.
- **To Turn Off:** Rotate the switch counter-clockwise until you hear a click and the light turns off.

6. MAINTENANCE

- **Cleaning:** Ensure the lamp is unplugged before cleaning. Wipe the metal surfaces with a soft, dry cloth. For the fabric shade, use a lint roller or a soft brush to remove dust. Do not use abrasive cleaners or polishes.
- **Bulb Replacement:** Always unplug the lamp before replacing the bulb. Allow the old bulb to cool completely before removing it. Screw in a new E26 Medium base bulb, ensuring it does not exceed 100 watts.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Lamp not plugged in. Bulb is loose or burnt out. Power outlet is not functioning. Rotary switch is faulty.	Ensure the power cord is securely plugged into a working outlet. Tighten the bulb or replace it with a new one. Test the outlet with another appliance. Contact customer support if the switch is suspected to be faulty.
Lamp flickers.	Loose bulb connection. Incorrect bulb type or wattage.	Tighten the bulb. Ensure the bulb is an E26 Medium base and does not exceed 100 watts.
Height adjustment mechanism is loose.	Decorative joint not tightened sufficiently.	Firmly tighten the decorative joint after adjusting the height.

8. SPECIFICATIONS

Feature	Detail
Model Name	SL1166-21
Brand	Adesso
Finish Type	Antique Brass
Product Dimensions	16"D x 16"W x 65.5"H (maximum)
Adjustable Height	57 - 65.5 inches
Item Weight	14.7 Pounds
Base Material	Metal (60%), Fabric (30%), Electrical parts (10%)
Shade Material	Linen

Feature	Detail
Shade Color	Beige (Oatmeal)
Bulb Base	E26 Medium
Max Wattage	100 watts
Light Source Type	LED (recommended) / Incandescent
Switch Type	Rotary
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor
Certification	ETL, UL Listed
Assembly Required	Yes
UPC	798919116614

9. OFFICIAL PRODUCT VIDEO

Watch the official Adesso video for an overview of their lighting products, showcasing various styles and features.

Your browser does not support the video tag.

Video 1: Adesso Luxury Lighting - A general overview of Adesso's lighting collection, highlighting design and functionality. This video is provided by the manufacturer, Adesso.

10. WARRANTY AND SUPPORT

The Adesso Barton Floor Lamp comes with a manufacturer's warranty. For specific warranty details or technical support, please refer to the official Adesso website or contact their customer service directly.

For further assistance, please visit the [Adesso Store on Amazon](#) or the manufacturer's official website.

© 2023 Adesso. All rights reserved. This manual is for informational purposes only.