

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VOYEE](#) /

› [VOYEE Xbox Controller Rechargeable Battery Pack and Fast Charging Station User Manual HHC-X1035](#)

## VOYEE HHC-X1035

# VOYEE Xbox Controller Rechargeable Battery Pack and Fast Charging Station User Manual

Model: HHC-X1035

## 1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- This product is designed for indoor use only.
- Do not expose the charging station or batteries to water, moisture, or extreme temperatures.
- Do not disassemble, modify, or attempt to repair the product. Refer all servicing to qualified personnel.
- Keep out of reach of children.
- Use only the provided USB cable and a recommended 5V/1A adapter for charging.
- Avoid short-circuiting the battery terminals.
- If a battery leaks, avoid contact with skin and eyes. Rinse immediately with water and seek medical attention.
- The integrated intelligent chip provides protection against overcharging, overcurrent, overvoltage, and short circuits. However, always monitor charging.

## 2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x VOYEE Fast Charging Station
- 3 x 2600 mAh Rechargeable Battery Packs
- 1 x USB Charging Cable
- 1 x User Manual
- 1 x Packaging Box

### 3. PRODUCT OVERVIEW

The VOYEE HHC-X1035 provides a reliable power solution for your Xbox controllers, ensuring extended gameplay without interruptions.



Image: The VOYEE charging station with two batteries inserted and one spare battery, alongside a USB charging cable. The station displays green LED indicators.

#### Key Features:

- **High Capacity Batteries:** Each battery provides 2600 mAh, offering over 20 hours of gameplay per charge.
- **Fast Charging:** Charges two batteries simultaneously in approximately 2.5 hours.
- **Wide Compatibility:** Compatible with official Xbox One, Xbox One S, Xbox One X, Xbox One Elite, Xbox Series X, and Xbox Series S controllers. *Note: Not compatible with third-party controllers.*
- **Intelligent Protection:** Built-in chip protects against overcharging, overcurrent, overvoltage, and short circuits.
- **LED Indicators:** Clear LED lights show charging status.

- **Long Lifespan:** Batteries are designed for up to 3000 recharge cycles.

## Strong Compatibility

Compatible with Xbox One/S/X/Elite  
Controllers/Xbox Series X/S



Image: A diagram illustrating the strong compatibility of the VOYEE charging station and batteries with various Xbox controller models, including Xbox Series X/S, Xbox One, Xbox One S, Xbox One X, and Xbox One Elite.

## 4. SETUP INSTRUCTIONS

### 4.1 Installing Batteries into Your Controller

1. Open the battery compartment on the back of your Xbox controller.
2. Insert a VOYEE rechargeable battery pack, ensuring the positive (+) and negative (-) terminals align

correctly with the markings inside the compartment.

3. Close the battery compartment cover securely.



Image: A close-up view of an Xbox controller's battery compartment with a VOYEE rechargeable battery pack correctly installed, showing the positive and negative indicators.

## 4.2 Connecting the Charging Station

1. Connect the small end of the provided USB charging cable to the Micro-USB port on the back of the VOYEE charging station.
2. Connect the larger USB-A end of the cable to a 5V/1A USB power source (e.g., a wall adapter, computer USB port, or game console USB port).
3. The LED indicators on the charging station will briefly illuminate to confirm power connection.



Image: A close-up of the VOYEE charging station showing the Micro-USB port and a USB cable being connected, indicating the power input.

## 5. OPERATING INSTRUCTIONS

### 5.1 Charging Batteries

1. Ensure the charging station is connected to a power source.
2. Insert the VOYEE rechargeable battery packs into the designated slots on the charging station. Ensure they are seated firmly.
3. The LED indicators on the front of the charging station will show the charging status:
  - **Flashing Green:** Battery is currently charging.
  - **Solid Green:** Battery is fully charged.
4. Once fully charged, remove the batteries from the station.

# LED Indicator Light

Check the charging status at a glance



Image: The VOYEE charging station with batteries inserted, showing the LED indicators. One side displays flashing green lights (charging), and the other displays solid green lights (fully charged).

## 5.2 Using Batteries

Once charged, install the battery into your compatible Xbox controller as described in Section 4.1. The battery will provide power for your gaming sessions. When the controller's battery indicator shows low power, replace the battery with a freshly charged one and place the depleted battery back on the charging station.

## 6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your VOYEE battery pack and charging station.

- **Cleaning:** Use a soft, dry cloth to clean the charging station and batteries. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the product in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** For optimal battery life, avoid completely draining the batteries before recharging them.

---

## 7. TROUBLESHOOTING

If you encounter issues with your VOYEE product, refer to the following common solutions:

- **Batteries not charging:**
  - Ensure the USB cable is securely connected to both the charging station and the power source.
  - Verify the power source is active and providing 5V/1A output.
  - Check if the batteries are correctly seated in the charging slots.
  - Confirm the LED indicators are flashing green. If not, try a different USB cable or power adapter.
- **Short battery life:**
  - Ensure batteries are fully charged (solid green LED) before use.
  - Battery performance can decrease over time with extensive use.
  - Operating conditions and game intensity can affect battery duration.
- **Controller not recognizing battery:**
  - Ensure the battery is correctly installed in the controller's compartment.
  - Verify that your controller is an official Microsoft Xbox controller, as this product is not compatible with third-party controllers.

---

## 8. SPECIFICATIONS

Parameter	Value
Brand	VOYEE
Model Number	HHC-X1035
Battery Capacity	2600 mAh (4.9 Wh) per battery
Battery Voltage	2.4 V
Charging Output	2 x DC 3.0 V 500 mAh
Charging Time	Approx. 2.5 hours (for 2 batteries)
Input Connector	Micro-USB

Compatible Devices	Xbox One, Xbox One S, Xbox One X, Xbox One Elite, Xbox Series X, Xbox Series S Controllers (Official only)
Special Feature	Fast Charging, Intelligent Protection
Recharge Cycles	Up to 3000 times

## 9. WARRANTY AND SUPPORT

VOYEE provides a worry-free replacement warranty for this product. For any questions, concerns, or technical assistance, please contact VOYEE customer service. Our support team is available 7 days a week, 24 hours a day, to assist you.

Please refer to your purchase documentation or the VOYEE official website for specific contact details and warranty claim procedures.