

[Manuals.plus](#) /

› [Galanz](#) /

› Galanz GLR16FS2K16 Refrigerator Instruction Manual

Galanz GLR16FS2K16

Galanz GLR16FS2K16 3 French Door Refrigerator User Manual

Brand: Galanz

Model: GLR16FS2K16

INTRODUCTION

This user manual provides essential information for the safe and efficient operation, installation, and maintenance of your Galanz GLR16FS2K16 3 French Door Refrigerator. Please read this manual thoroughly before using the appliance and keep it for future reference.

The Galanz 3-Door French Door Refrigerator with Bottom Freezer & Installed Ice Maker is designed to provide optimal food preservation with convenient features. It includes humidity-controlled crisper drawers, easy-to-clean glass shelves, and an efficient ice maker.

PRODUCT OVERVIEW



Front view of the Galanz GLR16FS2K16 3 French Door Refrigerator in Stainless Steel.



The Galanz refrigerator seamlessly integrated into a modern kitchen environment.

Dimension

28.4" X 31.1" X 70.0"
(W X D X H)

Capacity

16.0 Cu.Ft

Voltage

120 Volts/ 60 Hz

Weight

187.0 lbs

Installation Type

Free Standing/ Built-in



Key dimensions of the refrigerator: 28.4" W x 31.1" D x 70.0" H, with a 16.0 Cu.Ft capacity.

SETUP AND INSTALLATION

Before installation, ensure the refrigerator is placed on a level surface and has adequate clearance for proper ventilation. Refer to the detailed dimensions provided to ensure it fits your space. This model is designed for freestanding installation.

- **Unpacking:** Carefully remove all packaging materials, including internal packing and protective films.
- **Placement:** Position the refrigerator away from direct sunlight and heat sources. Allow sufficient space around the unit for air circulation (e.g., 2 inches at the back and sides).
- **Leveling:** Adjust the leveling feet to ensure the appliance is stable and level. This is crucial for proper door alignment and operation.
- **Power Connection:** Connect the refrigerator to a dedicated 120 Volt, 60 Hz grounded electrical outlet. Do not use extension cords.
- **Initial Operation:** Allow the refrigerator to stand upright for at least 2-4 hours before plugging it in to allow refrigerants to settle.

OPERATING INSTRUCTIONS

Electronic Temperature Control

Electronic Temperature Control

Refrigerator mode 33°F to 45°F,
freezer mode -8°F to 5°F.



Frost Free

Frost will not form on your food or the
freezer's interior.



Crisper Drawer with Humidity Control


2 half width clear crisper drawers keep your fruits
and vegetables fresh longer.



The electronic temperature control panel allows precise setting of refrigerator and freezer temperatures. Also shown are the humidity-controlled crisper drawers.

The refrigerator features an electronic LED control panel for precise temperature management. The recommended temperature range for the refrigerator mode is 33°F to 45°F, and for the freezer mode, it is -8°F to 5°F. Adjust settings using the control panel located inside the fresh food compartment.

Internal Storage Features



Bright LED interior lighting enhances visibility, and the image highlights the fresh food capacity (11.15 Cu.Ft) and freezer capacity (5.06 Cu.Ft).

- **Humidity Control Crisper Drawers:** Two half-width removable crisper drawers with humidity control help keep your fruits and vegetables fresh for longer.
- **Glass Shelves:** Three full-width glass shelves provide ample storage and are designed to slide out for easy cleaning.
- **Gallon Door Storage:** Conveniently store milk or large containers on the door shelves, freeing up valuable shelf space.
- **LED Interior Lighting:** Bright LED lights illuminate the interior, making it easy to find food and drinks.
- **Multi Air Flow:** This system circulates cold air throughout the refrigerator to maintain consistent temperatures and keep food fresh.

Bottom-Mount Freezer with Ice Maker



Bottom-mount Freezer

The built-in ice maker makes 3 lbs. of cubed ice daily so you're ready for entertaining.



The bottom-mount freezer features an installed ice maker and two full-width storage drawers for organized frozen food storage.

- **Ice Maker:** The installed ice maker produces approximately 3 lbs of cubed ice daily. Ensure the water supply is connected for ice production.
- **Full-Width Freezer Drawers:** Two full-width storage drawers maximize freezer space and allow for easy organization of frozen groceries, including large items.
- **Slide Rails:** The freezer drawers operate on smooth slide rails for easy opening and closing.

MAINTENANCE

- **Cleaning:** Regularly clean the interior and exterior surfaces with a mild detergent and warm water. Wipe dry with a soft cloth. Avoid abrasive cleaners or solvents.
- **Glass Shelves:** The glass shelves can be removed and wiped clean in case of spills.
- **Condenser Coils:** Periodically clean the condenser coils located at the back or bottom of the refrigerator to ensure efficient operation.
- **Door Gaskets:** Inspect and clean door gaskets regularly to ensure a tight seal, which helps maintain

temperature and energy efficiency.

- **Defrosting:** This refrigerator features an automatic defrost system, eliminating the need for manual defrosting.

TROUBLESHOOTING

Before contacting customer service, please refer to the following common issues and their potential solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; temperature control set to OFF.	Ensure plug is secure; reset circuit breaker; set temperature control to desired setting.
Temperature is too warm.	Door opened too frequently; large amount of warm food added; poor air circulation.	Minimize door openings; allow food to cool before placing inside; ensure proper spacing for air flow.
Unusual noises.	Unit not level; objects vibrating against the refrigerator; normal operating sounds.	Adjust leveling feet; move objects away from the unit; gurgling/hissing sounds are normal.
Ice maker not producing ice.	Water supply not connected or turned off; ice maker switch off; clogged water filter.	Check water line connection and valve; ensure ice maker switch is ON; replace water filter if applicable.

SPECIFICATIONS

Feature	Detail
Brand Name	Galanz
Model Info	GLR16FS2K16
Item Weight	187 pounds
Product Dimensions	31.1 x 28.3 x 70 inches (D x W x H)
Capacity	16 Cubic Feet
Annual Energy Consumption	572 Kilowatt Hours Per Year
Freezer Capacity	5.06 Cubic Feet (Fresh Food Capacity: 11.15 Cubic Feet)
Installation Type	Freestanding
Color	Stainless Steel
Voltage	120 Volts
Number Of Doors	3 (French Door)
Defrost System	Automatic

Feature	Detail
Shelf Type	Glass (3 shelves)
Crispers/Drawers	2
Special Features	Low Noise
Certification	CSA, DOE

WHAT'S IN THE BOX

- 1 x Galanz GLR16FS2K16 Refrigerator
- 3 x Glass Shelves
- User Manual (this document)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Galanz website. Keep your proof of purchase for any warranty claims. Typical protection plans are available for 2-Year and 3-Year durations. Customer support is available for assistance with product inquiries or issues.