

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [DORTALA](#) /

› [DORTALA Double Camping Chair with Canopy User Manual](#)

DORTALA AU-OP70569

DORTALA Double Camping Chair with Canopy User Manual

Model: AU-OP70569

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 265 lbs per chair. Exceeding this limit may lead to instability, damage to the chair, or personal injury.
- **Stable Surface:** Always use the chair on a stable, flat, and hard surface to prevent tipping.
- **Environmental Hazards:** Avoid using the chair near open flames, extreme heat sources, or in standing water.
- **Children:** Keep children away from the chair during assembly. Supervise children when they are using the chair.
- **Inspection:** Before each use, inspect the chair for any signs of damage, loose parts, or wear. Do not use if damaged.
- **Cleaning:** Refer to the maintenance section for proper cleaning instructions.

2. PACKAGE CONTENTS

Ensure all components are present before beginning assembly:

- 1 x Folding Double Camping Chair with Canopy
- 1 x Carrying Bag
- 1 x User Guide (This Manual)



Image 1: The DORTALA Double Camping Chair with its integrated canopy, shown alongside its compact carrying bag. This image illustrates the main components included in the package.

3. SETUP AND ASSEMBLY

The DORTALA Double Camping Chair is designed for quick and easy setup. No tools are required for assembly.

1. **Unpack:** Remove the folded chair from its carrying bag.
2. **Unfold the Frame:** Hold the chair frame and gently pull the two sides apart. The chair will begin to unfold. Ensure all four legs are fully extended and locked into place for stability.
3. **Position the Canopy:** The canopy is integrated into the chair. Extend the canopy supports upwards and secure the canopy in the desired position. The canopy is adjustable to provide optimal shade.
4. **Verify Stability:** Before use, gently press down on the seats to ensure the chair is stable and all locking mechanisms (if any) are engaged.



Image 2: This illustration demonstrates the simple folding and unfolding mechanism of the chair, highlighting its portability and ease of setup.

4. OPERATING INSTRUCTIONS

4.1 Key Features

- **Two-Person Design:** The loveseat configuration allows two individuals to sit comfortably side-by-side.
- **Adjustable Canopy:** Provides shade and sun protection. The canopy can be adjusted to different angles (up to 170 degrees) to block sunlight effectively.
- **Integrated Cooler Bag:** Located between the two seats, this insulated bag is designed to keep beverages and small items cool.
- **Cup Holders:** Each armrest features a built-in cup holder for convenient placement of drinks.
- **Storage Pocket:** A small storage pocket is located on the front of the cooler bag, ideal for holding personal items like phones or keys.



Image 3: A detailed diagram illustrating the various functional features of the DORTALA Double Camping Chair, including the iced bag, cup holders, storage pocket, durable fabric, and solid connection points.

Camp Chair with Shade Canopy

Ours

Reinforced Tube to Guarantee Safety



Others

Normal Steel Tube



Ours

Extra Supporting Tubes with Strong Weight Capacity



Others

No Supporting Tubes & Weak Weight Capacity



Image 4: This graphic demonstrates the sun protection capability of the adjustable canopy, showing its 170-degree range of motion to adapt to different sunlight directions.

4.2 Usage Scenarios

This chair is versatile and suitable for a variety of outdoor and indoor settings:

- Camping and Picnics
- Beach outings
- Fishing trips
- Outdoor concerts and festivals
- Backyards, patios, and balconies



Image 5: The double camping chair positioned in a garden setting, demonstrating its suitability for various outdoor environments.



Sun Protection

Providing you with cool shade on hot days
Adjustable canopy adapts to different sunlight directions




Image 6: Two individuals enjoying the double camping chair on a scenic wooden deck by the ocean, highlighting its comfort and suitability for relaxation.

4.3 Construction and Durability

The DORTALA Double Camping Chair is built with a focus on durability and stability, featuring a reinforced steel frame and robust fabric.

- **Reinforced Steel Frame:** The chair utilizes a powder-coated steel frame with extra supporting tubes to ensure high strength and stability, capable of supporting the stated weight capacity.
- **Durable Oxford Fabric:** The seating material is made from 600D Oxford fabric, known for its fade resistance, breathability, and puncture resistance, ensuring long-term outdoor use.



Image 7: A visual comparison highlighting the reinforced tube structure and extra supporting tubes of the DORTALA chair's frame, emphasizing its superior stability and weight capacity compared to standard designs.

5. MAINTENANCE

Proper care will extend the life of your DORTALA Double Camping Chair.

- **Cleaning:** Wipe the fabric and frame clean with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Ensure the chair is completely dry before folding and storing to prevent mold or mildew.
- **Storage:** Store the chair in its carrying bag in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically check all bolts, screws, and fabric for wear and tear. Tighten any loose fasteners.

6. TROUBLESHOOTING

If you encounter any issues with your DORTALA Double Camping Chair, please refer to the following common solutions:

Problem	Possible Cause	Solution
Chair feels unstable.	Not fully unfolded; uneven ground; loose connections.	Ensure all legs are fully extended and locked. Move to a flat, stable surface. Check for and tighten any loose bolts.
Canopy does not stay in position.	Canopy supports not fully extended or secured.	Ensure canopy supports are fully extended and clicked into their locking positions.
Difficulty folding the chair.	Frame parts are misaligned or stuck.	Gently wiggle the frame while attempting to fold. Ensure no fabric is caught in the joints.

If the problem persists or if you encounter issues not listed here, please contact DORTALA Customer Support.

7. SPECIFICATIONS

Attribute	Detail
Brand	DORTALA
Model Name	Double Camping Chair with Canopy
Item Model Number	AU-OP70569
Color	Red
Material	Steel, Oxford Fabric
Overall Dimensions (L x W x H)	65.5" x 28.5" x 59.5"
Canopy Dimensions (L x W)	55.5" x 28.5"
Height from Ground to Armrest	25.5"
Height from Ground to Seat	18"
Net Weight	26.5 lbs
Weight Capacity (Each Chair)	265 lbs
Foldable	Yes
UPC	685764600613




Sturdy Frame



Breathable & Comfortable



Space-saving Design



Easy Transportation



Image 8: A comprehensive diagram illustrating the key dimensions of the DORTALA Double Camping Chair, including overall length, width, height, and seat/armrest heights.

8. WARRANTY AND CUSTOMER SUPPORT

8.1 Limited Warranty

DORTALA warrants this product to be free from defects in material and workmanship under normal use and service for a period specified at the time of purchase. This warranty does not cover damage resulting from misuse, abuse, accident, alteration, or unauthorized repair. Proof of purchase is required for all warranty claims.

8.2 Customer Support

For any questions, concerns, or assistance with your DORTALA Double Camping Chair, please contact our customer support team. You can find more information and contact details on the official DORTALA brand store:

[Visit the DORTALA Brand Store](#)

