Ninja JC101

Ninja JC101 Cold Press Pro Juicer Instruction Manual

Model: JC101

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- To protect against risk of electrical shock, do not immerse the motor base in water or other liquid.
- Close the anti-drip lever before juicing to prevent spills.
- Always ensure the appliance is properly assembled before operation.
- Do not process frozen fruits or vegetables, or ice.
- Always unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands and utensils out of the feed chute during operation to prevent injury or damage to the juicer.

Getting Started & Setup

Before first use, wash all parts that come into contact with food in warm, soapy water. Rinse and dry thoroughly. All parts, except the motor base, are dishwasher safe.

What's Included



Figure 1: All components included with your Ninja Cold Press Juicer Pro.

- 150-watt Motor Base with Stainless Steel Auger
- 3 Interchangeable Pulp Filters (No Pulp, Some Pulp, Lots of Pulp)
- 16oz. Juice Jug
- Large Pulp Container
- Cleaning Brush
- Tamper/Food Tray/Feed Chute

Assembly Instructions

Assemble the juicer by following these steps:

1. Place the motor base on a clean, dry, level surface.
2. Insert the auger into the motor base.
3. Select your desired pulp filter (No Pulp, Some Pulp, or Lots of Pulp) and place it over the auger.
4. Attach the feed chute assembly to the motor base, ensuring it clicks into place.
5. Position the juice jug under the juice spout and the pulp container under the pulp spout.




Figure 2: The juicer is designed for no-hassle setup.

Video Description: This video demonstrates the unboxing and assembly of the Ninja JC101 Cold Press Pro Juicer, showing all included parts and how they fit together for initial setup.

Operating Instructions

The Ninja Cold Press Juicer Pro features Cold Press Technology for maximum juice yield and vibrant colors.

Controls



Figure 3: Simple one-touch controls for Start/Stop and Reverse functions.

- **START/STOP:** Press to begin or end juicing.
- **HOLD TO REVERSE:** Press and hold to reverse the auger's direction, which can help clear clogs.

Food Preparation

For best results, prepare ingredients as follows:

- Remove skins and rinds from fruits like citrus, pineapple, mango, and melon.
- The peel or skin can remain on for ingredients such as apples, cucumbers, and carrots.
- Remove stems from fruits and vegetables.
- Remove large pits and seeds from ingredients like peaches, plums, cherries, and apricots.
- Cut ingredients into 2-inch pieces for optimal juicing.

Juicing Process

Once assembled and plugged in, press START/STOP. Slowly feed prepared ingredients into the feed chute. Use the tamper to gently push ingredients down if needed. Do not force ingredients.




Figure 4: Make your favorite fruit juices without the additives.




Figure 5: Create nutrient-rich juices made of fruits and veggies in no time.




Figure 6: Give your immune system a quick dose of vitamins and nutrients.

Video Description: This video demonstrates the juicing process with the Ninja Cold Press Juicer, showing how to feed ingredients and the resulting juice and pulp.

Video Description: This video highlights the high juice yield and easy cleanup of the Ninja Cold Press Juicer, demonstrating its efficiency in extracting juice from various produce.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your juicer.

Cleaning




Figure 7: All parts, except the motor base, are dishwasher safe.

- Unplug the juicer before cleaning.
- Disassemble all removable parts.
- All removable parts are dishwasher safe. For manual cleaning, use warm, soapy water and the included cleaning brush for hard-to-reach areas.
- Wipe the motor base with a damp cloth. Do not immerse the motor base in water.

Storage




Figure 8: The compact size fits under cabinets or can be conveniently stored away.

Store the cleaned and dried juicer in a cool, dry place. Its compact size allows for convenient storage under cabinets or in a pantry.

Troubleshooting

If you encounter any issues with your Ninja Cold Press Juicer Pro, refer to the following common problems and solutions:

- **Juicer does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check that all parts are correctly assembled and locked into place.
- **Low juice yield or wet pulp:** Ensure ingredients are cut into appropriate 2-inch pieces. Try using the 'Reverse' function to clear any clogs. Ensure the correct pulp filter is used for desired pulp level.
- **Juicer clogs frequently:** Feed ingredients slowly and do not overload the chute. Use the tamper gently to push ingredients down. Use the 'Reverse' function to clear blockages.
- **Noisy operation:** Some noise is normal during operation. If the noise is excessive or unusual, ensure all parts are securely assembled.

Specifications

Brand	Ninja
Model Number	JC101
Color	Graphite
Product Dimensions	6.89"D x 13.78"W x 14.17"H
Item Weight	8.31 pounds
Maximum Power	150 Watts
Capacity	16 ounces
Product Care Instructions	Dishwasher Safe (removable parts)
Special Feature	Manual, Cold Press Technology

Warranty & Support

The Ninja JC101 Cold Press Pro Juicer comes with a 1-year limited warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal household use.

For warranty claims, troubleshooting assistance, or to purchase replacement parts, please contact Ninja Customer Service:

- **Website:** www.ninjakitchen.com
- **Phone:** 1-877-646-5288

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question