



[Manuals.plus](#) /

› [Signstek](#) /

› Signstek High Frequency Skin Therapy Device User Manual

Signstek C

Signstek High Frequency Skin Therapy Device User Manual

Model: C

INTRODUCTION

Thank you for choosing the Signstek High Frequency Skin Therapy Device. This manual provides essential information for the safe and effective use of your device, designed for acne treatment and skin firming. Please read these instructions carefully before use and retain them for future reference.



Main product image of the Signstek High Frequency Skin Therapy Device, showcasing the main unit and several included wands.

The Signstek High Frequency Skin Therapy Device features a powerful bar and new Fluon Argon Fusion 6 applicators. These wands combine the beneficial anti-acne strength of argon and the skin-oxygenating properties of neon in a universal delivery system. They work synergistically to provide a comprehensive skin therapy experience, reducing treatment time and eliminating the need to switch between neon and argon wands.

INCLUDED COMPONENTS

- High Frequency Device Main Unit
- Power Cord
- Tongue Tube Applicator
- Bent Tube Applicator
- Comb Tube Applicator
- Y-shaped Argon Tubes Applicator
- Rod Tube Applicator (for forehead and body)

IMPORTANT SAFETY WARNINGS

- **Water Proximity:** Do not install or use this device near water or with wet hands.
- **Liquid Contact:** Ensure no liquid is poured onto the device.
- **Damage:** Unplug the power cord immediately if the device is wet, smells unusual, has fallen, is broken, or if the power cable is damaged.
- **Storage:** Store the device in a dry and clean place.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Check all parts for any signs of damage. Do not use if damaged.
3. **Connect Power:** Plug the power cord into the device and then into a suitable electrical outlet.
4. **Select Applicator:** Choose the appropriate glass electrode wand for your intended treatment area. Gently insert the wand into the device's handle. Ensure it is securely seated.

OPERATING INSTRUCTIONS

Follow these steps for safe and effective operation:

1. **Prepare Skin:** Cleanse your skin thoroughly and apply a small amount of conductive gel to the area to be treated.
2. **Select Wand:** Choose the appropriate glass electrode wand based on the treatment area and desired effect. Refer to the wand descriptions below.
3. **Power On:** Turn on the device using the power control. Start with the lowest intensity setting.
4. **Apply Wand:** Gently apply the applicator to the skin in slow, steady, circular or sweeping movements. Do not hold the wand stationary on one spot for too long.
5. **Adjust Intensity:** Gradually increase the intensity to a comfortable level. You should feel a slight tingling sensation.
6. **Treatment Duration:** Treat each area for approximately 3-5 minutes. The device is recommended for use 2 to 3 times per week.
7. **Power Off:** After completing your treatment, turn off the device and unplug it from the power outlet.
8. **Clean Up:** Remove the applicator and clean it as per the maintenance instructions.

Applicator Wands and Their Uses



Image illustrating the Mushroom, Y-Shaped, and Comb high-frequency wands. The Mushroom wand is for broad area treatment to reduce wrinkles and fine lines. The Y-Shaped wand is for neck, arm, legs, or other areas that can be treated by placing skin between the prongs. The Comb wand is designed to stimulate scalp circulation for new hair growth.

- **Mushroom Wand:** Used for broad area treatment to reduce wrinkles and fine lines on the face.
- **Y-Shaped Wand:** Ideal for treating areas like the neck, arms, and legs, where skin can be placed between the prongs for effective firming.
- **Comb Wand:** Designed to stimulate blood circulation to the scalp, promoting new hair growth and improving scalp health.



Power of Argon: anti-bacterial for acne treatment



ROD

Rod tube is for body, forehead and other broader areas.



BENT

Bent tube is for spot area treatment to reduce pimples.



TONGUE

Tongue tube is for sensitive areas, such as dark circles beneath eyes, nose or lips.

Image illustrating the Rod, Bent, and Tongue high-frequency wands. The Rod tube is for the body, forehead, and other broader areas. The Bent tube is for spot area treatment to reduce pimples. The Tongue tube is for sensitive areas, such as dark circles beneath the eyes, nose, or lips. This image highlights the anti-bacterial power of Argon for acne treatment.

- **Rod Wand:** Suitable for broader areas of the body and forehead.
- **Bent Wand:** Specifically designed for targeted spot treatment to reduce pimples and blemishes.
- **Tongue Wand:** Best for sensitive areas such as under-eye dark circles, around the nose, and lips.

SIGNSTEK'S BREAKTHROUGH FUSION WANDS

deliver the skin boosting benefits
of both elements into a universal applicator



Image illustrating the distinct benefits of Argon and Neon fusion wands. Argon is effective for natural acne treatment, reducing healing time. Neon improves blood flow by oxygenating the skin, helping to reduce fine lines over time.

The device utilizes both Argon and Neon gases within its wands. Argon is particularly effective for natural acne treatment, significantly reducing healing time. Neon works to improve blood flow by oxygenating the skin, which helps in reducing fine lines and promoting overall skin health over time.

MAINTENANCE

- **Cleaning Wands:** After each use, gently wipe the glass electrode wands with a soft, dry cloth. For deeper cleaning, you may use a mild antiseptic wipe or alcohol solution, ensuring the wand is completely dry before storage or next use.
- **Device Cleaning:** Wipe the main device unit with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the device and all wands in a dry, clean, and safe place, away from direct sunlight and extreme temperatures. Ensure wands are stored carefully to prevent breakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on or has no power.	Power cord not securely plugged in. Power outlet malfunction. Internal device fault.	Ensure the power cord is firmly connected to both the device and the wall outlet. Test the outlet with another appliance. If the device is wet, smells unusual, or appears broken, unplug immediately and discontinue use. Contact customer support if the issue persists.
No tingling sensation or weak output.	Intensity setting is too low. Applicator not properly inserted. Insufficient conductive gel.	Increase the intensity setting gradually. Ensure the glass electrode wand is fully and securely inserted into the handle. Apply a sufficient amount of conductive gel to the skin.
Glass wand breaks easily.	Improper handling or storage.	Handle glass wands with care. Store them in their protective packaging or a secure container when not in use.

SPECIFICATIONS

Brand	Signstek
Model Number	C
Power Source	Corded Electric
Package Dimensions	32.4 x 21.8 x 5.7 cm
Item Weight	830 grams
Included Components	Power Cord, Tongue Tube, Bent Tube, Comb Tube, Y-shaped Argon Tubes, Rod Tube

WARRANTY AND SUPPORT

Specific warranty information and direct customer support contact details are not available in the provided product data. Please refer to the product packaging or the retailer's website for warranty terms and customer service contact information.

VIDEO RESOURCES

No official product videos were found in the provided data. For visual guides, please check the manufacturer's official website or authorized retailer pages.

