EASINE G80

EASINE G80 Cordless Stick Vacuum Cleaner User Manual

Model: G80 | Brand: EASINE

1. Introduction

Thank you for choosing the EASINE G80 Cordless Stick Vacuum Cleaner. This lightweight and powerful vacuum is designed to provide efficient cleaning for various surfaces, including carpets and hard floors. Featuring 22Kpa max suction, a 45-minute runtime, 4-stage cyclone filtration, and a special side brush design, the G80 ensures a thorough cleaning experience. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new vacuum cleaner.

2. Setup and Assembly

Your EASINE G80 vacuum cleaner is designed for easy assembly and convenient storage. Follow these steps to set up your device.

2.1 Package Contents

Before assembly, ensure all components are present:

- Main Motor Unit
- Extension Wand
- Motorized Floor Head (with roller brush)
- 2-in-1 Suction Nozzle
- Crevice Tool
- Wall Mount / Storage Base
- Power Adapter
- User Manual



Figure 2.1: All components of the EASINE G80 Cordless Stick Vacuum Cleaner, including the main unit, various attachments, and the storage base.

2.2 Assembly

The G80 features easy assembly. Simply connect the desired attachments to the main motor unit or extension wand until they click securely into place.

Your browser does not support the video tag.

Video 2.2: This video demonstrates the easy assembly of the EASINE G80, showing how components connect and detach for versatile use.

The multifunction storage base allows for convenient storage of multiple attachments and simultaneously charges the battery.

3. Operating Instructions

Learn how to effectively use your EASINE G80 for optimal cleaning performance.

3.1 Powering On and Suction Modes

Press the power button to turn on the vacuum. The G80 provides up to 22Kpa ultra-strong suction power for deep cleaning. You can adjust the suction power as needed for different cleaning tasks.



Figure 3.1: The vacuum effectively picks up debris on hard floors, demonstrating its powerful 22Kpa suction.

3.2 Real-Time Working Status Display

The integrated LED display shows the device status at a glance. It displays the battery remaining capacity, the current suction mode (AUTO/MAX), and alerts for brush tangled or airflow clogged issues.



Figure 3.2: Close-up of the vacuum's LED display, providing real-time information on battery, mode, and potential alerts.

3.3 Specialized Cleaning Features

- **Unique Side Brush Design:** The special side brush effectively cleans along edges and corners, ensuring no dust is left behind.



Figure 3.3: The unique side brush design allows for thorough cleaning right up to edges and into corners.

- **Built-in LED Lighting:** The motorized floor head features built-in LED lights to illuminate dark areas, allowing for thorough cleaning even under furniture or in dimly lit spaces.
- **Rotatable Motorized Floor Head:** The flexible motorized floor head can smoothly clean around corners and reach under furniture, enhancing maneuverability.
- **Nylon Roller Brush:** Designed for cleaning large particles, powered by 22Kpa suction power, suitable for both hard floors and carpets.



Figure 3.4: The nylon roller brush effectively picks up various debris sizes from different floor types.

3.4 Versatile Cleaning with Attachments

The G80 can be easily converted into a handheld vacuum and used with various attachments to clean hard-to-reach areas.

- **2-in-1 Suction Nozzle:** Ideal for cleaning desks, sofas, and other surfaces.
- **Crevice Tool:** Suitable for cleaning small gaps and tight spaces, such as between couch cushions or car seats.

4. Maintenance

Regular maintenance ensures your EASINE G80 operates at peak performance and extends its lifespan.

4.1 Dust Cup Emptying

The dust cup features a simple one-touch disposal mechanism for hygienic emptying.

1. Locate the dust cup release button.
2. Press the button to open the dust cup and empty contents into a trash bin.

4.2 Filter Cleaning

The G80 utilizes a 4-stage filtration system, including a HEPA filter, Sponge Filtration, Cyclone Filtration, and Primary Filtration, to ensure fade-free suction power and expel fresh air. The filters are rewashable to maintain peak performance economically.



Figure 4.1: Illustration of the 4-stage filtration system, showing how different sizes of particles and dust are isolated and captured.

1. Remove the dust cup and separate the filter components.
2. Rinse the filters under running water until clean.
3. **Important:** Ensure all parts are totally dried before reassembling to prevent damage and maintain filtration efficiency.

4.3 Roller Brush Maintenance

The roller brush can be easily changed or cleaned to remove tangled hair or debris.

1. Locate the release tab on the side of the motorized floor head.

2. Open the cover and remove the roller brush.
3. Clean any tangled hair or debris from the brush.
4. Reinsert the clean brush and close the cover securely.

5. Troubleshooting

If you encounter any issues with your EASINE G80, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted.	Charge the vacuum fully (approx. 3.5 hours for 45 mins runtime).
Low suction power.	Dust cup is full; Filters are clogged; Airflow is blocked; Roller brush is tangled.	Empty the dust cup. Clean or wash the filters. Check for blockages in the nozzle, wand, or floor head. Clean the roller brush.
Brush not spinning.	Roller brush is tangled with hair or debris; Floor head is blocked.	Remove and clean the roller brush. Check the floor head for any obstructions.
Short runtime.	Battery not fully charged; Battery degradation over time.	Ensure the vacuum is fully charged. If battery life significantly decreases, contact customer support for potential battery replacement.

6. Product Specifications

Feature	Detail
Brand	EASINE
Model Name	G80
Special Feature	Special Side Brush Design to Clean All Corners
Filter Type	Disk (4-Stage Cyclone Filtration)
Included Components	Brush, 2-in-1 Suction Nozzle, Crevice Tool, Wall Mount
Is Cordless?	Yes
Capacity	0.65 Liters (Dust Cup)
Wattage	250 watts
Runtime	Up to 45 minutes (in normal mode)
Recommended Uses	Carpet, Hard Floors, Car, Upholstery
Form Factor	Stick
Color	White
Battery Type	Lithium-Ion (2500mAh high capacity)

Feature	Detail
Noise Level	72 dB
Item Weight	4.29 pounds
Product Dimensions	45.28 x 10.43 x 10.16 inches

7. Warranty and Support

For warranty information, technical support, or any inquiries regarding your EASINE G80 Cordless Stick Vacuum Cleaner, please visit the official EASINE store or contact customer service through the retailer where the product was purchased. You can visit the EASINE Store on Amazon for more information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question