

[Manuals.plus](#) /

› [soges](#) /

› soges 39.4-inch Kitchen Sideboard Buffet Cabinet Instruction Manual

soges WL-SZKST-DC100-1

soges 39.4-inch Kitchen Sideboard Buffet Cabinet Instruction Manual

Model: WL-SZKST-DC100-1

IMPORTANT SAFETY INFORMATION

Always follow the assembly instructions carefully to avoid injury. Use only mild cleaning solutions and avoid harsh chemicals or abrasive materials to clean the cabinet. Ensure all parts are securely fastened before use.

PRODUCT OVERVIEW

The soges 39.4-inch Kitchen Sideboard Buffet Cabinet is designed for versatile storage in various settings such as dining rooms, kitchens, or entryways. It features multiple storage shelves and two large drawers, providing ample space for dishes, dinnerware, wine cups, bottles, and other household items.

LARGE STORAGE SPACE



two large drawers

Image: Front view of the soges 39.4-inch Kitchen Sideboard Buffet Cabinet, highlighting its overall dimensions: 39.4 inches (L) x 11.8 inches (W) x 33.9 inches (H).



Image: The soges cabinet with its two drawers pulled out and the right-side cabinet door open, showcasing the internal storage capacity for various items like cups and plates.

ASSEMBLY INSTRUCTIONS

This cabinet requires assembly. Please follow the detailed instructions provided in the packaging. It is recommended to have two people for assembly to ensure stability and ease of construction.

Tools Required:

- Screwdriver (not included)
- Hammer (not included)

Step-by-Step Assembly:

1. Unpack all components and verify against the parts list in your manual.
2. Assemble the main frame of the cabinet according to the diagrams.

3. Install the drawer slides. **Important Note:** Ensure the drawer slide screws (often labeled 'E' in diagrams) are inserted into the correct hole (frequently the third hole from the front, not the second, for proper alignment and function).
4. Assemble the drawers and attach them to the installed slides.
5. Attach the cabinet doors using the provided hinges.
6. Place the shelves into the designated slots.
7. Secure all connections and ensure the cabinet is stable.



Image: Close-up view of the cabinet's drawers, illustrating the smooth slide rails for easy opening and closing.

OPERATING INSTRUCTIONS

The soges Kitchen Sideboard is designed for straightforward use. The drawers operate on smooth slide rails, and the cabinet doors open and close easily. Ensure items are placed evenly on shelves and within drawers to maintain balance and prevent tipping.

Storage Capacity:

- Two large storage shelves with doors to protect contents from dust.
- Open shelves for daily necessities or decorative items.
- Two large drawers suitable for dishes and dinnerware.



Image: The cabinet with its doors and drawers open, demonstrating the extensive storage space available for various kitchen and dining items.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your soges cabinet, follow these care guidelines:

- **Cleaning:** Wipe clean with a soft, damp cloth. Use only mild cleaning solutions. Avoid harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the high-gloss finish.
- **Spills:** Promptly wipe up any spills or water stains to prevent damage to the particle wood.
- **Placement:** Avoid placing the cabinet in direct sunlight or near heat sources to prevent warping or discoloration.
- **Stability:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.



Image: Close-up of the cabinet's desktop surface, illustrating its smooth and water-resistant properties, making it easy to clean.

TROUBLESHOOTING

If you encounter any issues during assembly or use, refer to the following common solutions:

- **Difficulty with Assembly:**

- Review the instruction manual carefully, paying close attention to diagrams for screw and part orientation.
- Ensure all parts are correctly identified and matched to the corresponding steps.
- If parts are mislabeled or missing, contact customer support.

- **Drawers Not Sliding Smoothly:**

- Check the alignment of the drawer slides on both the drawer and the cabinet frame.
- Verify that the screws securing the slides are in the correct holes and are fully tightened.
- Ensure no debris is obstructing the slide mechanism.

- **Cabinet Instability:**
 - Confirm all fasteners are securely tightened.
 - Ensure the cabinet is placed on a flat, level surface.

SPECIFICATIONS

Dimension (L x W x H)	39.4 x 11.8 x 33.9 inches
Weight	65 lbs (approximate)
Material	15mm E1 grade particle wood with high glossy finish
Color	Black + White
Storage	2 Drawers, Multiple Shelves (2 with doors, open shelves)
Assembly Required	Yes
Model Number	WL-SZKST-DC100-1

WARRANTY AND SUPPORT

soges offers friendly and reliable pre-sales and after-sales service. If you have any questions about this cabinet during assembly or usage, please feel free to contact us. We aim to reply within 24 hours.

For specific warranty details, please refer to the documentation included with your purchase or contact soges customer service directly.

© 2024 soges. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question