

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Magic Mesh](#) /
- › [Magic Mesh Personal Portable Pod Instruction Manual](#)

Magic Mesh Magic Mesh Pod

Magic Mesh Personal Portable Pod Instruction Manual

Model: Magic Mesh Pod

1. INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Magic Mesh Personal Portable Pod. This portable shelter is designed to offer a personal space with mesh walls, allowing fresh air circulation while providing protection from insects. Its pop-up design ensures quick deployment and compact storage.

2. SAFETY INFORMATION

- **Anchoring:** Ensure the pod is properly anchored in windy conditions to prevent it from being carried away or damaged.
- **Weather Conditions:** Supervise use in adverse weather. While the pod offers some protection, it is not designed for extreme weather conditions.
- **Fire Hazards:** Keep the pod away from open flames, heaters, and other fire hazards. The material is not fireproof.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, as this may degrade the material over time.
- **Children and Pets:** Always supervise children and pets when they are inside or around the pod.

3. SETUP INSTRUCTIONS

The Magic Mesh Personal Portable Pod features an easy pop-up design, requiring no assembly. Follow these steps for quick deployment:

1. **Unpack:** Carefully remove the portable pod from its carrying bag.
2. **Release:** Hold the folded pod away from your face and body. Gently release the tension, and the pod will automatically spring open into its full shape.
3. **Position:** Place the pod on a flat, stable surface.

4. **Secure (Optional):** If using outdoors or in windy conditions, use stakes (not included) through the loops at the base of the pod to secure it to the ground.

MAGIC MESH™
PORTABLE POD

NO ASSEMBLY REQUIRED!

**EASY POP
UP DESIGN**



GREAT FOR
KEEPING
PETS COOL



Image: The Magic Mesh Portable Pod demonstrating its easy pop-up design, shown outdoors with a small dog inside, highlighting its quick setup and suitability for pets.



Image: A woman seated in a folding chair inside the Magic Mesh Portable Pod, illustrating the product's intended use as a personal, bug-free outdoor space.

4. OPERATING INSTRUCTIONS

The Magic Mesh Personal Portable Pod is designed for ease of use, featuring a magnetic screen door and breathable mesh construction.

- **Magnetic Door:** The front panel features a magnetic closure system. To enter or exit, simply push through the magnetic seam. The magnets will automatically re-close behind you, maintaining the enclosed space.
- **Ventilation:** The see-through mesh material allows for continuous airflow, keeping the interior fresh and comfortable.
- **Visibility:** The 360-degree mesh provides an unobstructed view of your surroundings.
- **Shade:** The solid top panel offers shade from direct overhead sunlight.

MAGIC MESH™


PORTABLE POD

POWERFUL MAGNETIC
SCREEN DOOR FOR
EASY ENTRY



MADE
WITH
HEAVY
DUTY
MESH

MAGICALLY CLOSES



INSTANTLY OPENS

KEEP
BUGS OUT!



Image: A detailed view of the magnetic screen door mechanism, demonstrating how the magnets click together to close the opening, ensuring insect protection.

MAGIC MESH™ PORTABLE POD

360° MESH VIEW TO LET FRESH AIR IN



GREAT FOR SPORTING EVENTS,
CAMPING & OTHER
OUTDOOR ACTIVITIES



Image: A person inside the portable pod, observing an outdoor sports event, illustrating the 360-degree mesh view and its use for various outdoor activities.

5. FOLDING AND STORAGE

To fold your Magic Mesh Personal Portable Pod for compact storage, follow these steps:

1. **Collapse:** Gently push the top and bottom edges of the pod towards each other, allowing the flexible frame to collapse.
2. **Twist:** Once collapsed, twist the frame into a figure-eight shape, bringing the two large circles together to form a smaller, compact circle.
3. **Secure:** Use the elastic strap (if provided) to secure the folded pod.
4. **Store:** Place the folded pod back into its carrying bag for easy transport and storage.

MAGIC MESH™ PORTABLE POD


FOLDS FLAT FOR EASY STORAGE

Height
2.5"

Diameter
20"



Height
59"



Depth
37.4"

SOLID TOP PANEL PROVIDES SHADE

Width
37.4"

Magic Mesh™ Portable Pod Includes:

1

PORTABLE POD
WITH MAGNETIC SCREEN DOOR

(37.4in x 37.4in x 59in (95cm x 95cm x 149.8cm))
(CHAIR NOT INCLUDED)

Image: A visual representation of the portable pod folded flat, alongside its dimensions when open and collapsed, demonstrating its compact storage capability.

6. MAINTENANCE

- **Cleaning:** To clean the mesh and fabric, wipe with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before folding and storing.
- **Storage:** Store the pod in a cool, dry place, away from direct sunlight and extreme temperatures, to prolong its lifespan.
- **Inspection:** Periodically inspect the mesh, zippers (if any), and frame for any signs of wear or damage. Address minor tears in the mesh promptly using a mesh repair kit to prevent them from enlarging.
- **Magnetic Closure:** Ensure the magnetic strips are clean and free from debris to allow for proper closure. If magnets appear weak, ensure they are correctly aligned.

7. TROUBLESHOOTING

- **Pod does not pop up correctly:** Ensure all parts of the frame are free from obstructions. Gently manipulate

the frame to help it expand.

- **Magnetic door does not close completely:**

- Check for debris or fabric caught between the magnetic strips.
- Ensure the pod is placed on a level surface and is not distorted, which can misalign the magnets.
- In windy conditions, the magnets may struggle to stay closed. Consider adding extra weights or anchors to the base of the pod.

- **Difficulty folding the pod:** Refer to the folding instructions in Section 5. The twisting motion can take practice. Do not force the frame, as this may cause damage.

8. SPECIFICATIONS

Feature	Detail
Brand	Magic Mesh
Model Number	Magic Mesh Pod
Product Dimensions (L x W x H)	37.4" x 37.4" x 59" (95cm x 95cm x 149.8cm)
Item Weight	3.52 Pounds (1.6 kg)
Occupancy	1 person
Frame Material	Metal
Body Material	See-through Mesh
Assembly Required	No
Water Resistance Level	Waterproof (Top panel only; mesh is not waterproof)
UV Protection	Provides some level of UV protection through shading from the solid top panel.

9. WARRANTY AND SUPPORT

For warranty information or product support, please contact Magic Mesh customer service. Details can typically be found on the product packaging or the official Magic Mesh website. Please retain your proof of purchase for any warranty claims.