

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Brookstone](#) /

› [Brookstone 360° Spin Cosmetic Display Case Instruction Manual](#)

## Brookstone 360 Spin Cosmetic Display Case

# Brookstone 360° Spin Cosmetic Display Case Instruction Manual

Model: 360 Spin Cosmetic Display Case

## INTRODUCTION

The Brookstone 360° Spin Cosmetic Display Case is designed to help organize and store your makeup products, brushes, and other beauty accessories efficiently. Its rotating design provides easy access to all items, making it a versatile storage solution for vanities, dressing tables, or bathroom countertops.

## SETUP AND ASSEMBLY

The cosmetic display case is designed for easy assembly. Follow these steps to set up your organizer:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all pieces are present and undamaged.
2. **Assemble Trays:** Slot the individual tray pieces into the main vertical panels. The design allows for adjustable height, so you can customize each section to fit products of varying sizes.
3. **Secure Trays:** Use the provided rubber rings to secure the trays in place. These rings help maintain stability and prevent items from shifting or falling during rotation.
4. **Placement:** Position the assembled organizer on a flat, stable surface such as a vanity, dressing table, or bathroom countertop.

Brookstone®

EASY ACCESS  
TO ESSENTIALS



Noiseless



Sleek



Sturdy



Functional

Figure 1: Fully assembled Brookstone 360° Spin Cosmetic Display Case.

# FULLY CUSTOMIZABLE



Figure 2: Customizable height levels for adjustable trays.

## OPERATING INSTRUCTIONS

The Brookstone 360° Spin Cosmetic Display Case is designed for intuitive use:

- **Loading Products:** Place your makeup brushes, lipsticks, skincare bottles, and other accessories onto the adjustable trays. Utilize the customizable height levels to ensure a snug fit for items of various sizes, preventing them from moving during rotation.
- **360° Rotation:** Gently rotate the organizer to access items stored on different sides. The smooth and quiet spinning mechanism allows for easy retrieval of any product.
- **Maximizing Space:** Arrange items strategically to maximize storage capacity. Taller items can be placed in sections with higher tray settings, while smaller items fit well in lower sections.





Figure 3: Demonstrating the 360° rotation for easy access.



Figure 4: Close-up of organized cosmetic items within the display case.

## MAINTENANCE

To ensure the longevity and cleanliness of your Brookstone 360° Spin Cosmetic Display Case, follow these maintenance guidelines:

- **Cleaning:** Wipe the organizer clean with a damp cloth as needed. For stubborn stains, a mild soap solution can be used, followed by wiping with a clean, dry cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals, as these may damage the plastic material.
- **Regular Inspection:** Periodically check the rubber rings and tray connections to ensure they remain secure.

## PRODUCT FEATURES

- **360° Spin:** Provides easy access to all stored items with a smooth, quiet rotation.
- **Adjustable Trays:** Features interlocking trays that can be adjusted to various heights, accommodating different product sizes.
- **Durable Construction:** Made from high-quality, stable, and strong plastic for frequent use.
- **Secure Storage:** Rubber rings are included to keep trays secure and prevent items from falling.
- **Space-Saving Design:** Helps to tidy up and organize makeup essentials, ideal for small counter spaces.



Figure 5: Key features including raised edges, customizable trays, and rubber rings.

## SPECIFICATIONS

Feature	Detail
Brand	Brookstone

Model	360 Spin Cosmetic Display Case
Material	Plastic, Rubber
Color	Black
Special Features	360 Rotation, Adjustable Trays
Item Weight	1.85 pounds (0.84 Kilograms)
Package Dimensions	12.01 x 9.37 x 1.93 inches
Unit Count	1 Count
UPC	843620128774

---

## TROUBLESHOOTING

If you encounter any issues with your Brookstone 360° Spin Cosmetic Display Case, consider the following:

- **Organizer Not Spinning Smoothly:**
  - Ensure the base is on a completely flat and level surface.
  - Check for any debris or obstructions under the base that might impede rotation.
  - Verify that the trays are evenly loaded and not causing an imbalance.
- **Trays Not Staying Secure:**
  - Confirm that the rubber rings are correctly installed and positioned to hold the trays firmly.
  - Ensure the trays are properly slotted into the vertical panels at the desired height.
- **Items Falling Out:**
  - Adjust the tray heights to better fit your items, minimizing gaps.
  - Avoid overloading individual sections.
  - Ensure the organizer is not being spun too forcefully.

---

## OFFICIAL PRODUCT VIDEOS

No official seller videos were found for this product based on the provided data.

---

## WARRANTY AND SUPPORT

For warranty information or customer support regarding your Brookstone 360° Spin Cosmetic Display Case, please refer to the contact details provided with your purchase or visit the official Brookstone website. Keep your proof of purchase for any warranty claims.

**Return Policy:** This product typically has a 30-day return/replacement policy. Please check with your retailer for specific return terms.

---

© 2023 Brookstone. All rights reserved.