Nokia TA-1316

Nokia 225 Dual SIM 4G Phone User Manual

Model: TA-1316

1. Introduction

Welcome to the user manual for your Nokia 225 Dual SIM 4G phone. This guide provides comprehensive instructions to help you get started, operate, and maintain your device. Please read this manual carefully to ensure proper use and to maximize the features of your phone.

2. Safety Information

Always read these simple guidelines. Not following them may be dangerous or illegal.

- **Switch off in restricted areas:** Switch the device off when mobile phone use is not allowed or when it may cause interference or danger, for example, in aircraft, near medical equipment, fuel, chemicals, or blasting areas.
- **Road safety comes first:** Obey all local laws. Always keep your hands free to operate the vehicle while driving.
- **Interference:** All wireless devices may be susceptible to interference, which could affect performance.
- **Qualified service:** Only qualified personnel may install or repair this product.
- **Batteries, chargers, and other accessories:** Use only batteries, chargers, and other accessories approved by Nokia for use with this device. Do not connect incompatible products.

3. What's in the Box

Your Nokia 225 Dual SIM 4G package includes the following items:

- Nokia 225 4G Phone
- Battery (Lithium Ion)
- Micro USB Charger
- Quick Guide

4. Product Overview

Familiarize yourself with the physical components of your Nokia 225 Dual SIM 4G phone.


Vo LTE 4G
02:25
Thursday, 15.10.2020
Unlock
NOKIA
1 oo
2 abc
def 3
4 ghi
5 jkl
mno 6



Figure 4.1: Front View. This image displays the front of the Nokia 225 phone, highlighting its 2.4-inch display, navigation keys, and alphanumeric keypad. The screen shows the time and date, along with network and battery indicators.





Figure 4.2: Angled Front View. An angled perspective of the Nokia 225, providing a better sense of its slim profile and the tactile nature of its physical buttons.





Figure 4.3: Side View. This image shows the side profile of the Nokia 225, emphasizing its compact and ergonomic design.





Figure 4.4: Back View. The rear of the Nokia 225, featuring the camera lens and the Nokia brand logo.

5. Setup

5.1. Inserting the SIM Card(s)

Your Nokia 225 supports Dual SIM functionality. To insert the SIM cards:

1. Carefully remove the back cover of the phone.
2. Locate the SIM card slots.
3. Insert your SIM card(s) into the designated slots, ensuring the gold contacts face downwards.
4. Gently push the SIM card until it clicks into place.

5.2. Inserting the Battery

After inserting the SIM cards, install the battery:

1. Align the battery contacts with the contacts in the phone's battery compartment.
2. Press the battery down gently until it is securely in place.
3. Replace the back cover, ensuring it snaps firmly into position.

5.3. Charging the Battery

Before first use, fully charge the battery:

1. Connect the micro USB charger to the charging port on your phone.
2. Plug the charger into a wall outlet.
3. The battery indicator on the screen will show the charging status.
4. Once fully charged, disconnect the charger.

6. Operating Your Phone

6.1. Power On/Off

- To **power on**, press and hold the Power key until the phone vibrates and the screen lights up.
- To **power off**, press and hold the Power key, then select 'Power off' from the options.

6.2. Basic Navigation

Use the navigation keys and the center select key to move through menus and make selections.

- **Navigation Keys:** Use the up, down, left, and right keys to scroll through options.
- **Select Key:** Press the center key to confirm a selection or open an item.
- **Back/Clear Key:** Use to go back to the previous screen or delete characters.
- **Call Key:** Press to make a call or answer an incoming call.
- **End Key:** Press to end a call or return to the home screen.

6.3. Making Calls

1. From the home screen, enter the phone number using the keypad.
2. Press the Call key to initiate the call.
3. To end the call, press the End key.

6.4. Sending Messages

1. Go to 'Menu' > 'Messages'.
2. Select 'Create message' or 'New message'.
3. Type your message using the keypad.
4. Enter the recipient's phone number or select from contacts.
5. Select 'Send'.

6.5. Using the Camera

Your Nokia 225 features a rear camera for capturing photos.

1. From the menu, select 'Camera'.
2. Frame your shot using the screen as a viewfinder.
3. Press the center select key to take a photo.

7. Maintenance

Proper care helps extend the life of your device.

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Do not expose the battery to extreme temperatures or dispose of it in fire. Recycle batteries according to local regulations.
- **Water Resistance:** This phone is not water-resistant. Avoid exposure to liquids.

8. Troubleshooting

If you encounter issues with your Nokia 225, try these common solutions:

Problem	Possible Solution
Phone does not power on	Ensure the battery is charged. Connect the charger and try again. Check if the battery is properly inserted.
Cannot make or receive calls	Check network signal strength. Ensure SIM card is correctly inserted. Contact your network provider if the issue persists.
Poor audio quality during calls	Check network signal. Ensure nothing is blocking the earpiece or microphone.
Battery drains quickly	Reduce screen brightness. Close unused applications. Limit background data usage.
Phone freezes or is unresponsive	Remove and reinsert the battery to perform a soft reset.

9. Specifications

Key technical specifications for the Nokia 225 Dual SIM 4G phone:

Feature	Detail
Model Name	Nokia 225
Item Model Number	TA-1316
Operating System	RTOS (Series 30+)
CPU Model	Snapdragon
Cellular Technology	4G

Feature	Detail
Connectivity Technology	USB (Micro USB)
Screen Size	2.4 Inches (Visible screen diagonal: 7" / 17 cm)
Resolution	320 x 240 pixels
Memory Storage Capacity	32 GB (Internal storage, actual user storage may be less)
Battery	1 Lithium Ion battery (included)
Product Dimensions	11.5 x 6.83 x 4.04 cm; 150 g

10. Warranty and Support

For warranty information and customer support, please refer to the warranty card included in your product package or visit the official Nokia support website. Keep your proof of purchase for warranty claims.
Online Support: www.nokia.com/phones/en_gb/support

© 2024 Nokia. All rights reserved. Nokia and the Nokia Logo are trademarks of Nokia Corporation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question