

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [lingland](#) /

> [MT-033 LCD Display Portable Folding Digital Travel Alarm Clock User Manual](#)

lingland MT-033

MT-033 LCD Display Portable Folding Digital Travel Alarm Clock

Model: MT-033 | Brand: lingland

INTRODUCTION

The lingland MT-033 is a lightweight and compact digital travel alarm clock designed for portability and convenience. Its foldable cover allows it to function as a stand, making it ideal for use on desks or tables. This manual provides comprehensive instructions for setting up, operating, and maintaining your MT-033 alarm clock.



Image: The MT-033 digital alarm clock in its open, standing position, clearly displaying the time, date, and temperature on its LCD screen.

PRODUCT FEATURES

- **Portable Design:** Lightweight and compact with a foldable cover that doubles as a stand.
- **Clear LCD Display:** Large screen for easy reading of time, date, week, and temperature.
- **Alarm Function:** Features an alarm with 8 optional melodies and a snooze function.
- **Time Formats:** Supports both 12-hour and 24-hour time display modes.
- **Temperature Display:** Shows current ambient temperature in Celsius or Fahrenheit.



Image: The MT-033 digital alarm clock displaying time, date, and temperature, accompanied by icons representing its clock, snooze, alarm, date, and temperature features.

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Gently slide open the battery cover.
3. Insert one CR2025 button cell battery, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery cover securely.




Image: A detailed view of the back of the MT-033 clock, highlighting the battery compartment and the arrangement of control buttons.

2. Initial Power On

Upon successful battery installation, the LCD display will illuminate, and the clock will typically show a default time or begin flashing. You can now proceed to set the time and other functions.

OPERATING INSTRUCTIONS

The MT-033 clock features several control buttons on its back panel for various settings. Familiarize yourself with these buttons:

MODE: Used to cycle through display modes (Time, Alarm, Date) and enter setting modes.

SET: Used to confirm settings and move to the next setting parameter.

ADJ/UP: Used to increase values during setting.

DOWN/C/F: Used to decrease values during setting and to switch between Celsius and Fahrenheit temperature display.

TIMER: (Functionality not explicitly detailed, typically for countdown/stopwatch)



Image: A close-up view of the control buttons located on the rear panel of the MT-033 digital clock, including MODE, SET, ADJ/UP, DOWN/C/F, and TIMER.

1. Setting Time and Date

1. From the normal time display, press the **MODE** button repeatedly until the time digits start flashing.
2. Use the **ADJ/UP** or **DOWN/C/F** buttons to adjust the hour.
3. Press **SET** to confirm the hour and move to the minutes.
4. Use **ADJ/UP** or **DOWN/C/F** to adjust the minutes.
5. Press **SET** to confirm the minutes and move to the year.
6. Continue this process for setting the year, month, and day.
7. After setting the day, press **SET** again to exit the setting mode and return to normal time display.

2. Setting the Alarm

1. From the normal time display, press the **MODE** button once to enter alarm display mode. The alarm time will be shown.
2. Press and hold the **SET** button until the alarm hour digits start flashing.
3. Use the **ADJ/UP** or **DOWN/C/F** buttons to adjust the alarm hour.
4. Press **SET** to confirm the alarm hour and move to the alarm minutes.
5. Use **ADJ/UP** or **DOWN/C/F** to adjust the alarm minutes.
6. Press **SET** to confirm the alarm minutes. You may then be able to select an alarm melody (use ADJ/UP/DOWN to cycle through 8 options).

7. Press **SET** again to exit alarm setting mode.
8. To activate/deactivate the alarm, in alarm display mode, press **ADJ/UP** (or a dedicated alarm ON/OFF button if present) to toggle the alarm icon on or off.

3. Snooze Function

When the alarm sounds, press any button (except for the alarm off button, if separate) to activate the snooze function. The alarm will temporarily stop and sound again after a few minutes (typically 5-10 minutes). To turn off the alarm completely, press the designated alarm off button or let it ring for its full duration.

4. 12/24 Hour Mode Selection

From the normal time display, press the **ADJ/UP** button to toggle between 12-hour (with AM/PM indicator) and 24-hour time formats.

5. Temperature Display (Celsius/Fahrenheit)

From the normal time display, press the **DOWN/C/F** button to switch the temperature display between Celsius (°C) and Fahrenheit (°F).

MAINTENANCE

Cleaning

To clean the clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the display or casing.

Battery Replacement

When the display becomes dim or the clock functions erratically, it is time to replace the battery. Follow the battery installation steps outlined in the "Setup" section. Ensure you use a fresh CR2025 button cell battery.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Low or depleted battery. Incorrect battery installation.	Replace the battery with a new CR2025. Ensure the battery is inserted with correct polarity.
Clock not keeping accurate time.	Low battery.	Replace the battery. Reset the time after battery replacement.
Alarm does not sound.	Alarm is not activated. Alarm volume is too low (if adjustable).	Ensure the alarm icon is displayed on the screen. Check if there's a volume setting (though not specified for this model).
Buttons are unresponsive.	Low battery. Temporary software glitch.	Replace the battery. Remove and reinsert the battery to perform a soft reset.

SPECIFICATIONS

Feature	Detail
Brand	lingland

Feature	Detail
Model	MT-033
Display Type	Digital LCD
Power Source	Battery Powered (1x CR2025, not included)
Material	Plastic
Color	Silver
Dimensions (Folded)	Approximately 85mm x 78mm (3.35 x 3.07 inches)
Item Weight	88 Grams (3.1 ounces)
Special Features	Alarm, Snooze, Date, Week, Temperature Display (C/F), 12/24 Hour Mode, Foldable Stand



Image: The MT-033 clock in its folded, compact state, with measurements indicating its approximate dimensions of 85mm by 78mm.

WARRANTY AND SUPPORT

This product is manufactured by Lingland. For any questions, technical support, or warranty inquiries, please refer to the contact information provided with your purchase or visit the manufacturer's official website. Please retain your proof of purchase for warranty purposes.

