

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Monster](#) /

› [Monster Prolink Performer 600 Speaker Cable with Speakon Connectors, 10ft - Instruction Manual](#)

Monster P600-S-10SP WW

Monster Prolink Performer 600 Speaker Cable with Speakon Connectors, 10ft - Instruction Manual

INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Monster Prolink Performer 600 Speaker Cable. Designed for high-fidelity signal transfer, this 10-foot cable features Speakon connectors and a durable construction suitable for stage and studio environments.

PRODUCT FEATURES

- **High Performance:** Engineered with Monster's Time Correct Windings for enhanced bass response and clear signal delivery.
- **Noise Rejection:** Multi-gauge wire construction and high-purity copper conductors minimize signal interference and noise.
- **Durable Construction:** The Duraflex outer jacket resists cuts and abrasions, offering lightweight flexibility for easy handling.
- **Secure Connection:** Features custom self-locking twist-lock Speakon connectors for reliable and secure plugging and unplugging.

BUILT FOR PERFORMANCE

Get high-fidelity and clear signal transfers from your speaker system whether.



Image: Detail of the Monster Prolink Performer 600 Speakon connector, highlighting the self-lock mechanism and the Duraflex outer jacket for enhanced durability and performance.

LONG-LASTING QUALITY

Features our Duraflex outer jacket, which resists slicing and abrasions



Image: The Monster Prolink Performer 600 cable demonstrating its long-lasting quality with the robust Duraflex outer jacket.



SELF-LOCK CONNECTOR

Built with Monster's custom self-locking twist-lock connector for effortless plugging or unplugging.

Image: A close-up view of two Monster Prolink Performer 600 Speakon connectors, illustrating the self-locking twist-lock design for secure connections.

SETUP AND CONNECTION

To connect your Monster Prolink Performer 600 Speaker Cable:

1. Ensure all audio equipment (amplifier, speaker) is powered off before making connections.
2. Locate the Speakon input on your speaker and the Speakon output on your amplifier or audio source.
3. Insert one end of the Speakon connector into the corresponding port. Twist the connector clockwise until it locks securely into place. You should feel a click.
4. Repeat the process for the other end of the cable, connecting it to your amplifier or audio source.
5. Once both ends are securely connected, you may power on your audio equipment.



Image: The Monster ProLink Performer 600 Speaker Cable properly connected to a speaker output, demonstrating a secure and ready-to-use setup.

OPERATION

Once connected, the Monster ProLink Performer 600 Speaker Cable operates passively, transmitting audio signals between your amplifier and speaker. No specific operational steps are required beyond ensuring a secure connection and proper functioning of your audio equipment. Always ensure that the cable is not under excessive tension or bent sharply during use to maintain signal integrity and cable longevity.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your speaker cable:

- **Cleaning:** Wipe the cable and connectors with a soft, dry cloth to remove dust and dirt. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, coil the cable loosely. Avoid tight coiling or kinking, which can damage the internal conductors. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Always grasp the connector housing when plugging or unplugging the cable, rather than pulling on the cable itself.

- **Inspection:** Periodically inspect the cable and connectors for any signs of wear, damage, or corrosion.

TROUBLESHOOTING

If you experience issues with your audio setup, consider the following troubleshooting steps:

- **No Sound:**

- Ensure both ends of the Speakon cable are securely connected and locked.
- Verify that your amplifier and speaker are powered on and functioning correctly.
- Check the volume levels on your amplifier and audio source.
- Test with a different cable if available to rule out cable failure.

- **Intermittent Sound or Static:**

- Ensure connectors are clean and free of debris or corrosion.
- Check for any visible damage to the cable jacket or connectors.
- Ensure the cable is not running near sources of electromagnetic interference.

SPECIFICATIONS

Attribute	Detail
Brand	Monster
Model Number	P600-S-10SP WW
Cable Length	10 feet (3 meters)
Connector Type	Speakon (Male-to-Male)
Cable Type	Speaker Cable
Compatible Devices	Speakers, Amplifiers
Special Feature	Tangle Free, Time Correct Windings
Jacket Material	Duraflex
Color	Blue (connector accents)
Item Weight	1.1 pounds
Indoor/Outdoor Usage	Indoor, Outdoor



DIMENSIONS AND SPECIFICATIONS

Weight	1.15 lbs
Cable Length	3 m / 10 ft
Jacket	Duraflex

Image: Visual representation of key dimensions and specifications for the Monster Prolink Performer 600 cable, including weight, cable length, and jacket type.

WARRANTY INFORMATION

The Monster Prolink Performer 600 Speaker Cable is covered by Monster's 100% replacement guarantee, ensuring a lifetime cable warranty. For detailed terms and conditions, please refer to the official Monster warranty documentation or contact customer support.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please visit the official Monster website or contact their customer service department. Refer to the product packaging or the Monster website for the most current contact information.