

BENYAR BY-5177

BENYAR 5177 Luxury Business Mechanical Watch User Manual

Model: BY-5177

INTRODUCTION

Thank you for choosing the BENYAR 5177 Luxury Business Mechanical Watch. This manual provides essential information for the proper setup, operation, and maintenance of your new timepiece. Designed for durability and precision, this automatic watch features a stainless steel construction, luminous hands, and water resistance suitable for daily wear.





Image: Front view of the BENYAR 5177 watch, showcasing its white dial, luminous markers, and polished stainless steel case and bracelet.

SETUP

Winding the Watch

Your BENYAR 5177 is an automatic mechanical watch, meaning it is powered by the motion of your wrist. However, for initial setup or if the watch has stopped, it requires manual winding.

- 1. Locate the Crown:** The crown is the small knob on the right side of the watch case.
- 2. Wind Manually:** With the crown in its normal, pushed-in position (position 0), turn it clockwise approximately 30-40 times. This will build up a power reserve to start the watch.
- 3. Self-Winding:** Once started, wearing the watch for at least 8-10 hours a day will keep it wound through your natural arm movements. If worn less frequently, occasional manual winding may be necessary.

Setting the Time

- 1. Pull out the Crown:** Gently pull the crown out to position 1 (first click).
- 2. Adjust Time:** Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
- 3. Push in the Crown:** Once the time is set, push the crown back into its normal position (position 0) to engage the movement and start the watch.

OPERATING THE WATCH

Wearing the Watch

Ensure the watch fits comfortably on your wrist. The stainless steel bracelet can be adjusted by a professional watchmaker to

remove or add links for a perfect fit. The folding buckle with the BENYAR logo provides a secure closure.



Image: The BENYAR 5177 watch being worn on a wrist, demonstrating its fit and appearance.

Luminous Display

The hands of your BENYAR 5177 watch feature a super strong luminous coating. This allows for easy readability in low-light conditions. The luminosity is charged by exposure to light.

MAINTENANCE AND CARE

Water Resistance

The BENYAR 5177 watch is designed with water resistance. However, it is crucial to follow these guidelines:

- **Avoid Extreme Temperatures:** Do not use the watch in extremely cold or extremely hot environments.
- **No Hot Water:** It is forbidden to use the watch in hot water (e.g., hot showers, saunas) to avoid moisture entering the watch.

- **Crown Position:** Always ensure the crown is fully pushed in when the watch is exposed to water.

While the watch is water-resistant, it is not designed for diving or prolonged submersion. Casual splashes or brief exposure to rain are generally acceptable.

Cleaning

To maintain the appearance of your watch:

- Wipe the case and bracelet regularly with a soft, dry cloth.
- For stubborn dirt on the stainless steel, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.



Image: The BENYAR 5177 watch displayed on a dark surface, highlighting its polished finish.

TROUBLESHOOTING

Watch Not Running or Stopping

- **Insufficient Power Reserve:** Manually wind the watch by turning the crown clockwise 30-40 times. Wear the watch consistently for several hours to allow the automatic movement to build up power.
- **Crown Not Pushed In:** Ensure the crown is fully pushed into position 0. If it's pulled out, the watch will not run.

Time Inaccuracy

- **Magnetic Fields:** Avoid exposing the watch to strong magnetic fields (e.g., speakers, refrigerators, certain electronic devices) as this can affect the accuracy of mechanical movements.
- **Service Needed:** If the watch consistently runs too fast or too slow despite proper winding and care, it may require professional servicing.

SPECIFICATIONS

BENYAR 5177 Key Specifications

Feature	Detail
Model Number	BY-5177
Movement	Automatic (G2666Z)
Case Thickness	14MM
Dial Diameter	41MM
Weight	152G
Max Perimeter	240MM
Band Width	21MM
Band Material	316L Stainless Steel
Dial Window Material	Hardlex
Clasp Type	Folding buckle / Push Button Deployment Clasp
Luminous Hands	Yes, Super strong Luminous Coating
Case Back	Back-through screw-in back cover



Image: A detailed view of the BENYAR 5177 watch, highlighting its craftsmanship and materials.

WARRANTY AND SUPPORT

For any questions, concerns, or warranty inquiries regarding your BENYAR 5177 watch, please contact the manufacturer or your point of purchase. Retain your proof of purchase for warranty validation.



Image: The BENYAR 5177 watch shown with its original packaging, emphasizing product presentation.


© 2023 BENYAR. All rights reserved.

Related Documents



[Benyar Watch User Manual and International Guarantee](#)

Explore the Benyar Watch User Manual, covering international guarantee details, premium materials like stainless steel and titanium, detailed function illustrations for time and date setting, mechanical watch operation, and essential care instructions.



[BENYAR BY-5140 Watch Setting Guide](#)

Comprehensive guide to setting the time, date, and using the stopwatch and tachymeter functions of the BENYAR BY-5140 chronograph watch.

Documents - BENYAR – BY-5177

no relevant documents