

Hape E3401B

Hape All Season Furnished Dollhouse Instruction Manual

Model: E3401B

INTRODUCTION

Thank you for choosing the Hape All Season Furnished Dollhouse. This manual provides essential information for the safe assembly, operation, and maintenance of your dollhouse. Please read these instructions carefully before use and retain them for future reference.

The Hape All Season Dollhouse is designed to inspire imaginative role-play and encourage the development of communication and social skills in children. Crafted from sustainably sourced wood with non-toxic finishes, this durable toy is built for years of creative play.

SAFETY INFORMATION

WARNING: Not suitable for children under 36 months due to small parts which may present a choking hazard.

- Adult assembly is required.
- Ensure all screws are securely tightened before allowing children to play.
- Regularly inspect the dollhouse for any loose parts or damage. Discontinue use if damaged.
- Keep packaging materials away from children to prevent suffocation.
- This product is intended for indoor use only.

PACKAGE CONTENTS

The Hape All Season Furnished Dollhouse package includes the following items:

- 1 Dollhouse structure
- **Bedroom Furniture:** 1 lamp, 1 bed, 1 wardrobe, 1 stool, 1 dresser, 1 carpet, 2 pillows, 1 quilt.
- **Bathroom Furniture:** 1 toilet, 1 washstand, 1 bathtub, 1 shower room, 1 duck, 1 towel, 1 carpet.
- **Living Room Furniture:** 2 sofas, 1 lamp, 1 plant, 1 fireplace, 1 tea table, 1 carpet, 3 sofa cushions, 1 TV, 1 TV

shelf.

- **Kitchen Furniture:** 1 fridge, 1 cabinet, 1 oven, 1 coffee maker, 2 pots, 1 towel.
- Assembly hardware (screws, Allen key)



Image: The Hape All Season Furnished Dollhouse, fully assembled, with a child interacting with it. This image shows the overall design and scale of the dollhouse.

ASSEMBLY INSTRUCTIONS

The Hape All Season Furnished Dollhouse requires adult assembly. Follow these general guidelines for a smooth assembly process:

1. **Review Instructions:** Carefully read through the entire assembly manual provided in the product packaging before beginning.
2. **Unpack and Inventory:** Unpack all components and verify that all parts listed in the "Package Contents" section are present. Lay out all pieces in an organized manner.
3. **Prepare Tools:** An Allen key is typically included for assembly. No additional tools should be required.
4. **Align Screws:** When attaching panels, align all screws in their respective holes before fully tightening any one screw. This helps prevent misalignment and ensures a secure fit.
5. **Secure Connections:** Tighten all screws firmly, but do not overtighten, to avoid damaging the wood.
6. **Final Check:** Once assembled, double-check all connections to ensure the dollhouse is stable and secure.

1: 12 SCALE DOLLHOUSE FURNITURE SETS



Image: A diagram highlighting key features of the dollhouse, including the reversible winter/summer themed roof with solar panels, movable stairs, solid balcony, and openable door. This visual aid can assist during assembly and understanding functionality.

OPERATING INSTRUCTIONS (PLAY GUIDE)

The Hape All Season Furnished Dollhouse offers a versatile play experience.

- **Role-Playing:** Encourage children to create stories and scenarios with their dollhouse family and furniture. The six rooms across three levels provide ample space for various play settings.
- **Seasonal Play:** The roof is reversible, featuring a summer side with solar panels and a winter side. Children can flip the roof to change the season of their dollhouse.
- **Furniture Arrangement:** The included furniture sets for the bedroom, bathroom, living room, and kitchen can be arranged and rearranged to suit different play narratives.
- **Interactive Features:** Utilize the movable stairs to connect different floors, open and close the front door, and use the solid balcony for outdoor scenes.



Image: Close-up views of various furniture sets included with the dollhouse, such as bedroom, living room, bathroom, and kitchen items. This illustrates the detailed accessories for play.

MAINTENANCE

To ensure the longevity and safety of your Hape All Season Furnished Dollhouse:

- **Cleaning:** Wipe the dollhouse and furniture with a damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all wooden components and connections for wear, damage, or loose screws. Tighten any loose screws as needed.
- **Storage:** Store the dollhouse in a dry environment, away from direct sunlight or extreme temperatures, to prevent warping or fading of the wood and paint.
- **Material Safety:** The dollhouse is made from durable, sustainably sourced wood and finished with non-toxic, child-

safe paints.

TROUBLESHOOTING


This product is designed for durability and ease of use. Should you encounter any issues, please consider the following:

- **Loose Connections:** If any part feels wobbly, check and tighten all screws.
- **Missing Parts:** If you believe parts are missing upon unboxing, refer to the "Package Contents" list and contact Hape customer support.
- **Damage:** If any component is damaged, discontinue use and contact customer support for replacement parts or guidance.

SPECIFICATIONS

Feature	Detail
Model Number	E3401B
Product Dimensions (L x W x H)	59.99 x 30 x 73.41 cm (23.62 x 11.81 x 28.9 inches)
Item Weight	6.39 kg (14.08 lbs)
Recommended Age	36 months - 6 years
Main Material	Wood
Number of Pieces (Dollhouse & Furniture)	36
Assembly Required	Yes
Batteries Required	No
Educational Value	Literacy awareness, spatial awareness

**Reversible winter/
summer themed
& solar-paneled roof**



Moveable stairs



Solid balcony



Openable Door

Image: A diagram illustrating the key dimensions of the Hape All Season Dollhouse, including height, width, and depth, for reference.

WARRANTY AND SUPPORT

Specific warranty details are not provided in this manual. For information regarding warranty, replacement parts, or customer support, please refer to the official Hape website or contact your retailer.

You can visit the Hape website for more information: www.hapetoys.com

© Hape. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question