

MohMus Universal Compatibility

MohMus Premium Microfibre Vacuum Cleaner Dust Bags and Universal Filters User Manual

INTRODUCTION

This manual provides instructions for the proper installation, use, and maintenance of your MohMus Premium Microfibre Vacuum Cleaner Dust Bags and Universal Filters. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

PRODUCT OVERVIEW

The MohMus Premium Vacuum Cleaner Dust Bags are designed for a wide range of vacuum cleaner models, offering superior filtration and dust retention. Each set includes 20 multi-layer microfibre dust bags and 2 universal cut-to-size filters.

Key Features:

- **Multi-layer Microfibre Material:** Ensures high filtration efficiency and durability.
- **Dust Closure Flap:** Prevents dust spills during bag removal and disposal.
- **Optimal Filtration:** Captures fine dust particles, contributing to cleaner air.
- **Universal Filters:** Can be cut to fit various vacuum cleaner models.



2x



2x UNIVERSAL FILTER
ZUM ZUSCHNEIDEN

2x UNIVERSAL FILTER
CUT TO SIZE

Image: A stack of MohMus Premium Microfibre Vacuum Cleaner Dust Bags, illustrating the product's primary component.

COMPATIBILITY

These dust bags and filters are compatible with various vacuum cleaner models, including but not limited to:

- Ufesa: Mat 402 to 603, Mat 502 electronic, Mat 805 Turbo electronic, MT 302, MT 603, MT 704
- EIO: Typ 9, 9A, 9B, 14, 26, Pro Nature Eco+, Vivo Serie, Topo, Villa, Eco 2
- Melitta Swirl Handy-Bag EIO 80
- Quigg
- Profimaster

Always refer to your vacuum cleaner's manual for specific bag type requirements.

INSTALLATION INSTRUCTIONS

1. Preparing the Universal Filter:

1. Locate the existing filter in your vacuum cleaner.
2. Carefully remove the old filter.
3. Place the new universal filter over the old filter and trace its shape.
4. Using scissors, cut the new universal filter to the required size.
5. Insert the newly cut filter into the designated filter compartment of your vacuum cleaner.




Image: Two universal filters, with an icon indicating they can be cut to size for various vacuum cleaner models.

2. Installing the Dust Bag:

1. Ensure your vacuum cleaner is unplugged from the power outlet.
2. Open the vacuum cleaner's dust bag compartment.
3. Remove the full dust bag, utilizing the dust closure flap to prevent dust from escaping.
4. Carefully insert a new MohMus dust bag into the compartment, ensuring it is correctly seated and sealed around the inlet.

5. Close the dust bag compartment securely.
6. Plug in your vacuum cleaner and resume operation.




Image: A three-step illustration showing the dust closure flap mechanism, designed to prevent dirt spills when removing the vacuum bag.

OPERATING INSTRUCTIONS

Once the dust bag and filter are correctly installed, operate your vacuum cleaner as per its manufacturer's instructions. The MohMus dust bags are designed to maintain optimal suction power until they are full.

When to Change the Dust Bag:

- When the vacuum cleaner's suction power noticeably decreases.
- When the "bag full" indicator (if present on your vacuum cleaner) illuminates.
- When the dust bag appears visibly full.

Important: Do not overfill the dust bag, as this can reduce vacuum performance and potentially damage the

appliance.

MAINTENANCE

Dust Bag Replacement:

Regularly check and replace the dust bag as indicated in the "Operating Instructions" section. Timely replacement ensures consistent cleaning performance and extends the life of your vacuum cleaner.

Filter Replacement:

The universal filter should be replaced every 3-6 months, or more frequently if you notice a decrease in air quality or vacuum performance. Always ensure the replacement filter is cut to the correct size for your vacuum cleaner.

Storage:

Store unused dust bags and filters in a cool, dry place away from direct sunlight and moisture to maintain their integrity.

TROUBLESHOOTING

Reduced Suction Power:

- **Check Dust Bag:** The dust bag may be full. Replace it with a new one.
- **Check Filter:** The filter may be clogged. Replace or clean the universal filter as needed.
- **Obstruction:** Inspect the vacuum cleaner hose, nozzle, and attachments for any blockages.

Dust Leaking from Vacuum Cleaner:

- **Bag Installation:** Ensure the dust bag is correctly installed and sealed within its compartment.
- **Bag Damage:** Check the dust bag for any tears or holes. Replace if damaged.
- **Filter Placement:** Verify the filter is properly seated and not damaged.

SPECIFICATIONS

Feature	Detail
Product Type	Vacuum Cleaner Dust Bags and Universal Filters
Brand	MohMus
Material	Multi-layer Microfibre
Quantity	20 Dust Bags, 2 Universal Filters
Filter Type	Cut-to-size Universal Filter
Compatibility	Compatible with various Ufesa, EIO, Melitta, Quigg, Profimaster models (see Compatibility section)



Unsere Staubsaugerbeutel bestehen aus mehrlagigem Mikrovließ

Our vacuum cleaner dust bags are made of multi layer microfibre

Image: A close-up view of the multi-layer microfiber material used in the dust bags, highlighting its construction.



Unsere Staubsaugerbeutel sind aus sehr reißfestem Mikrovlies

Our vacuum cleaner dust bags are made of strong microfibre

Image: A detailed close-up showing the strong, tear-resistant microfibre material of the vacuum cleaner dust bags.

WARRANTY AND SUPPORT

For specific warranty information or support regarding your MohMus Premium Vacuum Cleaner Dust Bags and Universal Filters, please refer to the product packaging or contact your retailer. As these are consumable items, warranty terms typically cover manufacturing defects.

For further assistance, you may also visit the [MohMus brand page on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08RCBS2KP>

More documents and user manuals: **<https://manuals.plus/>**