

Thule 10101950

Thule Urban Glide 2 Single Instruction Manual

Model: 10101950

INTRODUCTION

Welcome to the Thule Urban Glide 2 Single instruction manual. This guide provides essential information for the safe and effective use, assembly, maintenance, and troubleshooting of your Thule Urban Glide 2 Single all-terrain stroller. Designed for active families, this stroller offers a sleek, lightweight design and an easy one-handed compact fold, making it ideal for various activities and environments. Please read this manual thoroughly before using your stroller.

IMPORTANT SAFETY INFORMATION

Always prioritize the safety of your child. Failure to follow these instructions could result in serious injury.

- Never leave your child unattended in the stroller.
- Always use the safety harness. Ensure it is correctly fitted and adjusted.
- Ensure all locking devices are engaged before use.
- Do not overload the stroller or the storage basket.
- Do not use accessories not approved by Thule.
- Be aware of the risks of open flames and other heat sources.
- This stroller is designed for one child only.
- The maximum weight recommendation for the child is 22 kilograms (48.5 lbs).
- Always engage the brake when the stroller is stationary.

SETUP AND ASSEMBLY

Follow these steps to assemble your Thule Urban Glide 2 Single stroller.

1. Unfolding the Stroller

1. Place the folded stroller on a flat surface.
2. Release the folding latch, typically located on the side of the frame.

3. Lift the handlebar and pull upwards until the frame locks into place. You should hear a click.
4. Ensure all frame locks are securely engaged before proceeding.



Image: The Thule Urban Glide 2 Single stroller fully unfolded, showcasing its sleek design and three-wheel configuration.

2. Attaching the Wheels

- **Rear Wheels:** Push each rear wheel axle into the corresponding opening on the stroller frame until it clicks securely into place. Pull on the wheel to ensure it is locked.
- **Front Wheel:** Insert the front wheel assembly into the designated slot at the front of the stroller. Ensure it is fully seated and the quick-release lever (if present) is closed.



Image: A detailed view of the Thule Urban Glide 2 Single stroller with its canopy extended, highlighting the wheel attachment points and overall frame.

3. Installing the Canopy and Seat Fabric

The canopy and seat fabric are typically pre-installed. If not, refer to the specific instructions provided with your packaging for attachment. Ensure all snaps, zippers, and Velcro straps are securely fastened.

4. Attaching Accessories (Optional)

The Thule Urban Glide 2 Single can be adapted with various accessories, such as a bassinet or car seat adapter.

- **Bassinet:** To attach a bassinet, remove the standard seat fabric (if applicable) and follow the bassinet's specific instructions for secure attachment to the frame.
- **Car Seat Adapter:** Install the car seat adapter onto the stroller frame according to its instructions. Ensure the car seat clicks securely into the adapter before placing a child in it.



Image: The stroller configured with a bassinet, providing a comfortable lying position for newborns.



Image: The stroller configured with a car seat, demonstrating compatibility for infant travel systems.

OPERATING INSTRUCTIONS

1. Securing Your Child

Always use the 5-point harness system to secure your child.

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their hips.
3. Connect the shoulder and waist buckles into the central buckle.
4. Adjust the straps to ensure a snug, secure fit. The harness features adjustable straps and padded shoulders for comfort.

2. Adjusting the Seat Recline

The seat offers multiple recline positions for your child's comfort. Locate the recline strap or lever behind the seat and adjust to the desired angle. Ensure the child is safely secured before adjusting.

3. Adjusting the Handlebar

The ergonomic handlebar is adjustable to suit different user heights. Locate the adjustment buttons or levers on either side of the handlebar and adjust to a comfortable pushing height. Ensure it locks securely in place.

4. Using the Brake System

The Thule Urban Glide 2 Single features an integrated twist hand brake for speed control and a foot-operated parking brake.

- **Parking Brake:** Press down on the foot pedal located near the rear wheels to engage the parking brake. Lift the pedal to release. Always engage the parking brake when the stroller is stationary.
- **Hand Brake:** The twist hand brake on the handlebar provides deceleration control, especially useful when jogging or descending hills. Twist the lever to apply braking force.

5. Folding the Stroller

The stroller features an easy one-handed compact fold.

1. Ensure the seat is in the upright position and the canopy is retracted.
2. Locate the folding mechanism (often a strap or lever in the seat area).
3. Pull the mechanism firmly, and the stroller will begin to fold.
4. Continue to fold until the stroller is compact and the auto-lock engages.



Image: A user demonstrating the ease of pushing the Thule Urban Glide 2 Single stroller through an urban landscape.

CARE AND MAINTENANCE

Regular maintenance will extend the life and ensure the safety of your Thule Urban Glide 2 Single stroller.

- **Cleaning:**

- **Fabric:** Spot clean fabric parts with a mild soap and cold water. Do not use bleach. Air dry thoroughly. The polyester fabric is designed to be durable.
- **Frame:** Wipe the aluminum frame with a damp cloth and mild detergent. Dry completely to prevent corrosion.

- **Wheels:**

- Inspect wheels regularly for wear and tear.
- Keep tires properly inflated (refer to tire sidewall for recommended pressure).
- Clean any dirt or debris from the wheel axles and swivel mechanism. Lubricate moving parts with a silicone-based lubricant if necessary.

- **Storage:** Store the stroller in a dry, well-ventilated area, away from direct sunlight and extreme temperatures.
- **Inspections:** Periodically check all fasteners, rivets, and connections to ensure they are secure. Replace any worn or damaged parts immediately.

TROUBLESHOOTING

If you encounter issues with your stroller, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Stroller does not unfold or fold easily.	Folding mechanism is jammed or not fully released/engaged.	Ensure the folding latch is fully released. Check for any obstructions in the folding mechanism. Apply a silicone lubricant to moving parts if stiff.
Wheels squeak or are difficult to turn.	Dirt/debris in axles, low tire pressure, or lack of lubrication.	Clean wheels and axles. Inflate tires to recommended pressure. Apply silicone lubricant to wheel bearings and swivel mechanisms.
Brake is not engaging properly.	Brake cable tension is loose or mechanism is obstructed.	Check for obstructions around the brake mechanism. If the hand brake is loose, it may require adjustment of the cable tension (consult a service center if unsure). Ensure the foot brake pedal is fully depressed.
Stroller pulls to one side.	Uneven tire pressure or front wheel alignment issue.	Check and adjust tire pressure on all wheels. Ensure the front wheel is locked straight if not in swivel mode.

If you cannot resolve the issue using these steps, please contact Thule customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Thule
Model Number	10101950
Color	Dark Shadow
Material (Frame)	Aluminum
Material (Fabric)	Polyester
Material (Tire)	Rubber
Seating Capacity	1
Stroller Type	Jogging Stroller
Harness Type	5 Point (Adjustable straps, padded shoulders)
Number of Wheels	3 (2 x 16in rear, 1 x swivel front)
Item Weight	11.5 Kilograms

Feature	Detail
Maximum Weight Recommendation	22 Kilograms
Folded Size	31.5*11.8 Inches
Included Components	Large cargo basket with zip-top cover, rear mesh pocket, and two mesh compartments
Safety Standard	ASTM

WARRANTY INFORMATION

Thule products are tested rigorously and are guaranteed against defects in materials and workmanship. Specific warranty terms and conditions may vary by region and product. Please retain your proof of purchase. For detailed warranty information, please visit the official Thule website or contact customer support.

CUSTOMER SUPPORT

For further assistance, spare parts, or to report an issue, please contact Thule customer support.

- **Online Support:** Visit the official Thule website for FAQs, product registration, and contact forms.
- **Phone Support:** Refer to the Thule website for regional contact numbers.
- **Retailer Support:** Your authorized Thule retailer can also provide assistance and service.

[Visit the Thule Store on Amazon](#) for more products and information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question