

Norelco CC12/52

Norelco Philips Quick Clean Pod Cartridge Instruction Manual

Model: CC12/52


1. INTRODUCTION

The Norelco Philips Quick Clean Pod Cartridge (Model CC12/52) is designed to maintain the optimal performance and hygiene of your Philips electric shaver. This alcohol-free, skin-friendly cleaning solution effectively removes cut hair and debris, ensuring your shaver remains clean, lubricated, and ready for use. Regular use contributes to a more comfortable and hygienic shaving experience.

2. SETUP

2.1 Unboxing the Cartridge

Carefully remove the Quick Clean Pod Cartridge from its packaging. Each package contains two cartridges, ensuring a continuous supply for your cleaning needs.



Thorough cleaning
in 1 minute

Image: Norelco Philips Quick Clean Pod Cartridge in its retail box.

For a visual guide on unboxing, please refer to the video below:

Your browser does not support the video tag.

Video: Unboxing the Philips Quick Clean Pod Cartridge. This video demonstrates how to open the packaging and access the cleaning cartridges.

2.2 Preparing the Quick Clean Pod

Remove the lid from the Quick Clean Pod. Peel off the protective seal from the new cartridge. Insert the cartridge into the Quick Clean Pod base, ensuring it clicks securely into place.



Image: Norelco Philips Quick Clean Pod Cartridge, showing the lid and protective seal to be removed before use.

3. OPERATING INSTRUCTIONS

3.1 Placing the Shaver in the Pod

After shaving, gently tap your shaver to remove excess hair. Place your Philips electric shaver upside down into the Quick Clean Pod, ensuring the shaver head is fully immersed in the cleaning fluid.

Your browser does not support the video tag.

Video: Philips Quick Clean Pod in action, demonstrating how to place the shaver into the cleaning pod and initiate the cleaning cycle.

3.2 Starting the Cleaning Cycle

Press the power button on your shaver to activate the cleaning cycle. The Quick Clean Pod will automatically begin a deep cleaning process, typically lasting about 1 minute. The system uses three high-pressure cleaning jets to thoroughly clean the shaver head.




Image: An electric shaver head undergoing a thorough cleaning process in the Quick Clean Pod, highlighting the 1-minute cleaning time.

For a detailed demonstration of the cleaning process, watch the video below:


Your browser does not support the video tag.

Video: A demonstration of how the Norelco Philips Quick Clean Pod works, showing the shaver's cleaning cycle.

4. MAINTENANCE

4.1 Cartridge Lifespan and Replacement

Each Philips Quick Clean Pod Cartridge is effective for approximately 30 cleaning cycles with daily usage, or up to three months with weekly usage. Replace the cartridge when the cleaning fluid appears visibly dirty or after the recommended usage period to ensure continued optimal cleaning performance.




<p>Fresh fragrance for a clean-feeling shave</p> <p>The cleaning cartridge's special fragrance smells fresh and gives you a clean feel while shaving.</p>	<p>Completely alcohol-free formula</p> <p>The alcohol-free, skin-friendly formula gives you a fresh and hygienic shave.</p>
--	--

Image: Visual guide for replacing the Quick Clean Pod Cartridge every 1-3 months, depending on usage.

4.2 Shaver Lubrication

The cleaning fluid contains special lubricants that help maintain the shaver's performance and extend the life of its blades. After the cleaning cycle, allow the shaver to air dry in the pod or on a clean surface. Do not wipe the shaver head with paper towels or cloths, as this can damage the blades and leave fibers.



**Deep cleaning
in just 1 minute**

10x more effective versus cleaning
with water*

*with cleaning fluid vs. water in the cartridge

**Active
lubrication**

The formula, enriched with active
lubricants, keeping your shaver
performing at its best for longer.

Image: Active lubrication of the shaver blades, a key benefit of the cleaning cartridge.

5. KEY FEATURES AND BENEFITS

- **Thorough Cleaning:** Philips exclusive hygienic formula with a multi-grid filter effectively eliminates cut hair and leaves your shaver 10 times cleaner versus water alone.
- **Active Lubrication:** Special lubricants keep your electric shaver performing at its best, ensuring efficient cut hair removal and deep cleaning in just 1 minute.
- **Alcohol-Free & Skin-Friendly:** The formula is completely alcohol-free and gentle on the skin, providing a clean and hygienic shave without irritation.
- **Refreshing Scent:** A special fragrance provides a fresh feel after each cleaning cycle.
- **Extended Lifespan:** Regular cleaning and lubrication help prolong the life of your shaver's blades.



Replace
cartridge every
1-3 months

Image: The alcohol-free formula ensures a gentle and hygienic shave.



**Refreshing scent
for a clean feel**

Image: The cleaning cartridge provides a refreshing scent for a clean feel.

6. SPECIFICATIONS

Product Dimensions	3.86 x 3.86 x 4.49 inches
Item Model Number	CC12/52
Item Form	Liquid
Scent	Refreshing Scent
Specific Uses For Product	Electronic Shaver
Special Features	Alcohol Free
Item Volume	160 Milliliters (5.41 Fl Oz) per cartridge
Number of Items	2
Item Weight	1.11 Pounds (for 2-pack)
Manufacturer	Philips Norelco

7. TROUBLESHOOTING

If your shaver is not cleaning effectively, ensure the cartridge is correctly installed and contains sufficient fluid. Verify that the shaver head is properly seated in the Quick Clean Pod. If issues persist, consider replacing the cartridge or consulting your shaver's specific user manual for further guidance.

8. WARRANTY AND SUPPORT

For product support, warranty information, or to purchase additional cartridges, please visit the official Philips Norelco website or contact their customer service. Keep your purchase receipt for any warranty claims.