

Funsicle 7' x 5' x 24" Rectangular Activity Lap Pool

Funsicle 7' x 5' x 24" Rectangular Above Ground Activity Lap Pool Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your Funsicle 7' x 5' x 24" Rectangular Above Ground Activity Lap Pool. Please read all instructions carefully before setting up and using the pool. Retain this manual for future reference.

SAFETY INFORMATION

WARNING: Failure to follow these instructions can result in serious injury or death.

- Adult supervision is required at all times when children are in or near the pool.
- Never dive or jump into this pool. It is not deep enough for diving.
- Ensure the pool is set up on a firm, level surface free of sharp objects.
- Keep children away from the pool when it is being filled or drained.
- Do not sit, stand, or climb on the pool frame.
- Empty the pool completely when not in use to prevent water accumulation, which can be a drowning hazard for small children.
- Always follow local regulations regarding pool fencing and safety barriers.
- Do not use electrical appliances near the pool.

PARTS LIST

Verify that all components are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly. Contact customer support.

- Pool Liner (1)
- Horizontal Top Beams (Quantity varies by model, check packaging)
- Vertical Legs (Quantity varies by model, check packaging)

- Corner Joints / T-Connectors (Quantity varies by model, check packaging)
- Leg Caps (Quantity varies by model, check packaging)
- Repair Patch (1)

SETUP INSTRUCTIONS

Follow these steps for proper assembly of your Funsicle Activity Lap Pool.

1. **Site Selection:** Choose a flat, level area in your yard. The ground must be firm and free of any sharp objects, rocks, or debris that could puncture the pool liner. Ensure the area is large enough to accommodate the pool and allow for safe access around it.
2. **Unpack Components:** Carefully unpack all parts and lay them out on a clean, soft surface. Refer to the parts list to ensure everything is accounted for.
3. **Assemble Frame:** Begin by connecting the horizontal top beams to the corner joints and T-connectors. The SmartConnect technology allows for easy snap-in assembly. Listen for a "click" to confirm secure connection.
4. **Attach Vertical Legs:** Insert the vertical legs into the T-connectors and corner joints. Ensure the leg caps are placed on the bottom of each vertical leg to protect the ground and provide stability.
5. **Install Pool Liner:** Carefully spread the pool liner inside the assembled frame. Ensure the drain plug is positioned correctly for future draining. Smooth out any wrinkles in the bottom of the liner.

Activity™ Lap Pool Features:



Figure 1: Key features of the Funsicle Activity Lap Pool, including the SmartConnect frame for easy assembly, the convenient quick-release drain plug with garden hose connection, and the durable puncture-resistant liner composed of three layers: polyester mesh between heavy gauge PVC materials.




Figure 2: Detailed view of the pool liner's construction, highlighting the heavy gauge PVC material on the exterior and interior, with a reinforcing polyester mesh layer sandwiched in between for enhanced durability and puncture resistance.

OPERATING INSTRUCTIONS

1. **Filling the Pool:** Begin filling the pool with water. As the water level rises, gently smooth out any remaining wrinkles in the bottom of the liner. Fill the pool to the recommended water line, typically indicated on the liner or in the product specifications. Do not overfill.
2. **Water Treatment:** For prolonged use, it is recommended to treat the pool water with appropriate pool chemicals to maintain hygiene and clarity. Consult a pool supply professional for suitable products and dosage instructions for your pool size.
3. **Supervision:** Always ensure constant adult supervision when the pool is in use, especially with children.

MAINTENANCE

Regular maintenance will extend the life of your pool and ensure a safe swimming environment.

- **Cleaning:** Regularly remove debris from the water surface and bottom using a pool skimmer and vacuum. Wipe down the pool walls as needed.
- **Water Chemistry:** Test water chemistry regularly (pH, chlorine levels) and adjust as necessary according to recommended guidelines for safe swimming.
- **Liner Inspection:** Periodically inspect the pool liner for any signs of wear, tears, or punctures. Use the included repair patch for minor damages.

- **Frame Inspection:** Check the frame components for rust or damage. Ensure all connections remain secure.
- **Draining:** To drain the pool, connect a garden hose to the quick-release drain plug and open the plug. Direct the water to a suitable drainage area away from foundations or electrical equipment.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Water leaking from pool	Puncture in liner; Loose drain plug	Locate puncture and apply repair patch. Ensure drain plug is securely closed.
Pool frame unstable	Uneven ground; Loose frame connections	Drain pool and relocate to a level surface. Check all SmartConnect poles for secure "click" connections.
Water cloudy or green	Improper water chemistry; Lack of filtration (if applicable)	Test water and adjust chemical levels (chlorine, pH). Consider adding a filtration system if not already in use.

STORAGE

When not in use for extended periods, or during colder months, it is recommended to disassemble and store the pool.

1. **Drain Pool:** Completely drain all water from the pool using the drain plug.
2. **Clean and Dry:** Thoroughly clean the pool liner and frame components. Ensure all parts are completely dry before storage to prevent mold, mildew, and rust.
3. **Disassemble:** Carefully disassemble the frame by reversing the assembly steps.
4. **Store:** Store the liner and frame components in a dry, cool place, protected from direct sunlight and extreme temperatures. Keep away from rodents and insects.

SPECIFICATIONS

Feature	Detail
Model	7' x 5' x 24" Rectangular Activity Lap Pool
Dimensions (L x W x H)	84"L x 60"W x 24"H (7 ft x 5 ft x 2 ft)
Shape	Rectangular
Material	Metal frame, Heavy Gauge PVC with Polyester Mesh liner
Assembly Required	Yes (SmartConnect Technology)
Indoor/Outdoor Usage	Outdoor
Included Components	Liner, Repair Patch



Figure 3: The Funsicle Activity Lap Pool, illustrating its 24-inch height, providing a suitable depth for recreational use.

WARRANTY AND SUPPORT

This Funsicle Activity Lap Pool comes with a **1-year manufacturer warranty**. For warranty claims, missing parts, or technical support, please contact Summer Waves customer service.

For additional resources and support, you may visit the official product page or scan the QR code on your product packaging. A direct link for product information is available at: funsicle.co/ActivityQR

Manufacturer: Polygroup