

Accutime MNL3016AZ

Accutime Star Wars Mandalorian Wall Clock Instruction Manual

Model: MNL3016AZ

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Accutime Star Wars Mandalorian Wall Clock. Please read this manual thoroughly before using the product to ensure proper function and longevity.

PACKAGE CONTENTS

- Accutime Star Wars Mandalorian Wall Clock (Model MNL3016AZ)
- Instruction Manual (this document)

Note: 1 x AA battery is required and not included in the package.

SETUP

1. Battery Installation:

Locate the battery compartment on the back of the clock. Insert one (1) AA battery, ensuring the polarity (+/-) matches the diagram inside the compartment. Close the battery cover securely.



Image: Rear view of the clock, highlighting the battery compartment and the integrated hook for wall mounting.

2. Setting the Time:

On the back of the clock, locate the time-setting knob (usually a small wheel or dial). Rotate this knob in either direction until the clock hands display the correct time. Ensure the minute and hour hands are aligned properly.

3. Mounting the Clock:

The clock is designed for wall mounting. Use the integrated hook on the back of the clock to hang it securely on a nail or screw in your desired location. Ensure the mounting point is sturdy enough to support the clock's weight (approximately 1.09 pounds).



Image: Front view of the Accutime Star Wars Mandalorian Wall Clock, displaying the Grogu character and numerical dial.

OPERATION

Once the battery is installed and the time is set, the clock will begin to operate automatically. The quartz mechanism ensures accurate timekeeping.

Note on Second Hand: The clock features a mechanical movement with a second hand that produces an audible ticking sound. This is a normal characteristic of the clock's design.



Image: Angled view of the Accutime Star Wars Mandalorian Wall Clock, showcasing its green frame and the detailed Grogu illustration on the clock face.

MAINTENANCE

- **Cleaning:** To clean the clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the plastic material or the clock face.
- **Battery Replacement:** Replace the AA battery approximately once a year, or when the clock begins to lose time or stop functioning. Always use a fresh, high-quality AA battery.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--|--|--|
| Clock not running or stops intermittently. | Dead or low battery; improperly installed battery. | Replace the AA battery with a new one. Ensure the battery is inserted with correct polarity. |
| Clock hands are not moving or are stuck. | Obstruction; internal mechanism issue. | Gently check if anything is obstructing the hands. If not, replace the battery. If the problem persists, contact customer support. |
| Time is inaccurate. | Low battery; time not set correctly. | Replace the AA battery. Reset the time using the setting knob on the back. |

SPECIFICATIONS

| | |
|----------------------|---|
| Brand | Accutime |
| Model Number | MNL3016AZ |
| Display Type | Analog |
| Power Source | Battery Powered (1 x AA battery required, not included) |
| Material | Plastic |
| Mounting Type | Wall Mount |
| Item Weight | 1.09 Pounds |
| Dimensions (Package) | 10.67 x 10.43 x 0.67 inches |
| Theme | Star Wars, Character (Grogu/The Child) |

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Accutime website. Keep your purchase receipt as proof of purchase.

You can visit the [Accutime Store on Amazon](#) for more information.