

[Manuals.plus](#) /

› [AUDIOTEK](#) /

› AUDIOTEK K69.5 6x9 Inch Car Audio Speakers Instruction Manual

AUDIOTEK K69.5

AUDIOTEK K69.5 6x9 Inch Car Audio Speakers Instruction Manual

Model: K69.5

INTRODUCTION

Thank you for choosing AUDIOTEK K69.5 6x9 Inch Car Audio Speakers. This manual provides essential information for the proper installation, operation, and maintenance of your new speakers. Please read these instructions carefully before proceeding with installation or use to ensure optimal performance and longevity of your product.

SETUP AND INSTALLATION

Proper installation is crucial for the performance and durability of your speakers. It is recommended that installation be performed by a qualified professional if you are unfamiliar with car audio wiring and mounting procedures.

Unpacking

Carefully remove the speakers from their packaging. Verify that all components listed in the 'What's in the Box' section are present. Inspect the speakers for any signs of damage that may have occurred during shipping.

Mounting

The AUDIOTEK K69.5 speakers are designed for standard 6x9 inch openings. Ensure the mounting surface is flat and stable. The required mounting depth is 3.13 inches (7.95 cm) and the mounting hole dimensions are 8.8 inches x 6 inches (22.35 cm x 15.24 cm).



Image: AUDIOTEK K69.5 6x9 Inch Car Audio Speaker with Grille. This image shows the speaker with its protective grille, ready for installation.



Image: Side Profile of AUDIOTEK K69.5 Speaker, Illustrating Mounting Depth. This view highlights the speaker's depth, essential for checking compatibility with vehicle mounting locations.

1. **Prepare the Mounting Location:** If replacing existing speakers, remove them. If installing in a new location, carefully cut the appropriate size and shape hole, ensuring no wires or vehicle components are damaged.
2. **Connect Wiring:** Connect the speaker wires from your car's audio system to the terminals on the back of the speaker. Ensure correct polarity (positive to positive, negative to negative) to prevent phase issues and ensure optimal sound quality. The speakers have an impedance of 4 ohms.
3. **Secure the Speaker:** Place the speaker into the mounting hole. Use the provided screws to secure the speaker firmly to the mounting surface. Do not overtighten.
4. **Install Grille (Optional):** If desired, attach the speaker grille over the speaker for protection.

Wiring Considerations

These speakers are rated for 700 Watts each (1400 Watts for a pair). Ensure your amplifier or head unit can provide adequate power without exceeding the speaker's maximum input to prevent damage. Mismatched power can lead to distortion or speaker failure.

OPERATING INSTRUCTIONS

Once installed, operating your AUDIOTEK K69.5 speakers is straightforward. They are designed to integrate seamlessly with your car's audio system.

1. **Power On:** Turn on your car's audio system (head unit/receiver).
2. **Audio Source:** Select your desired audio source (radio, CD, Bluetooth, etc.).
3. **Adjust Volume:** Gradually increase the volume to a comfortable listening level. Avoid excessively high volumes that cause audible distortion, as this can damage the speakers.
4. **Sound Adjustment:** Use your head unit's equalizer or tone controls to adjust bass, treble, and other audio settings to your preference. The speakers have an effective frequency range of 30Hz - 20kHz and a sensitivity of 88 dB.



Image: AUDIOTEK K69.5 6x9 Inch Car Audio Speaker without Grille. This image displays the speaker's cone, tweeter, and mid-range components.

MAINTENANCE

Regular, simple maintenance will help ensure your AUDIOTEK K69.5 speakers continue to perform well for years.

- **Cleaning:** Use a soft, dry cloth to gently wipe away dust and dirt from the speaker grilles and cones. Avoid

using harsh chemicals or abrasive cleaners, which can damage the speaker materials (Polypropylene woofer cone, PEI tweeter dome, rubber surround).

- **Inspection:** Periodically check the speaker mounts and connections to ensure they are secure. Loose connections can lead to poor sound quality or intermittent operation.
- **Environmental Factors:** While designed for automotive use, avoid exposing speakers to extreme moisture or direct sunlight for prolonged periods, as this can degrade materials over time.

TROUBLESHOOTING

If you experience issues with your AUDIOTEK K69.5 speakers, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from speaker(s)	Loose or incorrect wiring; head unit/amplifier issue; speaker damage.	Check all wiring connections for proper polarity and secure fit. Test with another audio source or speaker if possible. Consult a professional if speaker damage is suspected.
Distorted or unclear sound	Volume too high; incorrect audio settings; loose mounting; speaker damage; amplifier clipping.	Reduce volume. Adjust bass/treble settings on your head unit. Ensure speakers are securely mounted. Verify amplifier gain settings are not too high.
Rattling or buzzing noise	Loose mounting screws; foreign object in speaker cone; speaker damage.	Check and tighten all mounting screws. Inspect the speaker cone and surround for any obstructions or tears. If damage is visible, speaker replacement may be necessary.
Weak or no bass	Incorrect wiring polarity; bass settings too low; speaker damage.	Verify correct wiring polarity. Increase bass settings on your head unit.

If these steps do not resolve the issue, please contact customer support for further assistance.

SPECIFICATIONS

The following table details the technical specifications for the AUDIOTEK K69.5 6x9 Inch Car Audio Speakers:

Feature	Detail
Brand	AUDIOTEK
Model Number	K69.5
Speaker Type	5-Way Full Range Coaxial Speaker
Speaker Size	6 x 9 Inches
Maximum Output Power	700 Watts (Each), 1400 Watts (Pair)
Impedance	4 Ohms

Feature	Detail
Effective Frequency Range	30Hz - 20kHz
Frequency Response (Specified)	45 Hz to 20 KHz
Sensitivity	88 dB
Mounting Depth	3.13 Inches (7.95 cm)
Mounting Hole Dimensions	8.8 Inches x 6 Inches (22.35 cm x 15.24 cm)
Woofer Cone Material	Polypropylene
Tweeter Dome Material	PEI (Polyether Imide)
Surround Material	Rubber
Voice Coil	High-temperature resistant
Basket Material	Stamped (Good corrosion resistance, high thermal/electrical conductivity)
Connectivity Technology	Wired
Number of Items	2 (pairs of 6x9 inch speakers)



Image: Rear View of AUDIOTEK K69.5 Speaker, Showing Model and Power Ratings. This image displays the back of the speaker, including the model number K69.5 and maximum power rating.

WARRANTY INFORMATION

AUDIOTEK K69.5 6x9 Inch Car Audio Speakers come with a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, accident, misuse, abuse, neglect, unauthorized modification, or normal wear and tear.

Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the documentation included with your product or contact customer support.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to make a warranty claim, please contact the seller or manufacturer directly. Have your product model number (K69.5) and proof of purchase ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question